



## DIGI-BELT XF-3000 BELT Tension Tester Digital Measurement Tool Instructions

The Digi-Belt™ tension measurement tool is easy to use and gives repeatable belt tension measurements. The following instructions for use define the procedure for different belted applications. You must have the force deflection values for the system you are working on. These values are readily available from your belt and machine manufactures.

Model 3000-110 Maximum Deflection Force 110 lbs.

Model 3000-220 Maximum Deflection Force 220 lbs.


Section 1. Basic Single & Multi Belt Tensioning Procedure

Section 2. XF B.A.T. Green Laser Single & Multi Belt Tensioning Procedure

Section 3. Wide Belt Procedure Using Wide Belt Adapters

Section 4: Reference photos.

Section 5: BT 357D Operation and Specifications.



**DIGI-BELT™ XF 3000 Kit Contents:**

- a. 1-BT-357D: Digital Belt Tension Tester
- b. 1-BT-DSS-150: Deflection Span Scale
- c. 1-BT-ORS-25: Span Scale O-Ring
- d. 2-BT-357: B.A.T. Laser Magnetic Angle Brackets
- e. 2-BT-P24: Steel Magnet Adapter Plates
- f. 2-BT-357: B.A.T. Laser Magnetic Adapters
- g. 1-BT-WB1: 2" Wide Belt Adapter
- h. 1-BT-WB2: 3" Wide Belt Adapter
- i. 1-BT-WB3: 4" Wide Belt Adapter
- j. 1-BT-TM-6: 6 Foot Tape Measure
- k. 1-BT-WC1: USB Charger
- l. 1-BT-CA1: Charger Cable
- m. 1-BT-COC1: Certificate of Calibration
- n. 1-BT-IRC: Impact Resistant Carry Case
- o. 1-BT-IS1: Instruction Sheet



## Section 1

# Digi-Belt™ Basic Single & Multi Belt Tensioning Procedure

1. Look up the recommended measurements and tension values from the belt manufacture and or the machine provider
2. Measure belt span. (See Drawing 1)
3. Position O-ring on the tester scale at this measured length. The scale is 10" per increment. 150" Maximum Span. (Picture 2)
4. The BT 357D Tension Tester is already configured to test and measure belts. To begin simply press the power on/off button.
5. Zero the BT-357D by pressing the ZERO button
6. Place the tip of the Deflection Span Scale on one belt, at the center of the span.
7. Loosen the brass lock nut, then adjust the position of the Deflection Span Scale up or down on the adjustment rod until the ZERO line (see picture 2) is even with the adjacent belt or even with the lasers. (B.A.T. Belt Alignment Tool Method as described in section 2)
8. IF needed again Zero the BT-357D by pressing the ZERO button
9. Apply a sufficient force to BT-357D to deflect the belt such that the O-ring is in-line with the other belts. Maximum force of Model 3000-110 is 110lbs.
10. For increased accuracy or if this is a single-belt drive, use the angle brackets and the B.A.T. Belt Alignment Tool Method as described in section 2.
11. Read the deflection force on the BT-357D display
12. Compare this force with the value given on the chart or table supplied by your belt manufacture.
13. Zero the reading in the BT-357D and remeasure to verify results.
14. If the force is below the recommended value, increase the drive center distance to provide greater belt tension.
15. Reduce the center distance if there is too much force.

Diagram 1: Belt Span Measurement




Diagram 2: Position O-Ring on Deflection Span Scale





Diagram 3: Force Measurement



Section 2  
Digi-Belt™ XF B.A.T. Laser

## Single & Multi Belt Tensioning Procedure

1. This cross-firing laser method is the easiest and most accurate way to measure belt tension.
  2. Look up the recommended measurements and tension values from the belt manufacture and or the machine provider
  3. Measure belt span. (See Diagram 1)
  4. Position O-ring on the tester scale at this measured length. The scale is 10" per increment. 150" Maximum Span. (Diagram 2)
  5. Set Up and Measurement for the Angle Brackets & Laser Bats
    1. Mount Mag brackets to pullies as shown. (Diagram 3)
    2. Mount the steel adapter plates to the Mag brackets as shown. (Diagram 3 &4)
    3. Mount 2 BATS flat on the Mag bracket adapter plates as shown. (Diagram 3 & 4)
    4. Adjust the BATs so the green lasers are on the opposing BAT center white Glowline® targets.
    5. Press the power on off button on the BT-357D.
    6. Zero the BT-357D by pressing the ZERO button
- Diagram 3: Laser B.A.T. and MAG Bracket Set Up.







Diagram 4: B.A.T. Laser Span Deflection Method



7. Place the tip of the Span Deflection Scale on the belt, at the center of the span.
8. Loosen the brass lock nut, then adjust the position of the Deflection Span Scale up or down on the adjustment rod until the lasers are on the ZERO line (see picture 2 above)
9. IF needed again Zero the BT-357D by pressing the ZERO button. (See Picture 5)
10. Apply a sufficient force to BT-357D to deflect the belt such that the O-ring is in-line with the lasers. Maximum force is 110lbs.
11. Read the deflection force on the BT-357D display
12. Compare this force with the value given on the chart or table supplied by your belt manufacture.
13. Zero the reading in the BT-357D and remeasure to verify results.
14. If the force is below the recommended value, increase the drive center distance to provide greater belt tension.
15. Reduce the center distance if there is too much force.


---

## Section 3

### Digi-Belt™ XF B.A.T. Laser

# Wide and Banded Belt Tensioning Procedure

1. Procedure for using the wide belt adapters for wide belts, banded belts, toothed belts, timing belts etc.
2. Select the Wide Belt Adapter bar the best suits the belt being tested.
3. The brass tip of the Deflection Span Scale must be in contact with the bottom of the wide belt adapter.
4. The measurement procedure is the same described in Section 2.



5.

## Section 4 Reference Photos

Picture 4: Deflection Span Scale details

Picture 5: BT-357D Details







[www.beltalignmenttool.com](http://www.beltalignmenttool.com)

800-997-4467

[sales@beltalignmenttool.com](mailto:sales@beltalignmenttool.com)

---

## Section 5: BT 357D Operation and Specifications


[www.beltalignmenttool.com](http://www.beltalignmenttool.com)

800-997-4467

[sales@beltalignmenttool.com](mailto:sales@beltalignmenttool.com)

# DIGI-BELT BT-357D Digital Belt Tension Tester

## Operation Manual - Specifications



**Warning**

Operators should wear protection such as a mask and gloves in case pieces or components break away from the unit under test.

Whether the unit is ON or OFF, DO NOT exceed the capacity of the gauge. NEVER exceed 150% of the rated capacity, or the load cell will be damaged. At 110% of the rated capacity, the display will flash a warning.

Measure in line tension and compression forces only. DO NOT attempt to measure forces at an angle to the measuring shaft – damage to load cell and/or shaft may result.

Do not attempt to repair or alter this instrument. Warranty will be voided and damage to the unit may result.

Use and store within the stated temperature and humidity ranges, or damage and failure may result.

When using adapter measuring heads, do not use tools. Hand tighten only.

The new BT-357D Series digital force gauges are the choice for simple, cost-effective tension and compression testing. Combining one of the most compact housings, yet maintaining a large back-lit LCD, these units were designed to fit perfectly in the hand for ease of use. The multi-language BT-357's provide menu programming for intuitive set-up of the instrument to your desired requirements. Three modes of operation are selectable: Track mode displays live readings, Peak mode records the maximum reading sensed during the test, and Pre-set mode which activates user defined high and low limit set points. The programmable limits provide a quick visual and audible indication if a test passes or fails. In addition, a comparator output enables integration of the instrument into your quality system for repetitive testing such as on production lines.

The display graphics facilitate user comprehension and operation. An analog bar graph provides perspective of current reading in comparison to the full scale range. Pass/Fail icons provide an instant response of the testing outcome while a storage symbol acknowledges when a reading is logged. A menu-selectable display orientation streamlines switching from push to pull testing for portable or test stand applications.



### SPECIFICATIONS

**Accuracy:**  $\pm 0.3\%$  F.S.

**Selectable Units:** N, kgf, ozf, and lbf. (Depending on Range)

**Overload Capacity:** 150% of F.S. (LCD flashes beyond 110% of F.S.)

**Measurement Method:** Peak, Track, Preset

**Data Sampling Rate:** 1000 Hz

**Display:** 160\*128 dot matrix LCD with Backlight

**Display Update Rate:** 10 times/second

**Resolution:** (See chart)

**Memory:** 500 data

**Set Point:** Programmable high and low limits in Preset Mode

**Battery Indicator:** Display flashes battery icon when battery is low

**Power:** 3.6VDC 800mAH Ni-MH rechargeable batteries

**Battery Life:** Approximately 16 hours continuous use per full charge

**Charger / Adaptor:** Universal USB/BM charger, Input: 110 ~ 240VAC

**Temperature Effects:**  $< 0.054\%$  per  $^{\circ}\text{F}$  ( $0.03\%$  FS per  $^{\circ}\text{C}$ )

**Outputs:** USB, RS-232; High & Low Limit NPN's

**Operating Temperature:** 14 to 104 $^{\circ}\text{F}$  (-10 to 40 $^{\circ}\text{C}$ )

**Storage Relative Humidity:** 20 to 80%

**Housing:** Aluminum

**Storage Temperature:** -4 to 122 $^{\circ}\text{F}$  (-20 to 50 $^{\circ}\text{C}$ )

**Oper. Relative Humidity:** 5 to 95%

**Dimensions:** 5.5 x 2.8 x 1.4" (140 x 71 x 35.5 mm)


**Product Weight:** 0.9 lb (0.4 kg)

**Package Weight:** 2.25 lb (1 kg)






**Warranty:** 1 year

**Certification:** CE

**Included Accessories:** AC Adaptor/Charger, USB cable, calibration cert., 6 attachments: hook, flat tip, conical tip, chisel tip, notched tip, extension shaft.




### LCD Screen


1. Battery icon: Battery level or charging status. Flashes when gauge needs to be recharged.
2. OK/OV Indicator:  Measured value between low limit and upper limit;  Value over upper limit  
 Value between lower limit and 75% of lower limit
3. Force icon: Indicates force direction.  Tension  
 Compression
4. Test mode icon: Three measurement modes: Track, Peak and Preset
5. Current measured value
6. Analog bar: Indicates current position within full scale. When the bar enters the area enclosed by the dotted line, it means full scale capacity is exceeded and overload.
7. Storage icon: Indicates data is being saved.
8. System time
9. Units Indicator: Selected engineering unit.
10. Data Transmission icon


# 1. OPERATION


## 1.1 Key Functions


All keys are capacitive touch.

 ON/OFF: Push for 1 second to power On or Off

 During Measurement: Store data.  
In Menus: Back or quit.

 During Measurement: Enter the menus.  
In Menus: Select or Enter

 During Measurement: Track mode, tares weight of attachment. In Peak modes, resets the peak value.  
In Menus: Moves selection up or increases the value.

 During Measurement: Changes the measure mode from Track, Peak or Preset  
In Menus: Moves selection down or decreases the value.

## 1.2 Modes

**Track:** Real time, live measuring mode.

**Peak:** Peak readings will not change until a higher value is measured.

**Preset:** User-defined set points GO/NG testing with available and visual indicators.

## 1.3 Menu Structure

The FG-3000 Series Force Gauge has multi-level menu interface (Table 1-3) that enables simple navigation and programming.

MENUS	SUBMENUS	SELECTIONS
Measurement	Unit	N, kgf, lb, ozf
	Test Mode	Track, Peak, Preset
	Browse	
	Print	Selected, All
	Delete All	Yes, No
	Display	Obverse, Reverse
System	Auto Power	On, Off
	Backlight	On, Off
	Key Sound	On, Off
	Date/Time	
	Calibration	Yes, No
	Default	Yes, No
	Language	English, Chinese, Japanese, German
Information	Model, SN, Version	

Table 1-3

To mount the measuring adapter, install the adapter on the gauge's measurement shaft. Tighten by hand. Do not tighten with any tool.

**NOTE: Do not use tools to tighten the adapter to the gauge shaft. Damage to the force gauge will occur.**

## 3. SETUP

### 3.1 Measurement

The Measurement menu contains the Unit of measure and Measurement Mode sub-menus, as shown in Fig. 3-1.




Fig. 3-1

### 3.2 Select Units

The measuring units can be selected under this menu. Different range models may have different unit selection capabilities. Touch "ZERO" or "MODE" keys to shift to the next selection. Press "LOG" to cancel or touch "MENU" to confirm and exit. (Fig. 3-2)




Fig. 3-2

### 3.3 Select Test Mode

The FG-3000 has 3 types of Test Modes.

**Track:** The real time measuring mode. Under this mode, press the ZERO key to tare any initial reading being displayed.

**Peak:** In Peak mode, the maximum force will be recorded and displayed. Press the ZERO key to reset the peak value.

**Preset:** Enables the setting of an upper and lower limit to compare to the measured force value. A simple GO/NG analysis is displayed on screen via icon indicators for quick pass/fail testing. To guarantee an accurate test, make sure to zero the display and tare any small force being displayed before beginning the test.

There are two means to select your appropriate Test Mode. At the home screen simply press the MODE key to scroll through the three measuring modes.

You can also select the mode under the Measurement menu in the Test Mode sub-menu. See Fig. 3-3(a)

If the Preset is selected, a new screen will pop up where you can set the Upper and Lower limits. See Fig 3-3(b)

Press ZERO to adjust the number and press MODE to move to the next digit.




Fig. 3-3(a)




Fig. 3-3(b)

Note:

- 1) The upper limit can not exceed 110% capacity of the force gauge.
- 2) The lower limit must not be less than 10% of capacity.
- 3) The upper limit must exceed the lower limit

### 4. SAVING THE MEASURED VALUE

Measured results can be stored in the force gauge's memory. You can review or print the stored data at a later time.

At the home screen press the LOG key to store a value. The storage icon will be displayed.

The data stored is the current displayed force value in Track and Preset modes. In Peak mode it is the peak value shown on the display.

### 4.1 Memory




Fig. 4-1

Memory menu contains three submenus: Browse, Print, Delete all, as shown in Fig. 4-1.

You can browse stored data or print all the data via the FG-PRINT mini-printer (sold separately). You may also delete all the records in the Delete all sub-menu.

### 4.2 Browse

In the Browse sub-menu. The data in memory can be reviewed in the order saved which is oldest to newest. See Fig. 4-2(a)

Press ZERO/UP or MODE/DOWN to scroll.

Press MENU. A small window will pop out. Here you can select Delete or Print. See Fig. 4-2(b).

If you select Delete, a confirm window will appear asking you to confirm. Press MENU to confirm or LOG to exit.

No.	Force	Dir
013	0.738 N	↕
014	1.958 N	↕
015	2.136 kgf	↕
016	0.848 lbf	↕
017	1.799 kgf	↕
018	29.38 ozf	↕

Fig. 4-2(a)

No.	Force	Dir
013	0.738 N	↕
014	1.958 N	↕
015	2.136 kgf	↕
016	0.848 lbf	↕
017	1.799 kgf	↕
018	29.38 ozf	↕

Fig. 4-2(b)

### 4.3 Print

You can print the data in memory. Enter Print. (Fig. 4-3) Choose Selected or All.




Fig. 4-3

If Selected is chosen, the total Range of available data points will be indicated. Adjust the value points to be printed to the right of Select. Fig. 4-3(a)

If All is selected, a confirm window will appear asking you to confirm. See Fig. 4-3(b).

Fig. 4-3(a)




Fig. 4-3(b)




Fig. 5-1(a)



Fig. 5-1(b)

**4.4 Delete All**

All data points can be cleared from memory under the Delete all sub-menu (Fig. 4-4). A confirm window will appear asking you to confirm. See Browse for details on deleting individual points one at a time.




Fig. 4-4

**5. SYSTEM**

Under the System menu, the Display, Auto Power, Backlight, Key Sound, Date/Time, Calibration and Default sub menus are present.




Fig. 5

**5.1 Display**

There are two display modes: Obverse and Reverse (Fig. 5-1(a)). Obverse will allow the display to be up-right with the keypad underneath, while Reverse will allow the display to be up-right with the keypad above. Fig. 5-1(b)

**5.2 Auto Power**

The FG-3000 has an automatic power off function. With Auto Power on, if there is no operation performed within five minutes it will power off automatically. (Fig. 5-2)



Fig. 5-2

**5.3 Backlight**

The backlight can be set to turn on or off. See Fig.5-3. Choosing the backlight to be off will reduce the consumption of the battery.



Fig. 5-3

**5.4 Key Sound**

The Key Sound can be turned on or off as shown in Fig. 5-4.



Fig. 5-4

**5.5 Date/time**

Date and time can be adjusted under this menu. Press ZERO to adjust the number and press MODE to move to the next digit. Fig. 5-5



Fig. 5-5



## 5.6 Calibration

Because of the sensor material performance or the influence of external factors, there may be errors of a certain level after a period of usage.

It is recommended to send the force gauge to a specialized testing organization for calibration.

If you have standard force weights or other standard load and a test stand, you may utilize this function and procedure to calibrate the sensor.




Fig. 5-6(a)

- 1) Mount the force gauge.
- 2) Use the tare by use of the ZERO key.
- 3) Enter Calibration sub-menu as in Fig. 5-6(a).

The calibration interface is shown in Fig. 5-6(b).




Fig. 5-6(b)

- 4) Load a standard force. Now the value in the standard input area is just equal to the current measured value. Wait a moment for the force to stabilize.




Fig. 5-6(c)

- 5) Press ZERO and MODE to input the standard force value.
- 6) Press MENU to enter the next calibration. Press LOG to interrupt the calibration.

When 3 calibration points have been finished, a confirm window will pop up asking to “Save and Exit”(YES)/(NO). Fig. 5-6(d)

Press ZERO or MODE to select, then press MENU.

If “YES” is selected, Calibration is complete. Fig. 5-6(e)




Fig. 5-6(d)




Fig. 5-6(e)

## 5.7 Default

With this function, the force gauge can be restored back to the original factory settings. Only perform this function when all other troubleshooting tactics have first been attempted.

## 6. LANGUAGE

The force gauge can display in various languages. Set the language as desired. See Fig. 6.




Fig. 6

## 7. INFO

Information about the force gauge such as model, version and serial number is provided in this menu. Fig. 7




Fig. 7

## 8. COMMUNICATION PORT

The force gauge has a USB for recharging and communicating with a PC, plus an 8 pin connection for printer connection and set point output. Fig. 8-1




Fig 4-1


Pin#	Description	
1	RS232	
2		Tx
3		Rx
4	Setpoint Output B	
5		Gnd
6	Setpoint Output C (Common)	
7	Setpoint Output A	
8		

Fig. 8-1

The RS232 serial port is used to connect the mini-printer to print the memory data stored on the gauge.

**RS-232 Specifications:**

- Hardware Flow Control: None
- Data word length: 8 bits
- Stop bit: 1bit
- Parity: None
- Baud rate: 38400



**Fig. 8-2**

**8.2 Setpoint Output**

Two NPN open collector setpoint outputs are available.

The internal circuit of the setpoint output is shown as Fig 8-2.

Pin7 with Pin6 will be connected when an overload alarm occurs.

In Preset Mode, Pin7 to Pin6 is connected when the measured value exceeds the upper limit. Pin4 to Pin6 is connected when the measured value passes below the lower limit.

**CAUTION: Maximum permissible voltage: pin 7 to 6, pin 4 to 6 must be lower than 35V ; pin 6 to 7, pin 6 to 4 must be lower than 6V .**


Remember to remove the load after measurement. Applying a load for a long time period may affect the accuracy of the instrument.

**9. MAINTENANCE**

**9.1 Maintenance**

After use, please keep the instrument body clean. Do not let oil and other substances persist on the body and screen so as not to damage the instrument. Remember to remove the load after measurement. Applying a load for a long time period may affect the accuracy of the instrument.

**9.2 Charging**

When the battery is low, the icon “  ” will be displayed. The batteries should be charged immediately.

Connect the gauge and the charger with the USB cable. Then connect the charger with AC socket to start charging.

**10. TROUBLESHOOTING**

According to the following table, review possible solutions for problems encountered. Do not disassemble the gauge by yourself or attempt to repair. If you cannot resolve the fault yourself, please contact Nidec-Shimpo.

Failure	Possible Causes	Potential Solutions
Unit will not turn on	Low battery	Recharge and then re-boot. If after 3-4 hours of charging time the battery does not properly hold a charge, the battery needs to be replaced. Contact Nidec-Shimpo.
No key sound	Key sound is turned off	Turn on the key sound in menu
No backlight	Backlight is turned off	Turn on the backlight in menu
Error is too large	The gauge is not calibrated	Calibration of force gauge is required. After calibration if the error remains outside of the specifications, sensor may be damaged. Contact Nidec-Shimpo to get RMA for return.

## 11. CAPACITY AND RESOLUTION

Model						
		<b>N</b>	<b>kgf</b>	<b>ozf</b>	<b>lbf</b>	
<b>3000-110</b>	Capacity	500.0	50.00	1800	110.0	-
	Resolution	0.1	0.01	1	0.1	-
<b>3000-220</b>	Capacity	1000	100.0	3500	220.0	-
	Resolution	1	0.1	1	0.1	-

