



KANOMAX

ANEMOMASTER

MODEL 6113

Operation Manual



Please use this instrument properly by reading this user's manual and following the warning instructions. **Keep this manual in a place where it can be accessed quickly.**

KANOMAX JAPAN INC.

2-1 Shimizu Suita Osaka Zip:565-0805

Phone: +81(6)6877-0183

Fax : +81(6)6879-2080



01001

03. 01

Thank you for purchasing Kanomax product.
Please use this instrument properly by reading
the **operation** manual and following the
warning instructions.

List of Components

■ Standard

Items	MODEL	Qty	Functions
Main Body	6113	1	—
Probe	6113-01	1	Air velocity, air temperature sensor
Extension Rod	6112-03	1	To measure high places
Shoulder Strap		1	—
Operation Manual	—	1	—
AA Manganese Batteries	—	6	—

■ Options

Items	MODEL	Functions
Spare Probe	6113-01	For spare
Pressure Sensor	6113-07	For measurements of differential pressure
Analog Output	6113-08	Analog output terminal
AC Adaptor	6113-02	Power supply
RS232C Cable	6000-02	For the connection of Main Body and PC
Portable Anemometer Data Logging Software	S600-00	Data collection (application) software

Safety Precautions

PLEASE READ CAREFULLY BEFORE PROCEEDING


These precautions explain how to use the device correctly and safely, thereby preventing injury to yourself or to others. This section has been sub-divided into a **WARNING** section and a **CAUTION** section, according to the likelihood and nature of any potential injuries or damage inflicted. They relate to your personal safety, and also help you minimize the risk of damaging the device. Please read these sections carefully before proceeding.



WARNING


Always follow the basic precautions listed below to avoid the possibility of serious injury or even death from electrical shock, short-circuiting, damages, fire or other hazards. These precautions include, but are not limited to, the following:

- Do not install the probe in an area where flammable gas is present. Otherwise, there is an increased risk of fire or even explosion.




- Do not open the device or attempt to disassemble or modify it. Otherwise, there is an increased risk of electrical shock or fire. The device contains no user-serviceable parts. If it appears to be malfunctioning, have it inspected by qualified service personnel.

- Do not insert fingers or foreign objects into the device. Otherwise, there is an increased risk of personal injury (such as burning yourself), electrical shock, and damage to the device or fire. Please take particular care if small children are present.



- Do not expose the device to rain, use it near water or in damp or wet conditions or place containers on it that contain liquids which might spill into any openings. Otherwise, there is an increased risk of electrical shock, fire or personal injury.



- Follow the **Operation** Manual carefully. Otherwise, there is an increased risk of personal injury, electrical shock, fire or damage to the unit. Follow the correct procedure when setting up the device.

- If unusual smells, sounds or smoke emanate from the device or if liquids enter the device, switch the device off immediately and take out the batteries and/or unplug it from the power outlet.

Otherwise, there is an increased risk of electrical shock, fire or damage to the device. Return the device immediately to nearest Kanomax Office or to the Service Center in Osaka, Japan.



CAUTION

Always follow the basic precautions listed below to avoid the possibility of physical injury to yourself or others, or damage to the instrument or other property. These precautions include, but are not limited to, the following:

- Always unplug the anemometer from the electrical outlet if it will not be used for a prolonged period or if there is a risk of lightning. Otherwise, there is an increased risk of electrical shock, short-circuiting or fire.
- Always take out the batteries before storing. Otherwise, there is an increased risk of leakage.
- Do not leave exhausted batteries in the unit. Otherwise, there is an increased risk of leakage.
- Do not expose the device to excessive heat or vibrations or extreme cold or heat (such as in direct sunlight or near heater). Otherwise, the main body may become disfigured or the internal components may be damaged and no longer function properly.
- When cleaning the device, never use benzene, paint thinners, detergents or chemical-impregnated wiping cloths. Also, do not place vinyl, plastic or rubber objects on the device. Otherwise, the device may be damaged or its main body may become discolored or disfigured. Use a soft, dry cloth to wipe the device.
- Do not impact the device by resting your weight on or placing heavy objects on the device; do not use excessive force on the buttons, switches or connectors. Otherwise, there is an increased risk of damage to the device or personal injury.
- Have the device serviced regularly. Otherwise, there is an increased risk of not maintaining the accuracy. For information about servicing charges, contact your nearest Kanomax Office or Kanomax Service Center. The device should be serviced about once a year.
- The sensor is very sensitive to electrostatic. Please handle with care.




Table of Contents



1. ANEMOMASTER Anatomy.....	1
1. 1 Main Body.....	1
1. 2 Operation Panel.....	3
1. 3 Probe / Probe Cable.....	4
1. 4 Telescopic Articulating Extension Rod (Option).....	5
2. Getting Started.....	6
2. 1 Installing Batteries.....	6
2. 2 Confirming the Probe Number	7
2. 3 Connecting Probe.....	7
2. 4 Powering ANEMOMASTER ON / OFF.....	8
2. 5 How to Make Measurements.....	9
2. 5. 1 Measuring Air Velocity.....	9
2. 5. 2 Measuring Air Temperature	9
2. 5. 3 Measuring Pressure	9
3. Normal Measurement *** Measurement Mode ***	11
3. 1 Selecting the Measuring Parameters	11
3. 2 Display Hold.....	12
3. 3 Changing the Display Range on the Bar Graph	12
3. 4 To Change Time Constant	13
4. Storing and Deleting Stored Measurement Data	14
4. 1 To Store Measurement Data.....	14
4. 2 To Delete Data.....	15
4. 2. 1 Complete Deletion: Deleting All Stored Measurement Data.....	15
4. 2. 2 Simple Deletion: Deleting a Single Measurement Data Last Stored.....	15
4. 2. 3 Selective Deletion: Deleting a Single Specific Stored Data.....	16
5. Measuring Mean, Maximum & Minimum *** Calculation Mode ***.....	17
6. Data Output.....	19
6. 1 Printing Out.....	19
6. 1. 1 Set up the Printer Paper (Roll Paper).....	19
6. 1. 2 Spot Value Print Out	21
6. 1. 3 Calculation Results Print Out.....	21
6. 1. 4 Stored Data Print Out.....	22
6. 1. 5 Function Set Information Print Out (Also for Test Print).....	22
6. 2 Digital Output.....	23
6. 2. 1 Preparation.....	23
6. 3 To Access From Your PC.....	24
6. 3. 1 Transmission of On-Time Data (Every-second Basis)	24
6. 3. 2 Transmission of Data Stored in Memory.....	25
6. 4 Setting the Output for Single Parameter Measurement Data	25
6. 4. 1 How to Print-out using the Setting for Single Parameter Data Output....	25

6. 4. 2 Digital Output using the Settings for Single Parameter Output.....	25
6. 5 Analog Output (Optional)	26
7. Other Settings	27
7. 1 Date	27
7. 2 Units and Baud Rate	28
7. 2. 1 Set-up.....	28
7. 2. 2 Dip Switch Set-up Chart.....	29
8. Cleaning the Probe.....	30
9. Specification	31
10. Principle of Measurement	32
11. About Compensation.....	34
11. 1 Influence of Measuring Temperature	34
11. 2 Influence of Pressure at Measuring Point	34
11. 3 Measuring Gas Components.....	34
12. Probe Directivity (Air Velocity)	35
12. 1 Horizontal.....	35
12. 2 Vertical.....	35
13. Trouble Shooting	36
13. 1 Batteries	36
13. 2 Initial Operations	36
13. 3 During Operations.....	36
13. 4 Printer Output.....	37
13. 5 Digital Output	37
13. 6 Analog Output	37
14. Warranty and After Service.....	38

1. ANEMOMASTER Anatomy


1. 1 Main Body

Unit: mm




***) Caution**
Whenever you close the Lid, be sure to disconnect the Probe from the Probe Connection Terminal, and store on the Probe Rest. If you close the Lid while the Probe is still set on the Probe Rest, you may risk damage such as breaking the probe cable.

<Diagram of the Bottom>



<Diagram of the Left Side>



1. 2 Operation Panel

The key tone is set “ON” at the time of inspection. You may turn it off by going through the manual. Please refer to page xxxx

Hold/Set Key
Press this key to hold/reset the displayed value on the measurement mode. You can also use this key to select and choose the item on the date/time setting mode and function setting mode,

Samp. Key
The displayed value will be stored when you press briefly. (All measurement parameters will be stored.) The maximum number of memory is 100. If you press for an extended length of time, the average value for the duration of that time will be stored. Sampling is done every second up to a maximum of 60 seconds. (Measurement values beyond 60 seconds will not be acknowledged.)

Mode Key
Press this key to change displayed parameter on the measurement mode and the calculation mode.

Calc. Key
Use this key to switch to the calculation mode and go through the stored data.

Power Switch
Power Source ON/OFF
I : ON
O : OFF

Clear Key

- When you continue to press more than a second, it deletes the last piece of data stored on the memory.
- When you are in the function setting mode: Use this key to finish setting.
- During printing: Printing will be forced to stop. (Cannot stop printing for data that has already been transmitted to the printer.)

SP. Zero Key (Option)
When you continue to press for more than 2 seconds when the pressure is displayed during the measurement mode, it will adjust to zero.

Feed Key
Each time you press this key, the printer paper will be forwarded by 1 line.

▲Key
When you press this key during the measurement mode, you can select the time constant among 1, 5, or 10 seconds.


▼Key
When you press this key during the measurement mode, you can select the range of the bar graph among 1, 5, 10, 25, or 50m/s.
※In other modes, keys ▲ or ▼ can be used to select a Parameter or to move numbers up or down.

Print Key
When you press this during the measurement mode, the displayed value will be printed. (All measurement parameters will be printed.) As for the calculation mode, the calculation results (average, max, min) of the data stored in the memory will be printed.

Measurement Mode Flowchart:
 (Option) Air Velocity, Pressure, Air Temperature
 Measurement Mode
 Calculation Mode: Stored Data Display, Mean Value, Minimum Value, Maximum Value


1. 3 Probe / Probe Cable

Unit : mm



1. 4 Telescopic Articulating Extension Rod (Option)


Unit : mm



2. Getting Started


2.1 Installing Batteries

<Diagram of the Bottom of the Main Body>



- ① Remove the lid by pressing lightly on the 2 areas (see arrows) and pulling towards you.

- ② Insert batteries in the order as shown.
(※Be sure to observe the polarity.) This instrument requires six AA batteries. Use only AA size Manganese (R6), alkaline (LR6) or Ni-Cd batteries. Do not mix battery types, otherwise it may lead to leakage or damage to the Main Body.
※Batteries cannot be recharged by the optional AC Adapter.



- ③ Put the cover back on in the opposite order it was removed.

Acceptable Battery Types

Manganese (R6) AA Batteries
Alkaline (LR6) AA Batteries
Ni-Cd AA Batteries


2. 2 Confirming the Probe Number

Confirm that the number on the Probe and the number on the Main Body (indicated on the ROM cassette inserted in the bottom of the Main Body) matches.

※ You will need to confirm the Probe Number if you purchase in multiples or if you own a spare Probe.

(The number on the Main Body is also displayed when you turn on the power. See Chapter 2.4, “Powering ANEMOMASTER On/Off” for details.)

The characteristics data pertaining to each probe is stored in the ROM cassette inserted underneath the Main Body. Each Probe has different characteristics so you must confirm that the numbers match in order to measure properly.



Bottom of the Main Body

Probe


2. 3 Connecting Probe

Per the illustration below, connect the Probe by paying attention to the direction of the connector (Probe Cable sticks out from the “up” side) and attach to the Probe Terminal located on the Main Body.

※ Make sure that the power is OFF when connecting or disconnecting the Probe Cable.


※ Do not force the connector into the socket without confirming the correct direction, and do not rotate the connector after attaching as these will cause damage.

※ When you close the Lid, be sure to remove the Probe Connector otherwise it may damage the cable.




2. 4 Powering ANEMOMASTER ON / OFF

When you connect the Probe onto the Main Body and turn on the switch, the software version followed by the Probe Number will be displayed before you see the Normal Mode (Normal Measurement display).




When the ROM Cassette is not properly inserted, you will get an alarm and an error message as shown above. (Refer to Chapter 13 “Trouble Shooting” for Error Codes.) Turn off the instrument and check if the ROM Cassette is properly inserted.




Display Icons (Normal Mode: Refer to Chapter 3 “Normal Measurement” for details.)
 Instructed Value or Fixed Value, Bar Graph, Bar Graph Range, Unit, Battery Level Indicator

◆ Battery Level Indicator




Battery level is indicated upper right. Battery consumption depends on the air velocity being measured. When this indicator starts to flash, it is time to change batteries. Caution: Measurement may suddenly stop depending on the wind velocity if the battery is low.

The indicator changes as you see it below.




— LOCK —
 When “E - - 0” is displayed, every function of the instrument will be locked. The measurement will stop and data will NOT be saved. To unlock, turn off the power and replace batteries.



2. 5 How to Make Measurements

2. 5. 1 Measuring Air Velocity

- ◆ Probe has its own directivity characteristics. Make sure that the wind direction mark is facing the wind (For more details on directivity characteristics, refer to Chapter 12 “Probe Directivity (Air Velocity)”. If you are not sure of wind direction, slowly rotate Probe and measure at the point where you get the highest air velocity reading.
- ◆ To make the temperature compensation more effective, make sure that the **Air velocity sensor** and **Temperature compensation sensor** of Probe are evenly exposed to the airflow.
- ◆ To take a measurement in temperature changing situation, leave Probe for more than 20 seconds until the display becomes stable.





2. 5. 2 Measuring Air Temperature

- ◆ The faster the wind, the shorter the response time for temperature measurement. **(The response time is approximately 30 seconds at the airflow of 1m/s).** Take the measurement after the reading is stabilized on the display.
- ◆ With no airflow present, the instrument's air temperature reading may become higher than it actually is due to the heat generated by the air velocity sensor. It is recommended to take a measurement with at least 0.1m/s of wind present for accurate reading.

2. 5. 3 Measuring Pressure

- ◆ Do not apply more than 75kPa of pressure to the pressure sensor (optional). This may cause serious damage to the sensor.
- ◆ When you make a measurement, make sure that the temperature is somewhere between 5 to 40°C or 41 to 104°F.
- ◆ Before you make a pressure measurement, make sure you execute the zero adjustment. When you make the adjustment, leave the both pressure ports ((+) and (-)) open.

<Zero Adjustment Procedure>

DISPLAY	PROCEDURE
	<p>Press Mode when you are in the Measurement Mode, and select pressure measurement.</p> <p>Each time you press the MODE key, it will show in order air velocity ->air temperature -> pressure.</p>
	<p>When you press SP. Zero for more than 2 seconds, you will hear a beep, and the pressure display will show "0.00".</p>


<Connecting Pressure Tube>

Connect the pressure tube to the (+) or (-) port as you see on the bottom.

Connect/insert the other end of the tube to the measuring hole of the duct. If the pressure that you are going to measure is **positive**, connect the tube to (+) Port. If it is negative, connect the tube to (-) Port.

! CAUTION !

In order to make a precise measurement, the tube must have no holes and must be connected securely. Also, the tube must not be bent at any point.






3. Normal Measurement *** Measurement Mode ***

When you first turn on the instrument this will be the first mode that you will be in (Air Velocity Measurement Mode). You cannot save any data in this mode. The display will be updated every 1 second.







<Air Velocity Measurement Display>

3. 1 Selecting the Measuring Parameters







DISPLAY	PROCEDURE
<p>①</p> 	<p><NORMAL MODE></p> <p>Press <input type="button" value="Mode"/> in the Normal Measurement display. (See example on the left.)</p> <p>Press <input type="button" value="Mode"/>, and display mode moves in order, as shown below.</p> <p>② Air Temperature → ③ Pressure (Optional) → ① Air Velocity(=Normal)</p>
<p>②</p> 	<p><AIR TEMPERATURE MEASUREMENT MODE></p> <p>※In the Air Temperature Measurement Mode, there will be no bar graphs displayed under the measured value.</p>
<p>③</p> 	<p><PRESSURE MEASUREMENT MODE></p> <p>※In the Pressure Measurement Mode, there will be no bar graphs displayed under the measured value.</p> <p>※This mode is available only to instrument with optional pressure sensor.</p>

3. 2 Display Hold

DISPLAY	PROCEDURE
	<p>While measuring, press .</p> <p>(The same procedure applies when you are in Air Temperature Measurement Mode, and Pressure Measurement Mode.)</p>
	<p>“HOLD” indicator appears on the display to indicate that the reading shown is held.</p> <p>Press  once again to release.</p>




3. 3 Changing the Display Range on the Bar Graph

Bar graphs are displayed only for air velocity measurement.

DISPLAY	PROCEDURE
	<p>Press  key when you are in the Normal Measurement Mode (Air Velocity Measurement Mode)</p> <p>※The initial range is 0 – 10m/s and each scale equals 2m/s.</p> 
	<p>You will see the value on the right end of the bar graph change. The range is now between 0 – 25m/s.</p> <p>1 scale now equals 5m/s.</p>
	<p>Each time you press , the value on the right end of the bar graph will change. The range will change in the following order:</p> <p>0~10m/s(1 scale:2m/s、1 bar:0.4m/s)<Initial Default Setting> →0~25m/s(1 scale:5m/s、1 bar:1m/s) →0~50m/s(1 scale:10m/s、1 bar:2m/s) →0~1m/s(1 scale:0.2m/s、1 bar:0.04m/s) →0~5m/s(1 scale:1m/s、1 bar:0.2m/s) →0~10m/s</p> <p>※Once you turn off the power, the setting will revert to the default range(0~10m/s).</p>

3. 4 To Change Time Constant




You can change the Time Constant only when measuring air velocity. The Time Constant for air temperature and pressure (option) is fixed at 1 second.

DISPLAY	PROCEDURE
 <p style="text-align: center; margin-top: 10px;">Time Constant</p>	<p>When you hit  when you are in the Normal Measurement Mode (Air Velocity Measurement Mode) you will see a display (see left) which briefly flickers the set Time Constant.</p> <p>※Default setting is 1 second.</p> <p>In the Normal Measurement Mode, you can change the Time Constant by pressing .</p> <p>You can select Time Constant from 1sec, 5sec and 10sec.</p> <p style="margin-left: 20px;">00:01 : Display moving average of 1sec. 00:05 : Display moving average of 5sec. 00:10 : Display moving average of 10sec.</p> <p>※Once you turn the switch off, the Time Constant will revert to the default setting of 1 second.</p>

*** What is Time Constant? ***

Time Constant determines the time span of the moving average. When you set the Time Constant to a larger value, the indicating value will become stable. When you select the smaller (=shorter) Time Constant value, the reading will become more responsive and sensitive to the change in air velocity.



This function will not be in effect in Calculation Mode and Air Flow Mode.

MODE	How to Take In Measured Data	EXPLANATION
00:01 (1 sec.)	 <p style="text-align: center;">Average of 1 sec</p>	Take the data 10 times in a second and indicate its average as an instantaneous value at every 1 second.
00:05 (5 sec.)	 <p style="text-align: center;">Average of 5 sec</p>	Indicate the average value of 5 seconds at every 1 second. Data shifts by 1 second.
00:10 (10 sec.)	 <p style="text-align: center;">Average of 10sec</p>	Indicate the average value of 10 seconds at every 1 second. Data shifts by 1 second.


4. Storing and Deleting Stored Measurement Data

4.1 To Store Measurement Data

① Storing Spot Data

DISPLAY	PROCEDURE
	<p>Hit the Samp. key when you are in the Normal Measurement Mode. You can do the same on the displays for the Air Velocity, Air Temperature, and Pressure measurement modes.</p>
 <p>Approx. amount of stored data</p> <p>Data Number</p>	<p>As per the illustration on the left, you will see “Samp”, Data Number, and a bar graph flicker briefly. After this, the data for all measurement parameters (Air Velocity, Air Temperature, Pressure) will be stored as one set. (The bar graph that flickers briefly indicates the approximate accumulated amount of stored data.) The maximum number of data that can be stored is 100.</p>

② Storing the Average Value ... For Consecutive Data Not Exceeding 60 Seconds

DISPLAY	PROCEDURE
	<p>Press Samp. for longer than 1 second when you are in the Normal Measurement Mode. By doing so, the average value for the data spanning the length you continued to hold will be stored as 1 set of data.</p> <p>Sampling is done every second (you will hear a beep) and you will get the average value for consecutive data not exceeding 60 seconds.</p> <p>Also note that while you hold onto Samp., the “Samp”, Data Number, and bar graph will continue to be displayed.</p> <p>(For example, if you pressed 10 seconds, the single average value pertaining to the 10 sampled values will be stored.)</p> <p>※If you held beyond 60 seconds, you will hear an alarm and the measurement will end.</p>

※Once the measurement data is stored, it will not be lost even if the switch is turned off. In addition, data will be preserved even during battery change since the built-in back-up battery will kick in.

However, please be warned that if the built-in back-up battery has worn out over time, it is possible that data may not be stored.

4. 2 To Delete Data

4. 2. 1 Complete Deletion: Deleting All Stored Measurement Data

DISPLAY




PROCEDURE

When you simultaneously press and for more than 4 seconds when you are in the Normal Measurement Mode, you will see the “n-00” display (as on the left), and all stored data will be deleted.

4. 2. 2 Simple Deletion: Deleting a Single Measurement Data Last Stored


DISPLAY



<Measurement Mode Display>

PROCEDURE

Press for more than 1 second when you are in the Normal Measurement Mode. (This can be done for Air Velocity, Air Temperature, Pressure measurement modes.)



The Total Number of
Measurement Data Stored

You will briefly see a display “n-xx” (as on the left) and the latest (newest) stored data will be deleted.

(The number in “xx” indicates the total number of stored data that will remain after the deletion. “n-00” indicates there are no stored measurement data.)

The only data you can delete using this method is the last (newest) data you stored. For example, it is not possible to delete anything in between, such as the 40th data from a total of 75 data.

4. 2. 3 Selective Deletion: Deleting a Single Specific Stored Data


DISPLAY

PROCEDURE




Data Number

< Stored Measurement Data Display >



Total Number of
Stored Measurement Data



Press **Calc.** 4 times when you are in the Normal Measurement Mode and change over to the display of Stored Measurement Data in the **Calculation Mode**.

(For details on Calculation Mode, refer to Chapter 5 “Measuring Mean, Maximum, Minimum”.)


Press **▲** **▼** to find the Data Number you would like to delete.

Press **Clear** for more the 4 seconds. (This can be done for Air Velocity, Air Temperature, Pressure measurement modes.) You will hear a beep along with a display of the total number of stored measurement data. After this, the display will return to show the remaining stored data.

To delete successively, press **▲** **▼** and select the data to delete. Press **Clear** for more than 4 seconds to delete. You can delete only one data a time. The selected page will be deleted and the remaining data will shift up. (See example below.)

Example :

There are data, 1 through 4. If you delete the 3rd data, the 4th data now becomes the 3rd data (likewise, the assigned Data Number changes to 3), and there will now remain data pertaining to pages 1 through 3.







5. Measuring Mean, Maximum & Minimum

*** Calculation Mode ***

Calculation Mode will automatically calculate the maximum, minimum, mean from the stored data.

If there are no stored data, you must first store the measurement data in order to compute. (Refer to Chapter 4 “To Store and Delete Measurement Data” on how to store.)


The calculation is performed on all stored measurement data. (It is not possible to select certain data and perform calculations on them.)

DISPLAY	PROCEDURE
<p>①</p>  <p><Normal Measurement Display></p>	<p>Press Calc. when you are in the Normal measurement Mode (You can do the same for Air Velocity, Air Temperature, Pressure.)</p> <p>Each time you press Calc., there will be displays in the following order:</p> <p>② Mean Value Display (Avg) → ③ Max Value Display(Max) → ④ Minimum Value Display(Min) → ⑤ Stored Measurement Value Data Display → ① Normal Measurement Display</p>
<p>②</p>  <p>Mean Value</p> <p>Total Number of Stored Measurement Data</p>	<p><Mean Value Display></p> <p>Along with the Mean Value display, you will see the total number of stored measurement data at the bottom.</p> <p>Each time you press Mode, it will show in order the mean values for: Air Temperature → Pressure → Air Velocity.</p>
<p>③</p>  <p>Maximum Value Mark</p>	<p><Maximum Value Display></p> <p>Along with the Maximum Value display, you will see the total number of stored measurement data at the bottom.</p> <p>Each time you press Mode, it will show in order the maximum values for: Air Temperature → Pressure → Air Velocity</p>
<p>④</p>  <p>Minimum Value</p>	<p><Minimum Value Display></p> <p>Along with the Minimum Value display, you will see the total number of stored measurement data at the bottom.</p> <p>Each time you press Mode, it will show in order the minimum values for: Air Temperature → Pressure → Air Velocity</p>

DISPLAY

PROCEDURE

⑤



Approximate Location

Data Number

<Stored Measurement Data Display>

The latest measurement data that was stored will be displayed with the Data Number and bar graph. (The bar graph indicates the approximate location of the data stored.)

Each time you press **Mode**, it will show in order the stored measurement values for : Air Temperature → Pressure → Air Velocity



In addition, when you press **▲** **▼** you can display other data pertaining to other Data Numbers.


Each time you press **Mode**, it will show in order the stored measurement values for : Air Temperature → Pressure → Air Velocity

※You can also select and delete data from this display. For details refer to Chapter 4 “Storing and Deleting Stored Measurement Data”.

6. Data Output

6. 1 Printing Out

6. 1. 1 Set up the Printer Paper (Roll Paper)




① Open the cover by lightly pressing on the arrows, and pulling the printer cover towards you.


② Turn on the Power Supply Switch and press

Feed

③ Confirm the sides of the paper – front and back. (The illustration shows the back (inner) side of the roll paper facing upwards toward you.) Insert the front end of the roll paper underneath the Roller.




How to Cut the Roll Paper




As shown in the left illustration, cut the right side of the Roll Paper so it is longer than the left. The Roll Paper Sensor is located at the right side of the Roller, therefore, Roll Paper installation will be easier if the right side is longer.

※Use the designated thermal paper. (Seiko Instruments TP-202L).




④ When you insert the tip of the Roll Paper into the Roller, the Roller will automatically rotate and crank up the paper, and the paper will come out from the top.

※ If you have problems properly setting the paper (slanted, bent, etc), pull the Head Lever up, remove the paper, and repeat steps ② to ④.




⑤ Press **Feed** until the tip of the approximately 5 cm of the paper has come out of the Roller.

※ Be careful that the paper coming out of the Roller does not get fed back into the Roller.




⑥ Install the paper into the Holder as you tighten the roll. Make sure the paper comes out of the Paper Outlet located on the Printer Cover. Close the Printer Cover to complete installation.

※ Be sure to eliminate any slack on the Roll Paper as much as possible. Otherwise, the loose portion may accidentally get pulled into the Roller.




6. 1. 2 Spot Value Print Out

DISPLAY	PROCEDURE
---------	-----------




Press **Print** while you are in the Normal Measurement Display. It will hold the measurement value for all **parameters** (Air Velocity, Air Temperature, Pressure) .Those values will be printed out.

Example of Print Out




6. 1. 3 Calculation Results Print Out

DISPLAY	PROCEDURE
---------	-----------




Display the Calculation Mode (Press **Calc.** in the Normal Measurement Mode) and then press **Print** . The calculated values for all measurement **parameters** (mean, maximum, minimum) will be printed out.

Example of Print Out



6. 1. 4 Stored Data Print Out

DISPLAY



PROCEDURE

Display the **Calculation** Mode (Press **Calc.** in the Normal Measurement Mode. By pressing **▼** together with **Print** you will get the print out of the calculation values for all measurement **parameters** (mean, maximum, minimum) along with the stored measurement data.

6. 1. 5 Function Set Information Print Out (Also for Test Print)

DISPLAY



PROCEDURE

Press **Print** **Feed** keys together for more than 2 seconds. This will print out the information pertaining to the functions that were set up.
 ※For details on how to set up functions, refer to Chapter 7 “Other Settings”.
 ※This function can be used to do test print.

Example of Data Print Out

< Calculation Results + Measurement Data >

< Information on Function Set-up >

Measurement	Conditions	DATE: 2002/10/29									
		TIME: 09:41:29									
		DATA: 063									
	Results	MODE: VEL TEMP PRS									
		MAX 7.25 m/s									
		AVG 5.79 m/s									
		MIN 2.66 m/s									
		MAX 22.5									
		AVG 21.0									
		MIN 19.4									
Measurement Data	MAX 0.78 kPa										
	AVG 0.43 kPa										
	MIN 0.27 kPa										
		NUM	m/s		kPa						
		01	3.89	21.8	0.33						
		02	4.41	22.0	0.41						
		03	5.01	22.4	0.32						

	Probe Number	PROBE No. 1	
		PROBE Type.10	
		SensorTime 150min	
	Information on Hardware Setup	HARD SW SETTING	Information on Function Setup
	(This cannot be changed)	Bit PR ON	
		Bit PRS ON	
	Baud Rate	SOFT SW SETTING	
	Buzzer ON/OFF	BAUD RATE 4800	
	Air Velocity Unit	BUZZER ON	
	Air Temperature Unit	Vel Unit m/s	
	Pressure Unit	Temp Unit	
	Analog Output Range(Air Vel)	PRS Unit kPa	
	Analog Output Range(Air Temp)	ANALOG Vel 0 - 5.0	
	Analog Output Range(Pressure)	ANALOG Temp 0 - 50.0	
		ANALOG PRS -5.0 - 5.0	
		DATE DISPLAY JP	

	Test Print	TEST PRINT	
		0123456789-+/*()	

6. 2 Digital Output

6. 2. 1 Preparation

You can download the data stored in the ANEMOMASTER to your PC, by connecting ANEMOMASTER and your PC with the RS232C cable (Optional).

<Need To Have>

- Personal Computer
- RS-232C Cable (Optional)
- Software (Example: Windows has software for hyper terminals.)


<Check the BAUD RATE>

You need to coordinate the **Baud rate** on both Main Body and your PC.

The factory setting of Main Body is as follows:

Data Bit Length	8 bits
Parity Permission	Without
Parity Condition	Odd
Stop Bit	1
Delimiter	CRLF
Baud Rate	※Depends on the set up value

※To change the BAUD RATE, please refer to Chapter 7 “ Other Settings”



For setting your PC, refer to the operation manual of your PC

<Connecting PC>

- ① Turn OFF the ANEMOMASTER
- ② Connect PC to Main Body using an RS-232C cable.
- ③ Turn ON the ANEMOMASTER
- ④ Make sure that the ANEMOMASTER is displaying the NORMAL Measurement Mode.

RS232C Cable Wiring Diagram

PC (D-Sub9 pin)		Connection	ANEMOMASTER (MODEL6113)			
Signal	Pin No.		Pin No.	Signal	Purpose	Direction
NC	1		1	GND	Signal Ground	
RXD	2		2	TXD	Transmitting	Output
TXD	3		3	RXD	Receiving	Input
NC	4		4	CTS	Transmission Approval	Input
GND	5		5	RTS	Transmission Request	Output
NC	6		6	NC		
RTS	7					
CTS	8					
NC	9					

◆ We also have measurement software available for Windows. (Sold separately.)

6. 3 To Access From Your PC

To connect to ANEMOMASTER to your PC, please refer to the previous Section 6. 2 “Digital Output”.

Icons and its Meaning

␣: Space

␣: Return or Press Enter

*: A Number




Command	Function
D * * * * ␣	Number of Downloading Data
N␣	Receiving Cancelled
S␣	Output of Measuring Condition (of On-time Data)
U␣	Output of Measuring Units
P␣	Output of Page Number and Amount of Data
T * * * * ␣	Output of Stored Data

※ All commands must be in capital letters.

6. 3. 1 Transmission of On-Time Data (Every-second Basis)

DISPLAY	PROCEDURE
<p>Example: Air Velocity Measurement Mode and typed D****␣</p> <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>AD␣ ␣␣␣0.19;␣␣␣26.8;␣␣␣73.4␣ ␣␣␣0.51;␣␣␣26.8;␣␣␣73.5␣ ␣␣␣0.61;␣␣␣27.0;␣␣␣76.1␣ ␣␣␣0.24;␣␣␣27.0;␣␣␣77.5␣ ␣␣␣0.15;␣␣␣26.9;␣␣␣76.0␣</p> </div>	<p><Set Number of Data Needed> Press “D * * * * ␣” (※Must type in 4 digits) After entering you will receive “AD” and the data will be displayed. Each data represents 1second of measurement. If you ask for 20 data, it takes approximately 20 seconds to display. The maximum number that can be set is 9999. If you need more, re-send the command. <Output Content> With Pressure (Option): Air Velocity; Air Temperature; Pressure Without Pressure: Air Velocity; Air Temperature;; 0000000</p>
<div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>AN␣</p> </div>	<p><To Cancel> Press “N”. You will receive “AN” and the transmission will be cancelled.␣</p>
DISPLAY	PROCEDURE
<div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>AS␣ VT- ;01;␣</p> </div>	<p><To Download Measuring Conditions> Press “S␣” After entering“S”, you will receive “AS” and the data will be displayed. You will see the measurement Parameter, and Time Constant that appears on the display. (See Section 3. 4 “To Change Time Constant”) <Output Content> Measuring Parameter (VT- PRS); Time Constant; { VT-: Air Velocity, or Air Temperature PRS: Pressure (Optional)</p>
DISPLAY	PROCEDURE
<div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>AU␣ m/s; ;kPa␣</p> </div>	<p><To Download Measuring Units> Press “U␣” After entering “U”, you will receive “AU” and the data will be displayed. You will see the measurement unit that is currently set up. <Output Content> Velocity Unit; Temperature Unit; Pressure Unit</p>

6. 3. 2 Transmission of Data Stored in Memory

DISPLAY	PROCEDURE
	<To Download Page Number> Press "P" You will receive "AP". Number of data stored pages will be downloaded.
DISPLAY	PROCEDURE
	<To Download Stored Data> Press "T****" (※Must type in 4 digits) Type in the desired page number after "T". You will receive "AT", and the data which is stored under that number will be displayed. ※There will be no output of calculation data (Min, Mean, Max). ※The measurement unit currently set up will be applied to the output data. <Output Content> With Pressure (Option): Data Number, Air Velocity, Air Temperature, Pressure Without Pressure: Data Number, Air Velocity, Air Temperature, 00000
DISPLAY	PROCEDURE
	<Error Message> You will get this message if you enter the wrong number of pages. Re-type the command.

6. 4 Setting the Output for Single Parameter Measurement Data


When you turn on this function, you can output only the value that was shown in the operation. See Pag xxxx "Other Settings" for details.

6. 4. 1 How to Print-out using the Setting for Single Parameter Data Output

Please refer to Section 6. 1 "Printing Out" on how to print out measurement data.

Example of a Print Out


<Measurement Results (Air Velocity)>



```

2002/10/29  09:41:29
MODE VEL
0.06 m/s
  
```

<Calculation Results (Pressure)>



```


DATE:2002/10/30
TIME:07:52:55
DATA:006
MODE:PRS
MAX   0.44 kPa
AVG   0.33 kPa
MIN   0.21 kPa
  
```

6. 4. 2 Digital Output using the Settings for Single Parameter Output

Please refer to Section 6.2 "Digital Output" on how to digitally print out measurement data.

Display


<Output of Downloaded Data (Air Temperature)>



```

AD
0000000;0.268;0000000
0000000;0.267;0000000
  
```

<Output of Stored Data (Air Velocity)>



```


AT
2002/10/30;14:25:46
011;0.15;0000000;0000000
  
```

6. 5 Analog Output (Optional)

- ①Data Update Interval0.1 seconds
- ②Load ImpedanceAbove 5KΩ
- ③Output CurrentDC 0~1V

For the analog output, you must select one setting from the table below. The measurement value that is displayed on the Normal Measurement Display will be out put. See “Other Settings” for details.

	Output Range	Conversion Formula
Velocity (U)	0 ~ 5 m/s	$U= 5 \times V$ m/s
	0 ~ 10 m/s	$U=10 \times V$ m/s
	0 ~ 25 m/s	$U=25 \times V$ m/s
	0 ~ 50 m/s	$U=50 \times V$ m/s
	0 ~ 1000 FPM	$U=1000 \times V$ FPM
	0 ~ 2000 FPM	$U=2000 \times V$ FPM
	0 ~ 5000 FPM	$U=5000 \times V$ FPM
	0 ~ 9999 FPM	$U=9999 \times V$ FPM
Temperature (T)	-10 ~ 40 °C	$T= 50 \times V - 10$ °C
	0 ~ 50 °C	$T= 50 \times V$ °C
	0 ~ 100 °C	$T=100 \times V$ °C
	14 ~ 104 °F	$T= 90 \times V + 14$ °F
	32 ~ 122 °F	$T= 90 \times V + 32$ °F
	32 ~ 212 °F	$T=180 \times V + 32$ °F
Pressure (P)	-5 ~ +5 kPa	$P= 10 \times V - 5$ kPa
	-2 ~ +2 kPa	$P= 4 \times V - 2$ kPa























Of the output range, the low end will be set at 0V and the high end will be set at 1V. The voltage is linear. The Time Constant (0.1 second at normal) will be in effect. To change the setting of Time Constant, refer Section 3. 4 “To Change Time Constant”.

Mode	Way To Take In Measured Data (Analog Output)	Explanation
TC1	<p>0 0.5 1.0 1.5 2.0sec (Measuring Time)</p> <p>Average of 1sec.</p>	Take the data 10 times in a second and indicate its average as an instantaneous value at every 0.1 sec.
TC5	<p>0 2.5 5.0 7.5 10sec (Measuring Time)</p> <p>Average of 5sec.</p>	Output the average value of 5sec. at every 0.1sec. Data shifts by 0.1sec.
TC10	<p>0 5 10 15 20sec (Measuring Time)</p> <p>Average of 10sec.</p>	Output the average value of 10sec. at every 0.1sec. Data shifts by 0.1sec.

7. Other Settings

7.1 Date

DISPLAY	PROCEDURE																		
	<p>When you are in the Normal Measurement Mode, press  and  together for more than 2 seconds.</p>																		
 <p data-bbox="178 952 343 985">Set-up Level</p>	<p>The set-up level will be displayed on the bottom left and the last 2 digits of the year will flicker. Press either keys   to adjust to the desired number. Then press .</p> <p>※ The Set-up Level numbers correspond to the following:</p> <table data-bbox="686 918 1220 1041"> <tr> <td>1</td><td>.....</td><td>Year</td> <td>4</td><td>.....</td><td>Time</td> </tr> <tr> <td>2</td><td>.....</td><td>Month</td> <td>5</td><td>.....</td><td>Minute</td> </tr> <tr> <td>3</td><td>.....</td><td>Day</td> <td></td><td></td><td></td> </tr> </table>	1	Year	4	Time	2	Month	5	Minute	3	Day			
1	Year	4	Time														
2	Month	5	Minute														
3	Day																	
	<p>Next, there will be a display to set up the month. Press either keys   to adjust to the desired number. Then press .</p>																		
	<p>Next, there will be a display to set up the day. Press either keys   to adjust to the desired number. Then press .</p>																		
	<p>Next, there will be a display to set up the time. Press either keys   to adjust to the desired number. Then press .</p>																		



Next, there will be a display to set up the time.

Press either keys to adjust to the desired number, and press . This will return you to the Normal Measurement Mode, and the set up will be complete.


※ If you press before you save, you will return to Main Menu and the setting will NOT be saved.

7. 2 Units and Baud Rate

You can set up the Baud Rate, measurement units, data output **parameters**, using the bit set-up (Soft Dip Switch). Once the set-up is stored, it will not be lost even if the switch is turned off because of the back-up batteries.

7. 2. 1 Set-up

DISPLAY



Bit Number shows zero

Indicates the Bit Status


PROCEDURE

Turn the switch OFF first. Then turn the switch back ON by holding onto . Continue to hold until you see a display like the one on the left.

The “b0” (see left) indicates the Bit Number. “01” on the right indicates the Bit Status. (See the next page Section 7.2 “Dip Switch Set-up Chart” for definitions on Bit Number and Bit Status.)



Using either keys, select the Bit Status. Press to save the set-up. Move onto the next bit number. (After 9 is displayed, it will display 0 (zero)).



Press when you have finished setting up all Bit Numbers. This will return you to the Normal Measurement Display.

7. 2. 2 Dip Switch Set-up Chart

※ = Set up at the time of ship-out

Set-up Parameter	Specification	Display of Bit Status		
Baud Rate Setup [b0, b1]	4800bps	b0:00	b1:00	
	9600bps	b0:01	b1:00	
	19200bps	b0:00	b1:01	
	38400bps	b0:01	b1:01	
Buzzer ON/OFF Setup [b2]	YES	b2:00	—	
	NO	b2:01	—	
Wind Velocity Unit Setup [b3]	m/s	b3:00	—	
	FPM <1m/s = 196FPM>	b3:01	—	
Air Temperature Unit Setup [b4]	°C	b4:00	—	
	°F <T(°F) = 1.8 × T(°C) + 32 >	b4:01	—	
Analog Output (Option) [b5] Range Setup	Wind Velocity	0~5m/s	b5:00	b6:00
		0~10m/s	b5:01	b6:00
		0~25m/s	b5:00	b6:01
		0~50m/s	b5:01	b6:01
		0~1000FPM	b5:00	b6:00
		0~2000FPM	b5:01	b6:00
		0~5000FPM	b5:00	b6:01
		0~9999FPM	b5:01	b6:01
	Wind Temp.	0~50°C	b5:00	b6:00
		0~100°C	b5:01	b6:00
		-10~40°C	b5:00	b6:01
		32~122°F	b5:00	b6:00
		32~212°F	b5:01	b6:00
	Pressure	14~104°F	b5:00	b6:01
		-5~+5kPa	b5:00	b6:00
		-2~+2kPa	b5:01	b6:00
Data Output Parameter Setup [b7]	All Parameters	b7:00	—	
	Single Parameter	b7:01	—	
Date Display Format Setup [b8, b9]	Japanese Format: Yr/Mo/D	b8:00	b9:00	
	American Format: Mo/D/Yr	b8:01	b9:00	
	European Format: D/Mo/Yr	b8:00	b9:01	

8. Cleaning the Probe

Dust or particles attached on the velocity sensor would alter the amount of heat diffusion, which leads to less precise reading. Also, deformation or clogging up of the protective mesh around the sensor of ANEMOMASTER would also affect the accuracy of the instrument.

Users are encouraged to clean up Probe regularly for maintaining accurate measurement

Procedure

Clean the sensor by soaking it to water in ultrasonic cleaner for 10 to 20 seconds. Do not soak it for too long, since there is an increased risk of damaging the coating of the sensor.

You can also clean the sensor with neutral detergent, when it should be washed up with water fully.

! CAUTION !

!)When cleaning, make sure that the power is OFF.

!)Make sure that the sensor is dry before turning it ON.

9. Specification


Product Name		ANEMOMASTER Air Velocity Meter	
Model		6113	
Measuring Object		Clean air flow	
Measuring Range (Resolution)	Air Vel.	0.10~50.0 m/s (0.00~9.99m/s:0.01m/s, 10.0~50.0m/s:0.1m/s)	
	Air Temp	0.0~100.0 °C (0.1°C)	
	Pressure ※	-5.00~+5.00 kPa (0.01kPa)	
Accuracy	Air Vel.	±(3% of reading + 0.1) m/s	
	Air Temp	±1.0 °C	
	Pressure ※	±(3% of reading + 0.01) kPa	
Response Time	Air Vel.	Approx. 1 second (at 1m/s, 90% response time)	
	Air Temp	Approx. 30 seconds (at 1m/s, 90% response time)	
	Pressure ※	Approx. 1 second	
Temperature Compensation (Air Velocity)		±(5% of Reading + 0.1)m/s (in the temperature range 5 to 80.0°C)	
Functions		<p>Measurement Hold: Max., Min., Avg.; Time Constant (1, 5, 10 seconds); Battery Level Indicator (5 Levels), Unit selection: (Air Velocity: m/s, FPM, Temperature: °C, °F; Static Pressure※: kPa) Measurement data storage: Spot value, Mean value(max 60seconds); Max upload of 100 data. Calculation functions: Max, Min, Mean calculation; Unprocessed data display; Calendar feature; Bar graph display for air velocity value.</p>	
Output		<p>Digital Output: RS-232C (Baud Rate 4800, 9600, 19200 and 38400 bps) for output to PC※ Printer Output: Calculation results, measurement data Analog Output※: DC 0~1V (select one from Air Velocity, Temperature, Pressure)</p>	
Power		<p>6 × AA Batteries (Manganese, Alkaline, Ni-Cd), AC Adaptor※: AC 100~240V (50/60Hz)</p>	
Battery Life		Approximately 10 hours continuous (at air velocity 5m/s, 20°C, with alkaline batteries, and not using printer)	
Operating Environment	Main Body	5~40 °C	
	Probe	0~100 °C	
	Storage Environment	5~40 °C	
Weight		Approximately 1000 g (without batteries)	
Accessories		Operation Manual, 6 × AA Batteries, Probe Cable (2m), Extension Rod, Shoulder Strap, Printer Roll Paper	
Options		Spare Probe, Analog Output, Pressure Sensor, RS-232C Cable, Software (for Windows), AC Adaptor	

※Optional

10. Principle of Measurement

➤ Principle of Hot-Wire Anemometer


The principle of the thermal Probe is based on a heated element from which heat is extracted by the colder impact flow. The temperature is kept constant via a regulating switch. The controlling current is directly proportional to the velocity.



When thermal velocity Probes are used in turbulent flows, the measured result is

influenced by the flows impacting the heated body from all directions.

In turbulent flows, a thermal velocity sensor indicates higher measured values than a vane Probe. This can be observed during measurements in ducts. Depending on the design of the duct, turbulent flows can occur even at low velocities. The amount of heat that is extracted by the colder impact flow from the sensor can be expressed by:



$$H = (a + b\sqrt{U})(T - Ta) \quad \dots \dots \text{King's formula}$$

Where H: Heat diffusion quantity T: Temperature of the sensor Ta: Air temperature U: Air velocity a, b: Constant



Also, heat diffusion quantity can be expressed by the formula:

$$H = RI^2$$

Where R is resistance and I is current


(R is kept constant regardless of air velocity since the temperature is constant).

Therefore, $RI^2 \propto a + b\sqrt{U}$



➤ The Temperature Compensation

The air velocity sensor is heated to an elevated temperature relative to the surrounding air by means of control electronics. The temperature compensation sensor senses the ambient, or surrounding air temperature and forces the velocity sensor to stay at a constant overheat above the ambient. The circuit forces the voltage to be equal by means of an operational amplifier. Air flowing past the sensor tends to cool the sensor, thus driving down its resistance. The amplifier responds by immediately delivering more power to the circuit to maintain voltage equilibrium. Delivered power is converted into electrical signal to display.




Temp Sensor
(Platinum Resistor)

➤ **Measurement of Wind-Temperature**

The coefficient of resistance of the temperature sensor has a direct proportional relationship with the temperature. We can measure the wind temperature by adjusting the sensor's temperature to the wind-temperature, and measuring its coefficient of resistance.

➤ **Measurement of Humidity (Hygrometer)**


The sensor is a pair of condenser and its electro-capacity is depended upon the amount of water contained in its hydrophilic macromolecule (humidity sensitive) membrane. The components of the sensors are glass foundation; lower electrode; macromolecule membrane and upper electrode. The upper electrode will capture the change in permittivity caused by condensation or evaporation of water vapors to the macromolecule membrane. (Electrostatic Capacity Type) There is another type of hygrometer that uses a resistor instead of a condenser. It is usually said that the Electrostatic Capacity is good for low humidity measurement and the resistor is good for high humidity measurement.



➤ **Theory of detecting static pressure.**


To measure static pressure, we use a diffusion-type semiconductor pressure sensor. The diffusion-type semiconductor pressure sensor is incorporated under the principle that the resonant frequency of a piezo-crystal decreases linearly with the pressure applied. On a thin diaphragm of silicon, there are four diffusion resistors (sensor chips) placed in a fixed distant apart. (Pic.1)

When the pressure is applied from above, the diaphragm will deflect downward. When it is deflected, the sensors near center (R3 and R4) will have compressing stress and the sensors near perimeter (R1 and R2) will have tensile stress instead. (Pic.2) The diffusion coefficient of diffusion resistor change according to these two stresses.




R1 ~ R4: Diffusion Resistant

Pic.1 Pressure Sensor



Pic.2



Pic.3 Detecting Circuit

If we create a bridge among these diffusion resistors (Pic.3), it will be possible to detect voltage that is proportional to the amount of pressure applied. These sensors can be affected by the temperature, and therefore, temperature compensation circuit must be added.

11. About Compensation

This instrument has been calibrated at normal temperature and pressure. Therefore, if you are going to measure velocity at a different temperature and pressure, the indicating value will be affected.

11. 1 Influence of Measuring Temperature

This instrument has been calibrated at normal temperature. Because of theoretical fundamentals of hot-wire anemometer, it can easily be effected by the ambient temperature. To prevent such influence, temperature compensation is needed. The temperature compensation sensor senses the ambient, or surrounding air temperature and forces the velocity sensor to stay at a constant overheat above the ambient. By adopting temperature compensation sensors, you can measure air velocity accurately within the range of 5~80°C (41~176°F)

11. 2 Influence of Pressure at Measuring Point

This instrument has been calibrated at 1013hPa. Change in pressure does affect the amount of heat diffusion. Therefore, the pressure compensation, using the following equation, is needed.

$$U_m = \frac{1013}{P_m} \times U_c$$

Where: U_m : Actual Velocity[m/s] U_c : Indicating Value P_m : Pressure at the Measuring Point[hPa]



11. 3 Measuring Gas Components

This instrument has been calibrated using air. The ANEMOMASTER indicates air velocity based on the heat capacity, i.e. the heat diffusion quantity to deprive a device of in fluid. If the fluid, which is dealt with for the measurement, is different from the fluid when the instrument is calibrated, the diffusion quantity changes and the indicating air velocity, too, will be affected.

In order to compensate, you first need to find the heat diffusion quantity of air to the indicating value in mixture measurement. By substituting this heat diffusion quantity to the value in the heat diffusion-velocity relation formula, you can find the actual velocity value of the mixture.



12. Probe Directivity (Air Velocity)

12.1 Horizontal



At Air Velocity 5m/s

12.2 Vertical



At Air Velocity 5m/s

13. Trouble Shooting

13. 1 Batteries

Problem	Possible Cause(s) / Solution (s)	Refer To (Page No.)
ANEMOMASTER will not turn ON	The battery is old or defective. →Turn OFF the power and replace the batteries.	6
Nothing appears on the display even when batteries are replaced.	Batteries are installed incorrectly. →Turn OFF the power and place in the correct polarity.	6
Display shows "E - - 0"	The batteries are low. →Turn OFF the power and replace the batteries.	6


13. 2 Initial Operations

Problem	Possible Cause(s) / Solution (s)	Refer To (Page No.)
Display shows "E - - 9"	ROM Cassette is not inserted. →If already inserted, turn OFF the power and re-insert.	7
Display shows "- - - -"	Probe/Probe Cable not connected properly. →Turn the OFF the power and connect Probe.	7
The measurement unit is not correct.	You may switch to the Air Velocity Measurement unit (m/s, FPM), Air Temperature Measurement Unit (°C, °F).	28

13. 3 During Operations

Problem	Possible Cause(s) / Solution (s)	Refer To (Page No.)
"- - - -" is displayed for measured value.	This means the value exceeds the specified measurement range. →Use within the specified range.	31
	Probe/Probe Cable is not connected property. →Check the connection.	7
	Probe/Probe Cable may be damaged. →Contact your local Kanomax Office or service center.	
ANEMOMASTER is not displaying the right speed.	Probe is not facing the wind. →Make sure the Wind Mark is facing the wind.	9
Higher temperature is displayed.	Theoretically, ANEMOMASTER cannot measure temperature in no-wind environment. →Measure the temperature in environment with more than 0.1m/s of wind.	9
The response for Air Velocity Measurement is slow.	Confirm the Time Constant settings.	13
Display shows "E - - 8" when doing Zero Adjustment Procedure	Pressure Port(+, -)is blocked. →Unblock both ports for + and -.	9
	The adjustment exceeds the range specified for the Zero Adjustment. →Contact your local Kanomax Office or service center.	9

13. 4 Printer Output

Problem	Possible Cause(s) / Solution (s)	Refer To (Page No.)
Cannot printout.	Printer paper not installed correctly. →Open the printer cover and reinstall. Also, check for paper accidentally pulled into the printer.	19
	Out of printer paper. →Change the remaining amount on the roll when you start seeing red marks on the edges of the paper.	19
	Batteries are low. →Turn OFF the power and replace the batteries.	6
Prints only the value shown on the display.	The set-up for data output is in the SINGLE Parameter output mode. →Use the set-up function to switch to ALL parameters output mode.	28
Cannot cancel the printout.	You cannot cancel the printout.	
Display shows "E -- 1".	The printer paper is not set. →Check if the printer paper is properly set up in the Roller.	19
Display shows "E -- 2".	Batteries are low. →Turn OFF the power and replace the batteries.	6
	Printer Head is overheated due to continuous use of the printer. →Temporarily stop printing out and recommence.	
Display shows "E -- 3".	The Printer Head Lever is up. →Pull down the lever. Printer Head Lever 	19

13. 5 Digital Output

Problem	Possible Cause(s) / Solution (s)	Refer To (Page No.)
Cannot load the data	Cable not correctly connected or using wrong cable. →You need to use the RS232C cable.	23
	Baud rate setup is incorrect. →Check the settings between the ANEMOMASTER and the computer.	23
	Transmission command is wrong.	24

13. 6 Analog Output

Problem	Possible Cause(s) / Solution (s)	Refer To (Page No.)
	Wrong polarity. →Correct the polarity.	26

	Mode problem. →Need to use the Normal Measurement Mode.	11
The Air Velocity output looks like a “staircase”.	Check the Time Constant setting.	13
Output value is different	Analog output setting is wrong.	26
	The output range setting is wrong.	26
	The load impedance is lower than the designated value. (Load impedance needs to be over $5k\Omega$).	26

14. Warranty and After Service

Kanomax Limited Warranty

The limited warranty set below is given by KANOMAX JAPAN, Inc. (hereafter referred to as “KJI”) with respect to the KANOMAX brand anemometer, its attachment parts including Probe and other accessories (hereafter referred to as “PRODUCT”) that you have purchased. PRODUCT you have purchased shall be the only one that the limited warranty stated herein applies to.

Your PRODUCT, when delivered to you in new condition in its original container, is warranted against defects in materials or workmanship as follows: for a period of one (1) year from the date of original purchase, defective parts or a defective PRODUCT returned to KJI, as applicable, and proven to be defective upon inspection, will be exchanged for a new or comparable rebuilt parts, or a refurbished PRODUCT as determined by KJI. Warranty for such replacements shall not extend the original warranty period of the defective PRODUCT.

This limited warranty covers all defects encountered in normal use of the PRODUCT, and does not apply to the following cases:

- (1) Use of parts or supplies other than the PRODUCT sold by KJI, which cause damage to the PRODUCT or cause abnormally frequent service calls or service problems.
- (2) If any PRODUCT has its serial number or date altered or removed.
- (3) Loss of damage to the PRODUCT due to abuse, mishandling, improper packaging by the owner, alteration, accident, electrical current fluctuations, failure to follow operating, maintenance or environmental instructions prescribed in the PRODUCT’s instruction manual provided by KJI, or service performed by other than KJI.

NO IMPLIED WARRANTY, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, APPLIES TO THE PRODUCT AFTER THE APPLICABLE PERIOD OF THE EXPRESS LIMITED WARRANTY STATED ABOVE, AND NO OTHER EXPRESS WARRANTY OR GUARANTY, EXCEPT AS MENTIONED ABOVE, GIVEN BY ANY PERSON OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BIND KJI. KJI SHALL NOT BE LIABLE FOR LOSS OF STORAGE CHARGES, LOSS OR CORRUPTION OF DATA, OR ANY OTHER SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY THE USE OR MISUSE OF, OR INABILITY TO USE, THE PRODUCT, REGARDLESS OF THE LEGAL THEORY ON WHICH THE CLAIM IS BASED, AND EVEN IF KJI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT SHALL RECOVERY OF ANY

KIND AGAINST KJI BE GREATER IN AMOUNT THAN THE PURCHASE PRICE OF THE PRODUCT SOLD BY KJI AND CAUSING THE ALLEGED DAMAGE. WITHOUT LIMITING THE FOREGOING, THE OWNER ASSUMES ALL RISK AND LIABILITY FOR LOSS, DAMAGE OF, OR INJURY TO THE OWNER AND THE OWNER'S PROPERTY AND TO OTHERS AND THEIR PROPERTY ARISING OUT OF USE OR MISUSE OF, OR INABILITY TO USE, THE PRODUCT NOT CAUSED DIRECTLY BY THE NEGLIGENCE OF KJI. THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THE PRODUCT, OR THE PERSON FOR WHOM IT WAS PURCHASED AS A GIFT, AND STATES THE PURCHASER'S EXCLUSIVE REMEDY.

After Service

Whenever the PRODUCT is malfunctioning, please check with "Troubleshooting" to find possible cause first.

Repair parts are retained for a minimum period of five (5) years after production cessation of the PRODUCT. This storage period of repair parts is considered as the period during which KJI can provide repair service.

For more information, please contact your local distributor, or call us at KJI's service desk from 9:00 a.m. to 5:00 p.m. JST on weekdays excluding holidays. When you make a call, please have the following information of your PRODUCT at hand:

- (1) PRODUCT name;
- (2) Model number;
- (3) Serial number;
- (4) Probe number;
- (5) Description of Symptom, and;
- (6) Date of purchase