

**testo**

**testo 545**



**Instruction manual  
Luminous intensity  
measuring instrument**





Contents .....	2
Foreword .....	3
Initial operation .....	4
First measurement .....	5
Instrument description	
-Keypad/Connection assignment .....	6
-Display .....	7
Overview of controls .....	8-9
Current measurement .....	10
Switching on .....	10
Saving, Printing .....	10
Measurement functions .....	11
Freezing readings .....	11
Maximum readings .....	11
Minimum readings .....	11
Multi-point mean calculation .....	12
Timed mean calculation .....	12
Location selection .....	14
Measuring range switchover function .....	14
Memory settings .....	15
Overview .....	15
Manual / Automatic saving .....	16
Reading out or printing memory .....	17
Clearing memory contents / Sample printouts .....	18



According to the conformity certificate, the instruments fulfill **89/336/EWG** guidelines.

© 1999 Copyright Testo GmbH & Co.  
The software and software structure included in the product **testo 545** are protected by copyright laws worldwide.

## Contents

---

Instrument configuration .....	19
Power save function .....	19
Setting date/time .....	19
Unit selection / Factory reset .....	20
Power supply .....	20
Error messages .....	21
Technical data .....	22
Ordering data .....	23
Warranty .....	24
testo worldwide	

## Foreword

Dear Customer

You have made the right decision by choosing a measuring instrument from Testo. Every year, thousands of customers purchase our high-quality products. There are at least seven good reasons for this.

- 1) We offer value for money. Reliable quality at the right price. -
- 2) Considerably longer guarantee periods of up to 3 years - depending on the instrument.
- 3) With over 40 years of specialist experience we are optimally equipped to solve your measuring tasks
- 4) Our high quality standards are confirmed by ISO 9001 certification.
- 5) It goes without saying that our instruments bear the CE symbol required by the EU.
- 6) Calibration certificates for all relevant parameters.
- 7) Reliable service.

## Please read prior to measurement






Do not measure on live parts.

Observe storage and transport temperature and max. operating temperature (e.g. protect measuring instrument from direct sunlight)

The V24 cable (PC connection) can be inserted anytime.  
A simultaneous print command is not possible if the PC cable is connected.

Opening the instrument, inexpert handling and use of force cancels your warranty.



## Putting in the batteries

9V block battery is included in delivery.

Open the battery compartment at the back of the instrument.  
Put in block battery. **Observe polarisation**  
Close battery compartment.

Refer to "Power supply" Chapter for more information on alternative power supply, charge, battery quality.

**The description of the instrument and an overview of the controls provide a quick introduction.**



***Instrument configuration***

You will receive up to date readings once the instrument is switched on. However, you will still need to update or define the data in the instrument:

- ⇒ Date/Time:
- ⇒ Auto Off:
- ⇒ Units:

Some things can only be set via PC software (See Ordering data):

- ⇒ Location name (8 characters)
- ⇒ Log heading (24 characters), e.g. your company name - is printed when the readings are printed.

### Keypad:

On/Off

Prints


Confirms menu setting/  
executes function

Saves

Return to current measurement/  
location selection


Arrow buttons  
move the cursor

Hold Max Min  
Mean



# Instrument description

## Display



→ The symbols on the top line are explained below

→ Name of input socket and parameter

→ Displays reading in line 1

→ Name of location



→ Time/number of points in mean calculation



→ Displays measurement functions



### Explanation of symbols:



**M. 00** Counter for the log number in the memory.  
When saving manually: number of the measurement saved.  
When saving automatically: number of the measurement series. This counter is needed in order to be able to find single logs or a measurement series when reading out the memory.

**N. 0000** Counter for saving a measurement cycle (required only for automatic saving). The measurement cycle in a measurement series can be found.


**MAN** →  Manual saving of a single measurement by pressing the save button .

**AUTO** →  Automatic saving program has been set up.  
Saving is activated by pressing the  button.

 →  Symbol for reading contents of memory on display.


 →  Symbol for deleting memory contents.



If this symbol appears, the printing function is activated.  
The symbol flashes while data is being transmitted. You can print on the desktop printer by pressing the print button .



Shows capacity of battery and rechargeable battery.




If the inner segment no longer appears (symbol flashes), the battery has to be changed or the rechargeable battery has to be recharged. The instrument switches itself off automatically after 1 minute.









# Overview of controls




**Note**  
 Flashing display is activated and is confirmed by pressing **OK**.



Battery / rech.  
battery power



Location



Line 1

Line 2

It is possible to activate the following functions during measuring at the touch of a button:



**Save readings.**


Manual or automatic saving is determined by the save setting (Chapter 5).




**Print readings.**

# Measurement functions

Freezing values, maximum readings, minimum readings







# Measurement functions

Timed mean calculation Mean ☉


Current measurement




- Hold
- Hold
- Hold
- Hold
- Hold Max/Min Mean



[OK] Start timed mean calculation.




[OK] Finish timed mean calculation.



[OK] Continue timed mean calculation


or  
► Calculate mean.



New mean calculation is possible.

- Mean
- Duration of mean calculation
- [ ] → Save mean.
- [ ] → Print mean.
- ESC Lockout - or - HOLD MAX/MIN MEAN → Return to current measurement.


**Note on saved or printed logs:**  
 1. The log of a **multi-point** mean calculation contains single values, max. value, min. value and mean value.  
 2. The log of a **timed** mean calculation contains max. value, min. value and mean value.



1. Current measurement

The location names Location 1 to 99 are specified by the factory.

You can load your own location names (8 characters) onto your instrument using PC software.



▲/▼ Selection of location.


OK

OK → Confirm selection and return to measurement.

Return to current measurement

🖨 or 💾 :

From now on all measured data which is saved or printed is linked to the selected location or product names.



OK

LUX ▶ LUX

OK

## Measuring range switchover function

Switching between measuring range and lux or fc resolution

Lux ▶ Lux x 10 / 0.1 fc ▶ fc

The resolution selected flashes.

▶ → Select

OK → Confirm selection and return to measurement.


Resolution	Meas. range	Resolution	Meas. range
1 Lux	32,000 Lux	0.1 fc	3200 fc
10 Lux *	100,000 Lux	1 fc	10,000 fc

\* Multiply displayed value by 10.

# Memory settings

## OVERVIEW

### 1. Current measurement




Press the **OK** button to get to the memory settings mode. Confirm flashing save symbol via **OK** button.

4 memory settings are possible. Select the required saving option by pressing **▶**:


MAN ▶ AUTO ▶ OUT ▶ CLEAR ▶ MAN ▶ ...

The symbol corresponding to the selection appears in the top line. The function is activated with **OK**.





Press the **OK** button to get to the memory settings mode.  
Confirm flashing save symbol via button.




MAN

### Manual saving:

Each time is pressed a log of the measurement is saved in the instrument and includes measured values, location, date and time. The counter in the top left corner of the display shows the number of logs saved for this location.

**Saving a log with timed or multi-point mean calculation :**  
The log includes MIN value, MAX value and mean of the measurement and also single values in multi-point mean calculations.

2



AUTO

### Automatic saving:

When this saving function is set, the instrument automatically accepts the measured values at fixed intervals and saves them (=logger operation). The number of measuring cycles (CYCLE-N.) to be saved and intervals (CYCLE) have to be programmed:

#### 1. Cycle-N.

The instrument automatically offers the maximum possible number of measuring cycles. Set required number using / / .

Confirm set value by pressing **OK**.

#### 2. Cycle

Select interval in which the measured values are to be saved.

The blinking position can be changed using .

Confirm set value by pressing **OK**.

Automatic saving is started by pressing . The symbol flashes until the programmed measurement series is accepted.




Cancel saving procedure.


Starts automatic saving again. An additional measurement series is added.



# Memory settings



## Reading or printing memory

Press the **OK** button to access the memory settings mode. Confirm flashing save symbol  via the  button. Cancel printout by pressing the  button.






OUT

### 1. Reading out or printing memory contents:

If the "OUT" display is flashing and the  button is pressed, printing of the complete memory contents is started. Cancel printout by pressing the  button.

### 2. Selecting the location:



If **OK** is activated selection options appear in the display to select the required location. Select location by pressing  .


If printing is activated by pressing  at this point, **all** of the logs (measurement series and cycles) for this location are printed.

Cancel printout by pressing the  button.

### 3. Selecting the log:

Confirm the location selected above by pressing **OK**. The M.0x counter flashes in the display.



Select the log no. by pressing  .


 activates a printout of the selected measurement log. Press **OK** to display the values measured.


Cancel printout by pressing the  button.

### 4. Select the measurement cycle (only possible if a measurement log consists of a measurement series):

Confirm the measurement log selected above by pressing **OK**. The N.0x counter flashes in the display.

Select the measurement cycle by pressing  .

 activates a printout of the selected measurement cycle.


The  button enables you to go back one step.



Press the **OK** button to access the memory settings mode. Confirm flashing save symbol via the button.

4

**CLEAR. Clearing memory:**



Printout of automatic saving


Heading	Smith Ltd.
Date of printout	31.08.1998 11:27:32
Location	Museum
Log	M.05
Start of saving	31.08.1998 11:26:59
Measuring cycle	cycle 00:00:02
	1:Lux
	01 653
	02 652
	03 650
	04 690
	05 705
	06 710
	07 695
	08 675
	09 638
	Info :


Printout of manual saving



Smith Ltd.
31.08.1998 11:26:05
Museum
M.01
31.08.1998 11:20:05
1: 725 Lux
Info :





# Instrument configuration

## Power save function / Power supply



The  button enables you to change to the current measurement from every menu item.

The  button has to be kept pressed for approx. 2 seconds when switching on the instrument ( button).


The blinking position can be changed by pressing    or confirmed by pressing .

### Power save function

Auto OFF function is switched on ("ON")

If a button has not been pressed in the last 5 minutes or there is no communication with the PC, the instrument switches off automatically.

### Exceptions:

- the function is deactivated during timed and multi-point mean calculation
- Automatic saving mode:  
The function is only activated if saving cycles > 1 min are programmed.
- In the case of an activated function (cycle > 1 min) the instrument switches itself on at the measurement time and switches off again. This also occurs if the instrument is switched off via the  button after the saving program has been activated.

**BAT: Battery operation** with 9 V block battery, Alkali manganese IEC 6LR61.

**AKKU: Rechargeable battery operation** with Testo rechargeable battery (Part no. 0515.0025), Type: Ni-MH IEC 6F22. If the **rechargeable battery** is empty: Recharge battery in external charger (Part no. 0554.0025).

### Note:

If the battery/rechargeable battery is removed, the instrument retains set values (date/time) and memory contents for approx. 10 minutes. The data is lost after 10 minutes.

The capacity of the battery/rechargeable battery is shown in the display:



100 %

75 %

50 %


25 %

0 %


(last segment is flashing: the battery/rechargeable battery is almost empty)

(change battery/recharge rechargeable battery). Instrument switches off after 1 min.


1



OK



OK



OK

Current measurement

### Setting date

The flashing position in the display can be set

- ▲/▼ = scroll/ ► = next position -

### Setting the time

The blinking position in the display can be set

- ▲/▼ = scroll/ ► = next position -

Lux ► fc

The selected parameter flashes.

► → Select

OK confirms the selection.



Factory resets all of the settings in the instrument configuration to the factory settings.

- "AUTO OFF" is set at "ON"

- "Lux" is activated

OK confirms the selection and switches to the display of the current measurement.

## Error messages

Error message	Cause	Remedy
Memory full	The memory is full	Clear memory
	Measuring range has not been reached	The measured values are outside the allowed measuring range. Switch resolution.
	Connection to the probe has been interrupted.	Please contact a Testo service point.



## Technical data

<b>Sensor:</b>	Silicon photodiode
<b>Meas. range:</b>	0 to 100,000 Lux
<b>Accuracy:</b>	To DIN 5032, Part 6 $f_1 = 8\%$ $f_1 = V(l)$ adaptation $f_2 = 5\%$ $f_2 = \cos$ like rating
<b>Resolution can be switched:</b>	0 to 32,000 Lux 1 Lux 0 to 100,000 Lux 10 Lux  0 to 3.200 fc 0,1 fc 0 to 10.000 fc 1 fc
<b>Display:</b>	2 line LCD and 2 matrix lines
<b>Battery lifetime:</b>	9 V IEC 6F22 > 50 h Al-Mn
<b>Battery check:</b>	Automatically in 4 stages
<b>Operating temperature:</b>	0 to +50 °C
<b>Storage temperature:</b>	-20 to +70 °C
<b>Dimensions:</b>	220 x 68 x 50 (instrument)
<b>Weight:</b>	500 g (incl. packaging)
<b>Warranty:</b>	2 years

## Ordering data

---

### Ordering data for testo 545

#### Measuring instrument and accessories

Part no.

#### **testo 545**

**0560.0545**

incl. probe, batteries and instruction manual **and calibration protocol**

---

#### **TopSafe (indestructible protective case)**

**0516.0441**

With bench stand and belt clip, protects measuring instrument from impact, dirt...

---

#### **Testo log printer, with 4 AA batteries and 1 roll of thermal paper**

**0554.0545**

Prints measured data, location with date and time

---

#### **Comfort software "Light" for data management**

**0554.0273**

with data base, analysis and graphics function

---

#### **Comfort software "Professional" for data management**

**0554.0274**

with data base, analysis and graphics function, data analysis, trend curve

---

#### **Transport case**

**0516.3250**

For safe storage of measuring instrument, TopSafe, probe and Testo log printer

---

#### **RS232 cable**

**0409.0178**

Connects measuring instrument ↔ PC for data transmission

---

#### **ISO calibration certificate**

**0520.0010**

Calibration point: 1000 Lux

---



The warranty time is

- 2 years for display instruments
- 1 year for probes.

Warranty services do not extend the warranty life.

If you have reason for complaint we will repair any faults free of charge if it can be proven that they are manufacturing faults. The fault should be reported immediately after it has been found and within the warranty time guaranteed by us.

Excluded are working parts such as rechargeable batteries, measuring cells, filters, measuring elements etc. as well as fragile parts. Also not included is damage caused by improper use and non-adherence to the instruction manual.

The warranty is also cancelled once the measuring instrument has been opened provided this is not described in the instruction manual for maintenance purposes. This is also the case if the serial numbers have been changed, damaged or removed.

If in addition to the warranty service necessary repairs, adjustments or similar are carried out, the warranty services are free of charge but there is a charge for the other services in addition to transport and packaging costs.

Other claims, especially those for damage occurring outside the instrument are not included unless responsibility is legally binding.

### **After-sales service after the warranty time has elapsed**

We are, of course, there for you after the warranty time has elapsed. In the case of function faults please send us your measuring instrument with a brief description of the defect. Include your telephone number should we need to contact you.

Testo's **CUSTOMER SERVICE** puts the customer first.