

---

**User's  
Manual**

**UTAdvanced.**

**UT32A  
Digital Indicating Controller  
(Entry Model)  
User's Manual**

IM 05P01F31-01EN

---

**vigilantplant.®**

# Product Registration

Thank you for purchasing YOKOGAWA products.

YOKOGAWA provides registered users with a variety of information and services. Please allow us to serve you best by completing the product registration form accessible from our homepage.

***<http://www.yokogawa.com/ns/reg/>***



## Introduction

Thank you for purchasing the UT32A digital indicating controller (Entry model) (hereinafter referred to as UT32A).

This manual describes how to use UT32A functions other than UT32A's communication function. Please read through this user's manual carefully before using the product.

Note that the manuals for the UT32A comprise the following seven documents:

- **Printed manual**

Manual Name	Manual Number	Description
UT32A Operation Guide «Entry Model»	IM 05P01F31-11EN	This manual describes the basic operation method.
Precautions on the Use of the UTAdvanced Series	IM 05P01A01-11EN	This manual is always delivered even if 'without manuals' was selected.

- **Electronic manuals**

Manual Name	Manual Number	Description
UT32A Operation Guide «Entry Model»	IM 05P01F31-11EN	This manual describes the basic operation method.
Precautions on the Use of the UTAdvanced Series	IM 05P01A01-11EN	This manual is always delivered even if 'without manuals' was selected.
UT32A User's Manual «Entry Model»	IM 05P01F31-01EN	This manual. It describes the usage of all functions except the communication functions.
UTAdvanced Series Communication Interface (RS-485, Ethernet) User's Manual	IM 05P07A01-01EN	This manual describes how to use UT32A in Ethernet and serial communications. For communication wiring, see the Operation Guide or User's Manual.
LL50A Parameter Setting Software Installation Manual	IM 05P05A01-01EN	This manual describes how to install and uninstall the LL50A.
LL50A Parameter Setting Software User's Manual	IM 05P05A01-02EN	This manual describes how to use the LL50A, ladder sequence function, peer-to-peer communication, and network profile creating function.

\* User's Manual can be downloaded from a website.

For details of the each function, refer to the electronic manual.  
User's manuals can be downloaded or viewed at the following URL.



<http://www.yokogawa.com/ns/ut/im/>

- **General specifications**

Title	General specifications No.
UT32A Digital Indicating Controller «Entry Model»	GS 05P01F31-01EN
LL50A Parameter Setting Software	GS 05P05A01-01EN

\* The last two characters of the manual number and general specification number indicate the language in which the manual is written.

- **Authorised Representative in the EEA**

Authorised Representative in the EEA

Yokogawa Europe BV. (Address: Euroweg 2 , 3825 HD Amersfoort, The Netherlands) is the Authorised Representative of Yokogawa Electric Corporation for this Product in the EEA.

## Target Readers

This guide is intended for the following personnel;

- Engineers responsible for installation, wiring, and maintenance of the equipment.
- Personnel responsible for normal daily operation of the equipment.

---

## Notice

- The contents of this manual are subject to change without notice as a result of continuing improvements to the instrument's performance and functions.
- Every effort has been made to ensure accuracy in the preparation of this manual. Should any errors or omissions come to your attention, however, please inform Yokogawa Electric's sales office or sales representative.
- Under no circumstances may the contents of this manual, in part or in whole, be transcribed or copied without our permission.

## Trademarks

- Our product names or brand names mentioned in this manual are the trademarks or registered trademarks of Yokogawa Electric Corporation (hereinafter referred to as YOKOGAWA).
- Microsoft, MS-DOS, Windows, Windows Vista, and Windows 7 are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Adobe, Acrobat, and Postscript are either registered trademarks or trademarks of Adobe Systems Incorporated.
- Modbus is a registered trademark of Schneider Electric.
- We do not use the TM or ® mark to indicate these trademarks or registered trademarks in this user's manual.
- All other product names mentioned in this user's manual are trademarks or registered trademarks of their respective companies.

## Safety Precautions

This instrument is a product of Installation Category II of IEC/EN/CSA/UL61010-1, IEC/EN61010-2-201, IEC/EN61010-2-030 Safety Standards and Class A of EN61326-1, EN55011 (EMC Standards).



---

### CAUTION

---

This instrument is an EMC class A product. In a domestic environment, this product may cause radio interference in which case the user needs to take adequate measures.

---

The instrument is a product rated Measurement Category O (other).

\* Measurement Category O (other)

This category applies to electric equipment that measures a circuit connected to a low-voltage facility and receives power from stationary equipment such as electric switchboards.

To use the instrument properly and safely, observe the safety precautions described in this user's manual when operating it. Use of the instrument in a manner not prescribed herein may compromise protection features inherent in the device. We assume no liability for or warranty on a fault caused by users' failure to observe these instructions.

This instrument is designed to be used within the scope of Measurement Category O (other) and is dedicated for indoor use.

---

### Notes on the User's Manual

- This user's manual should be readily accessible to the end users so it can be referred to easily. It should be kept in a safe place.
- Read the information contained in this manual thoroughly before operating the product.
- The purpose of this user's manual is not to warrant that the product is well suited to any particular purpose, but rather to describe the functional details of the product.

### Safety, Protection, and Modification of the Product

The following symbols are used in the product and user's manuals to indicate safety precautions:



"Handle with Care" (This symbol is attached to the part(s) of the product to indicate that the user's manual should be referred to in order to protect the operator and the instrument from harm.)



AC



AC/DC



The equipment wholly protected by double insulation or reinforced insulation.



Functional grounding terminal (Do not use this terminal as a protective grounding terminal.)

- In order to protect the system controlled by this product and the product itself, and to ensure safe operation, observe the safety precautions described in this user's manual. Use of the instrument in a manner not prescribed herein may compromise the product's functions and the protection features inherent in the device. We assume no liability for safety, or responsibility for the product's quality, performance or functionality should users fail to observe these instructions when operating the product.
- Installation of protection and/or safety circuits with respect to a lightning protector; protective equipment for the system controlled by the product and the product itself; foolproof or failsafe design of a process or line using the system controlled by the product or the product itself; and/or the design and installation of other protective and safety circuits are to be appropriately implemented as the customer deems necessary.
- Be sure to use the spare parts approved by YOKOGAWA when replacing parts or consumables.
- This product is not designed or manufactured to be used in critical applications that directly affect or threaten human lives. Such applications include nuclear power equipment, devices using radioactivity, railway facilities, aviation equipment, air navigation facilities, aviation facilities, and medical equipment. If so used, it is the user's responsibility to include in the system additional equipment and devices that ensure personnel safety.
- Modification of the product is strictly prohibited.
- This product is intended to be handled by skilled/trained personnel for electric devices.
- This product is UL Recognized Component. In order to comply with UL standards, end-products are necessary to be designed by those who have knowledge of the requirements.



## WARNING

- **Power Supply**  
Ensure that the instrument's supply voltage matches the voltage of the power supply before turning ON the power.
- **Do Not Use in an Explosive Atmosphere**  
Do not operate the instrument in locations with combustible or explosive gases or steam. Operation in such environments constitutes an extreme safety hazard. Use of the instrument in environments with high concentrations of corrosive gas (H<sub>2</sub>S, SO<sub>x</sub>, etc.) for extended periods of time may cause a failure.
- **Do Not Remove Internal Unit**  
The internal unit should not be removed by anyone other than YOKOGAWA's service personnel. There are dangerous high voltage parts inside. Additionally, do not replace the fuse by yourself.
- **Damage to the Protective Construction**  
Operation of the instrument in a manner not specified in this user's manual may damage its protective construction.

---

### Warning and Disclaimer

- YOKOGAWA makes no warranties regarding the product except those stated in the WARRANTY that is provided separately.
- The product is provided on an "as is" basis. YOKOGAWA assumes no liability to any person or entity for any loss or damage, direct or indirect, arising from the use of the product or from any unpredictable defect of the product.

### Notes on Software

- YOKOGAWA makes no warranties, either expressed or implied, with respect to the software's merchantability or suitability for any particular purpose, except as specified in the terms of the separately provided warranty.
- This software may be used on one specific machine only.
- To use the software on another machine, the software must be purchased again separately.
- It is strictly prohibited to reproduce the product except for backup purposes.
- Store the software CD-ROM (the original medium) in a safe place.
- All reverse-engineering operations, such as reverse compilation or the reverse assembly of the product are strictly prohibited.
- No part of the product's software may be transferred, converted, or sublet for use by any third party, without prior written consent from YOKOGAWA.

### Handling Precautions for the Main Unit

- The instrument comprises many plastic components. To clean it, wipe it with a soft, dry cloth. Do not use organic solvents such as benzene or thinner for cleaning, as discoloration or deformation may result.
- Keep electrically charged objects away from the signal terminals. Not doing so may cause the instrument to fail.
- Do not apply volatile chemicals to the display area, operation keys, etc. Do not leave the instrument in contact with rubber or PVC products for extended periods. Doing so may result in failure.
- If the equipment emits smoke or abnormal smells or makes unusual noises, turn OFF the instrument's power immediately and unplug the device. In such an event, contact your sales representative.

---

## Checking the Contents of the Package

Unpack the box and check the contents before using the product. If the product is different from that which you have ordered, if any parts or accessories are missing, or if the product appears to be damaged, contact your sales representative.

### **UT32A Main Unit**

The UT32A main units have nameplates affixed to the side of the case.

Check the model and suffix codes inscribed on the nameplate to confirm that the product received is that which was ordered.

### **No. (Instrument number)**

When contacting your sales representative, inform them of this number, too.



## Model and Suffix Codes of UT32A (for Entry Model)

Model	Suffix code	Optional suffix code	Description
<b>UT32A</b>			Digital Indicating Controller (Power supply: 100-240 V AC) (provided with 2 DOs)
Type 1:	-V		Voltage pulse output type
Basic control	-C		Current output type
	-R		Relay output type
Type 2:	0		None
Functions	1		RS-485 communication (Max. 38.4 kbps, 2-wire/4-wire)(*1)
Type 3: Fixed code	0		None
Display language (*2)	-1		English (Default. Can be switched to other language by the setting.)
	-2		German (Default. Can be switched to other language by the setting.)
	-3		French (Default. Can be switched to other language by the setting.)
	-4		Spanish (Default. Can be switched to other language by the setting.)
Case color	0		White (Light gray)
	1		Black (Light charcoal gray)
Fixed code	-00		Always "-00" (for Standard Code Model)
Optional suffix codes	/LP		24 V DC loop power supply
	/DC		Power supply 24 V AC/DC
	/CT		Coating (*3)
	/CV		Terminal cover

\*1: When the /LP option is specified, the RS-485 communication of the Type 2 code "1" is 2-wire system.

\*2: English, German, French, and Spanish are available for the guide display.

\*3: When the /CT option is specified, the UT32A does not conform to the safety standards (UL and CSA) and CE marking (Products with /CT option are not intended for EEA-market).

### Coating Treatment

#### (1)HumiSeal coating treatment

Apply HumiSeal coating to the printed circuit board assembly.

Do not apply HumiSeal coating to the following parts: connector, gold-plated contact area, relay part, RJC device, and in the vicinity of the push switch/LED lamp.

#### (2)Apply terminal coating to the gold-plated contact area on the printed circuit board.

#### Notes


- There are two treatments as described above, but we do not guarantee their effectiveness.

We do not supply any test data on these treatments.

- Do not apply any treatment to the screw terminal area on the back side of the instrument.

## Accessories

The product is provided with the following accessories according to the model and suffix codes. Check that none of them are missing or damaged.



No.	Product Name	Quantity	Remark
1	Brackets	2	Part number: L4502TP (For fixing the upper and lower parts)
2	Unit label	1	Part number: L4502VZ
3	Tag label	1	Part number: L4502VE (Only when ordered.)
4	Operation Guide	1	A3 size, x 6 (Standard model only)

### How to use the unit label

- Affixing the unit label
  - Affix the unit label to the front panel. If necessary, combine with unit prefixes. Affix it so that the LCD area is not blocked.
- Affixing the unit label to the UT32A
  - Affix the unit label over the letters "PV" on the front panel.
- Maintenance port seals
  - Maintenance port seals (two spares) are available. Use them if the seal affixed to the UTAdvanced controller loses its adhesiveness.
- TAG No. labels
  - TAG No. labels (two pieces) are available. Use them if necessary.

---

## Accessory (sold separately)

The following lists an accessory sold separately.


- LL50A Parameter Setting Software

Model	Suffix code	Description
LL50A	-00	Parameter Setting Software

- Terminal cover  
Model: UTAP002

- Resistance Module

Model	Suffix code	Description
X010	See the General Specifications (*)	Resistance Module



For UT32A

- Brackets  
Part number L4502TP (2 pieces for fixing the upper and lower parts)
- User's Manual (A4 size)  
\* User's Manual can be downloaded from a website.

---

## Symbols Used in This Manual



This symbol is used on the instrument. It indicates the possibility of injury to the user or damage to the instrument, and signifies that the user must refer to the user's manual for special instructions. The same symbol is used in the user's manual on pages that the user needs to refer to, together with the term "WARNING" or "CAUTION."

### **WARNING**

Calls attention to actions or conditions that could cause serious or fatal injury to the user, and indicates precautions that should be taken to prevent such occurrences.

### **CAUTION**

Calls attention to actions or conditions that could cause injury to the user or damage to the instrument or property and indicates precautions that should be taken to prevent such occurrences.

### **Note**

Identifies important information required to operate the instrument.



Indicates related operations or explanations for the user's reference.



Indicates a character string displayed on the display.

### **Setting Display**

Indicates a setting display and describes the keystrokes required to display the relevant setting display.

### **Setting Details**

Provides the descriptions of settings.

### **Description**

Describes restrictions etc. regarding a relevant operation.

---

## How to Use This Manual

For the ladder sequence and communication functions, see the respective manuals. This user's manual is organized into Chapters 1 to 18 as shown below.

Chapter	Title and Description
1	<b>Introduction to Functions</b> Describes the main functions of the UT32A.
2	<b>UT32A Operating Procedures</b> Describes the flow from unpacking to regular operations.
3	<b>Part Names</b> Describes part names and functions on the front panel.
4	<b>Basic Operation</b> Describes basic operation of the UT32A.
5	<b>Quick Setting Function</b> Describes the minimum necessary settings for operation.
6	<b>Monitoring and Control of Regular Operations</b> Describes monitoring displays of regular operations and operation.
7	<b>Input (PV) Functions</b> Describes PV input.
8	<b>Control Functions</b> Describes basic control and advanced control.
9	<b>Auxiliary Control Functions</b> Describes auxiliary control functions
10	<b>Control Output Functions</b> Describes output functions.
11	<b>Alarm Functions</b> Describes alarm output and status output.
12	<b>Contact Output Functions</b> Describes contact output functions.
13	<b>Display, Key, and Security Functions</b> Describes display, user function key and security functions.
14	<b>Parameter Initialization</b> Describes the initialization to factory default values and to user default values.
15	<b>Power Failure Recovery Processing/Power Frequency Setting/Other Settings</b> Describes operations performed after momentary power interruption and power failures.
16	<b>Troubleshooting, Maintenance, and Inspections</b> Describes troubleshooting, maintenance, periodic inspections, and disposal.
17	<b>Installation and Wiring</b> Describes installation and wiring.
18	<b>Parameters</b> Provides parameter maps.
GS	<b>Specifications</b> Provides the UT32A specifications.

# Contents

Introduction.....	i
Target Readers.....	i
Notice .....	ii
Trademarks .....	ii
Safety Precautions .....	ii
Handling Precautions for the Main Unit.....	iv
Checking the Contents of the Package.....	v
Model and Suffix Codes of UT32A (for Entry model).....	vi
Symbols Used in This Manual.....	ix
How to Use This Manual .....	x
<b>Chapter 1 Introduction to Functions</b>	
1.1 Quick Setting Function .....	1-1
1.2 Input/Output Function.....	1-2
1.3 Control Functions .....	1-3
1.4 Display and Key Functions.....	1-4
1.5 Communication Functions.....	1-5
1.6 Definition of Main Symbols and Terms .....	1-7
<b>Chapter 2 UT32A Operating Procedures</b>	
2.1 UT32A Operating Procedures .....	2-1
<b>Chapter 3 Part Names</b>	
3.1 Names and Functions of Display Parts .....	3-1
3.2 Names and Functions of Keys .....	3-2
3.3 List of Display Symbols .....	3-4
3.4 Brief Description of Setting Details (Parameters) .....	3-6
<b>Chapter 4 Basic Operation</b>	
4.1 Overview of Display Switch and Operation Keys .....	4-1
4.2 How to Set Parameters .....	4-4
<b>Chapter 5 Quick Setting Function</b>	
5.1 Setting Using Quick Setting Function.....	5-1
5.2 Restarting Quick Setting Function.....	5-6
<b>Chapter 6 Monitoring and Control of Regular Operations</b>	
6.1 Monitoring and Control of Operation Displays.....	6-1
6.1.1 Operation Display Transitions.....	6-1
6.2 Setting Target Setpoint .....	6-5
6.3 Performing and Canceling Auto-tuning.....	6-7
6.4 Adjusting PID Manually .....	6-10
6.5 Setting Alarm Setpoint.....	6-15
6.6 Selecting Target Setpoint Number (SPNO).....	6-16
6.7 Switching Operation Modes .....	6-17
6.7.1 Switching between AUTO and MAN .....	6-17
6.7.2 Switching between STOP and RUN .....	6-19
6.7.3 Switching between REM (Remote) and LCL (Local) .....	6-21
6.8 Manipulating Control Output during Manual Operation.....	6-22
6.9 Releasing On-State (Latch) of Alarm Output.....	6-23

## Chapter 7 Input (PV) Functions

7.1	Setting Functions of PV Input .....	7-1
7.1.1	Setting Input Type, Unit, Range, Scale, and Decimal Point Position .....	7-1
7.1.2	Setting Burnout Detection for Input .....	7-3
7.1.3	Setting Reference Junction Compensation (RJC) or External Reference Junction Compensation (ERJC) .....	7-4
7.1.4	Correcting Input Value .....	7-5
	(1) Setting Bias and Filter .....	7-5

## Chapter 8 Control Functions

8.1	Control Function Block Diagrams .....	8-1
8.1.1	Single-loop Control .....	8-1
8.2	Setting Control Type (CNT) .....	8-3
8.2.1	PID Control .....	8-4
8.2.2	ON/OFF Control (1 point of hysteresis / 2 points of hysteresis) .....	8-5
8.2.3	PD Control (Stable Control in Which a Setpoint is not Exceeded) .....	8-7
8.3	Setting PID Control Mode (ALG) .....	8-8
8.4	Switching PID .....	8-10
8.4.1	Switching PID According to Target Setpoint Number (SPNO) .....	8-10
8.4.2	Switching PID According to PV .....	8-11
8.4.3	Switching PID According to SP .....	8-13
8.4.4	Switching PID According to Target SP .....	8-15
8.4.5	Switching PID According to Deviation (Reference Deviation) .....	8-17
8.4.6	Setting Hysteresis at Time of PID Switch .....	8-18
8.5	Suppressing Overshoot (Super Function) .....	8-19
8.6	Suppressing Hunting (Super2 Function) .....	8-21
8.7	Suppressing Integral Action (Anti-reset Wind-up) .....	8-23
8.8	Adjusting Auto-tuning Operation .....	8-24

## Chapter 9 Auxiliary Control Functions

9.1	Setting SP Limiter .....	9-1
9.2	Changing SP at a Fixed Rate (SP Ramp-Rate Setting Function) .....	9-2
9.3	Forcing SP to Track PV (PV Tracking) .....	9-4
9.4	Forcing SP to Track Remote Input (SP Tracking) .....	9-5
9.5	Setting Controller Action at Power ON (Restart Mode) .....	9-6
9.6	Setting Time between Powering on Controller and Starting Control (Restart Timer) .....	9-7

## Chapter 10 Control Output Functions

10.1	Control Output Functions .....	10-1
10.2	Setting Control Output Cycle Time .....	10-2
10.3	Setting Limiter to Control Output .....	10-3
10.4	Disabling Output Limiter in MAN mode .....	10-4
10.5	Setting Velocity Limiter to Control Output .....	10-5
10.6	Reducing 4-20 mA Current Output to 0 mA (Tight Shut Function) .....	10-6
10.7	Setting ON/OFF Control Hysteresis .....	10-7
10.8	Canceling Offset of PV and SP (Manual Reset) .....	10-9
10.9	Setting Preset Output Value .....	10-10
10.9.1	Setting Output Value in STOP Mode (Preset Output) .....	10-10
10.9.2	Setting Output Value When Switched to MAN Mode (Manual Preset Output) .....	10-11
10.9.3	Setting Output Value When Error Occurs (Input Error Preset Output) .....	10-12
10.10	Changing Current Output Range .....	10-13

**Chapter 11 Alarm Functions**

11.1	Setting Alarm Type .....	11-1
11.2	Setting Number of Alarm Groups to Use .....	11-12
11.3	Setting Hysteresis to Alarm Operation .....	11-13
11.4	Delaying Alarm Output (Alarm Delay Timer) .....	11-14
11.5	Setting Alarm Action According to Operation Mode.....	11-15

**Chapter 12 Contact Output Functions**

12.1	Contact Output Functions.....	12-1
12.1.1	Setting Function of Contact Output.....	12-1
12.1.2	Changing Contact Type of Contact Output .....	12-4

**Chapter 13 Display, Key, and Security Functions**

13.1	Setting Display Functions.....	13-1
13.1.1	Setting Active Color PV Display Function .....	13-1
13.1.2	Masking Arbitrary Display Value in Operation Display .....	13-4
13.1.3	Registering SELECT Display (Up to 5 Displays) .....	13-5
13.1.4	Changing Event Display .....	13-6
13.1.5	Registering SELECT Parameter Display (Up to 10 Displays).....	13-7
13.1.6	Setting Bar-graph Display Function .....	13-9
13.1.7	Masking Least Significant Digit of PV Display .....	13-11
13.1.8	Setting Economy Mode.....	13-12
13.1.9	Selecting the Initial Operation Display that Appears at Power ON .....	13-12
13.1.10	Switching Guide Display Language .....	13-13
13.1.11	Changing Guide Scroll Speed .....	13-13
13.1.12	Turning Guide Display ON/OFF .....	13-13
13.1.13	Setting Automatic Return to Operation Display .....	13-14
13.1.14	Setting Brightness and Contrast Adjustment of LCD and Display Update Cycle.	13-14
13.2	Assigning Function to User Function Key and A/M Key .....	13-15
13.3	Setting Security Functions.....	13-18
13.3.1	Setting/canceling a Password.....	13-18
13.3.2	Setting Parameter Display Level .....	13-18
13.3.3	Locking (Hiding) Parameter Menu Display .....	13-19
13.3.4	Key Lock .....	13-20
13.3.5	Setting Display/Non-display of Operation Display .....	13-20
13.3.6	Prohibiting Writing via Communication .....	13-20
13.4	Confirmation of Key and I/O Condition and Version.....	13-21
13.4.1	Confirmation of Key and I/O Condition .....	13-21
13.4.2	Confirmation of Version .....	13-22

**Chapter 14 Parameter Initialization**

14.1	Initializing Parameter Settings to Factory Default Values.....	14-1
14.2	Registering and Initializing User Default Values.....	14-2
14.2.1	Registering as User Setting (Default) Values.....	14-2
14.2.2	Initializing to User Setting (Default) Values.....	14-2

**Chapter 15 Power Failure Recovery Processing / Power Frequency Setting / Other Settings**

15.1	Remedies if Power Failure Occurs during Operations .....	15-1
15.2	Power Frequency Setting .....	15-2



## Chapter 16 Troubleshooting, Maintenance, and Inspections

16.1	Troubleshooting.....	16-1
16.1.1	Troubleshooting Flowchart.....	16-1
16.1.2	Errors at Power On.....	16-2
16.1.3	Errors during Operation.....	16-4
16.2	Maintenance.....	16-13
16.2.1	Cleaning.....	16-13
16.2.2	Packaging when Shipping the Product for Repair.....	16-13
16.2.3	Replacing Parts.....	16-13
16.3	Periodic Maintenance.....	16-14
16.4	Disposal.....	16-15

## Chapter 17 Installation and Wiring

17.1	Installation Location.....	17-1
17.2	Mounting Method.....	17-3
17.3	External Dimensions and Panel Cutout Dimensions.....	17-4
17.4	Wiring.....	17-5
17.4.1	Important Information on Wiring.....	17-5
17.4.2	PV Input Wiring.....	17-7
17.4.3	Control Output (Relay, Current, and Voltage Pulse) Wiring.....	17-8
17.4.4	Contact Output Wiring.....	17-10
17.4.5	24 V DC Loop Power Supply Wiring.....	17-11
17.4.6	RS-485 Communication Interface Wiring.....	17-11
17.4.7	Coordinated Operation Wiring.....	17-13
17.4.8	Power Supply Wiring.....	17-15
17.5	Attaching and Detaching Terminal Cover.....	17-16

## Chapter 18 Parameters

18.1	Parameter Map.....	18-1
18.2	List of Parameters.....	18-8
18.2.1	Operation Parameters.....	18-8
18.2.2	Setup Parameters.....	18-13

## Revision Information

## 1.1 Quick Setting Function

The Quick setting function is a function to easily set the basic function of the controller.

Buy and  
Unpacking



Installation  
and Wiring



Setup



Operation



Check the contents.

Installation and Wiring: Chapter 17

Install and wire a controller, and then turn on the power.



Q: What should I do to perform control immediately?  
First, I want to set the input and output.

A: Use the Quick setting function to perform the  
setup easily.  
Quick setting function: Chapter 5

Q: How do I determine the PID?


A: Use Auto-tuning to perform the tuning easily.  
Auto-tuning: Section 6.3

## 1.2 Input/Output Function

### PV Input (equipped as standard)

PV input is a universal input to arbitrarily set the type and range for the thermocouple (TC), resistance-temperature detector (RTD), and DC voltage/current.


► Chapter 7 Input (PV) Functions



### Control Output (Depends on the model and suffix codes)

Output type depends on the model and suffix codes.

► Chapter 10 Control Output Functions




### Contact Output

2 contact outputs can be incorporated. Contact output can output events such as alarms.

### 24 V DC Loop Power Supply

24 V DC loop power supply can be supplied to 2-wire transmitter.

► 17.4.10 24 V DC Loop Power Supply Wiring




# 1.3 Control Functions

## PID Control

PID control is a general control using the PID control-related parameters.

▶ 8.2.1 PID Control




## 1.4 Display and Key Functions

Employing a 14-segment, active color LCD greatly increases the monitoring and operating capabilities.

### Active Color PV Display (display color change)


The active color PV display function changes the PV display color (red or white) when abnormality occurs in PV etc.

▶ [13.1.1 Setting Active Color PV Display Function](#)



### Guide Display

The guide is displayed on PV display when setting parameters. This guide can be turned on/off with the Fn key.



### Multilingual Guide Display

English, German, French, or Spanish can be displayed in Guide display.

▶ [13.1.11 Switching Guide Display Language](#)

### Parameter Display Level

To intended use of the operator, the display level of the parameter can be set.

▶ [Chapter 18 Parameters](#)

### User Function Keys

The UT32A has a user function key (Fn).

Assign a function to a user function key to use it as an exclusive key.

▶ [13.2 Assigning Function to User Function Key and A/M Key](#)


## 1.5 Communication Functions

The UT32A can use RS-485 communication by specifying the suffix code and optional suffix code for each communication.

► [UTAdvanced Series Communication Interface \(RS-485, Ethernet\) User's Manual](#)


### RS-485 Communication (Modbus communication, PC link communication, and Ladder communication)

The UT32A can communicate with PCs, PLCs, touch panels, and other devices.



### Coordinated Operation


A system of coordinated operation is configured with a master controller and a number of slave controllers. The slave controllers are set to operate in the same way as the master controller. Therefore you do not have to create a communication program.



### Light-loader Communication


Use the LL50A to set parameters and create ladder programs. Attach the adapter to the front of the controller to communicate.

- ▶ [Light-loader function: LL50A Parameter Setting Software User's Manual](#)



### Maintenance Port Communication (Power supply is not required for the UT32A)

Maintenance port is used to connect with the dedicated cable when using LL50A Parameter Setting Software (sold separately). The parameters can be set without supplying power to the UT32A.



---

### CAUTION

---

When using the maintenance port, do not supply power to the controller. Otherwise, the controller does not work normally.  
If power is supplied to the controller while the cable is connected, or the cable is connected to the controller already turned on, unplug the cable and turn on the controller again. The controller returns to the normal condition.

---

## 1.6 Definition of Main Symbols and Terms

### Main Symbol

PV: Measured input value  
 SP: Target setpoint  
 OUT: Control output value

A/M: AUTO/MAN  
 AUTO: Automatic  
 MAN: Manual  
 REMOTE, REM: Remote  
 LOCAL, LCL: Local

E1: Terminal areas  
 ► [17.4 Wiring](#)

### Engineering Units

Input range (scale): the PV range low limit is set to 0%, and the high limit is set to 100% for conversion.

Input range (scale) span: the PV range span is set to 100% for conversion.


In this manual, the parameter setting range is described as the “input range” and “input range span.” This means that engineering units are required to be set. Set a temperature for temperature input.

The following describes a conversion example.

When the PV input range is 100 to 600°C, 0% of the PV range is equivalent to 100°C, 50% of the PV range is equivalent to 350°C, and 100% of the PV range is equivalent to 600°C.

100% of the PV range span is equivalent to 500°C.

20% of the PV range span is equivalent to 100°C.




The above applies to the scale for voltage and current input.






# 2.1 UT32A Operating Procedures






### 3.1 Names and Functions of Display Parts



(2) + (3) + (4) : Setpoint display

No. in figure	Name	Description												
(1)	<b>PV display (white or red)</b>	Displays PV. Displays an error code if an error occurs. Displays the scrolling guide in the Menu Display and Parameter Setting Display when the guide display ON/OFF is set to ON.												
(2)	<b>Group display (green)</b>	Displays a group number (1 to 4, or R) and terminal area (E1). 1 to 4 represent SP numbers in the Operation Display. R and E1 to E4 are displayed in the Parameter Setting Display.												
(3)	<b>Symbol display (orange)</b>	Displays a parameter symbol.												
(4)	<b>Data display (orange)</b>	Displays a parameter setpoint and menu symbol.												
(5)	<b>Bar-graph display (orange)</b>	Displays control output value (OUT) and measured input value (PV). The data to be displayed can be set by the parameter. Initial value: deviation												
(6)	<b>Event indicator (orange)</b>	Lit when the alarms 1 to 4 occur. Event displays other than alarms can be set by the parameter.												
(7)	<b>Key navigation indicator (green)</b>	Lit or blinks when the Up/Down or Left/Right arrow key operation is possible.												
(8)	<b>Parameter display level indicator (green)</b>	Displays the setting conditions of the parameter display level function. <table border="1" style="width: 100%; margin-top: 5px;"> <thead> <tr> <th>Parameter display level</th> <th>EASY</th> <th>PRO</th> </tr> </thead> <tbody> <tr> <td>Easy setting mode</td> <td>Lit</td> <td>Unlit</td> </tr> <tr> <td>Standard setting mode</td> <td>Unlit</td> <td>Unlit</td> </tr> <tr> <td>Professional setting mode</td> <td>Unlit</td> <td>Lit</td> </tr> </tbody> </table>	Parameter display level	EASY	PRO	Easy setting mode	Lit	Unlit	Standard setting mode	Unlit	Unlit	Professional setting mode	Unlit	Lit
Parameter display level	EASY	PRO												
Easy setting mode	Lit	Unlit												
Standard setting mode	Unlit	Unlit												
Professional setting mode	Unlit	Lit												
(9)	<b>Status indicator (green and red)</b>	Displays the operating conditions and control status. <table border="1" style="width: 100%; margin-top: 5px;"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>REM</td> <td>Lit when in remote mode (REM).</td> </tr> <tr> <td>STOP</td> <td>Lit when in stop mode (STOP).</td> </tr> <tr> <td>MAN</td> <td>Lit when in manual mode (MAN). Blinks during auto-tuning.</td> </tr> </tbody> </table>	Display	Description	REM	Lit when in remote mode (REM).	STOP	Lit when in stop mode (STOP).	MAN	Lit when in manual mode (MAN). Blinks during auto-tuning.				
Display	Description													
REM	Lit when in remote mode (REM).													
STOP	Lit when in stop mode (STOP).													
MAN	Lit when in manual mode (MAN). Blinks during auto-tuning.													
(10)	<b>Security indicator (red)</b>	Lit if a password is set. The setup parameter settings are locked.												


## 3.2 Names and Functions of Keys



No. in figure	Name	Description
(1)	<b>DISP key</b>	Used to switch the Operation Displays. Press the key in the Operation Display to switch the provided Operation Displays. Press the key in the Menu Display or Parameter Setting Display to return to the Operation Display.
(2)	<b>PARA key</b>	Hold down the key for 3 seconds to move to the Operation Parameter Setting Display. Hold down the key and the Left arrow key simultaneously for 3 seconds to move to the Setup Parameter Setting Display. Press the key in the Parameter Setting Display to return to the Menu Display. Press the key once to cancel the parameter setting (setpoint is blinking).
(3)	<b>SET/ENTER key Up/Down/ Left/Right arrow keys</b>	<b>SET/ENTER key</b> Press the key in the Menu Display to move to the Parameter Setting Display of the Menu. Press the key in the Parameter Setting Display to transfer to the parameter setting mode (setpoint is blinking), and the parameter can be changed. Press the key during parameter setting mode to register the setpoint. <b>Up/Down/Left/Right arrow keys</b> Press the Left/Right arrow keys in the Menu Display to switch the Displays. Press the Up/Down/Left/Right arrow keys in the Parameter Setting Display to switch the Displays. Press the Up/Down arrow keys during parameter setting mode (setpoint is blinking) to change a setpoint. Press the Left/Right arrow keys during parameter setting mode (setpoint is blinking) to move between digits according to the parameter.
(4)	<b>Light-loader interface</b>	It is the communication interface to the adapter cable when setting and storing parameters via PC. The LL50A Parameter Setting Software (sold separately) is required.
(5)	<b>A/M key</b>	Used to switch between AUTO and MAN modes. The setting is switched between AUTO and MAN each time the key is pressed. The user can assign a function key.
(6)	<b>User function keys</b>	The UT32A has Fn key. The user can assign a function to the key. The function is set by the parameter.

**Maintenance Port (Power supply is not required for the UT32A).**

The maintenance port is used to connect with the dedicated cable when using LL50A Parameter Setting Software (sold separately). The parameters can be set without supplying power to the UT32A.

**CAUTION**


When using the maintenance port, do not supply power to the controller. Otherwise, the controller does not work normally.

If power is supplied to the controller while the cable is connected, or the cable is connected to the controller already turned on, unplug the cable and turn on the controller again. The controller returns to the normal condition.






### 3.3 List of Display Symbols

The following shows the parameter symbols, menu symbols, alphanumeric of guide, and symbols which are displayed on the UT32A.







Figure (common to all display area)

0 1 2 3 4 5 6 7 8 9  


PV display (14 segments): Alphabet

A B C D E F  
  
 G H I J K L  
  
 M N O P Q R  
  
 S T U V W X  
  
 Y Z  


Symbol display and Data display (11 segments): Alphabet

A B C D E F  
  
 C (lower-case)  
  
 G H I J K L  
  
 M N O P Q R  
  
 S T U V W X  
  
 Y Z  


Group display (7 segments): Alphabet

A	B	C	D	E	F
G	H	I	J	K	L
M	N	O	P	Q	R
S	T	U	V	W	X
					None
Y	Z				

PV display (14 segments): Symbol

Space	-	/	'	,



## 3.4 Brief Description of Setting Details (Parameters)

This manual describes the Setting Details as follows in addition to the functional Description.

### Setting Details

#### (Display Example)

Parameter symbol	Name	Display level	Setting range	Menu symbol
A1 to A4	Alarm-1 to -4 setpoint	EASY	Set a display value of setpoint of PV alarm, SP alarm, deviation alarm, output alarm, or velocity alarm. -19999 to 30000 (Set a value within the input range.) Decimal point position depends on the input type	SP <b>Ope</b>

(1) Parameter symbol: Symbol displayed on Symbol display on the front panel.

(2) Name: Parameter name

(3) Display level: Indicates the parameter display level.

(4) Setting range: Parameter setting range

(5) Menu symbol: Indicates the menu to which the parameter belongs.

**Ope**: Operation parameter

**Set**: Setup parameter

#### Parameter Display Level

Display level		Description
EASY	Easy setting mode: The minimum necessary parameters are displayed.	Corresponding parameters are displayed in all modes.
STD	Standard setting mode: The wider range of parameters than those shown in Easy setting mode are displayed.	Corresponding parameters are displayed only in Standard setting mode and Professional setting mode. Parameter display level indicators "EASY" and "PRO" are unlit in Standard setting mode. *: "STD" is the symbol used in this manual only.
PRO	Professional setting mode: All parameters are displayed.	Corresponding parameters are displayed only in Professional setting mode.

#### Note


For more intelligible display operation of parameters and the references, see Chapter 18, "Parameter Map."

# 4.1 Overview of Display Switch and Operation Keys

The following shows the transition of Operation Display, Operation Parameter Setting Display, and Setup Parameter Setting Display.

The "Operation Parameter Setting Display" has the parameters for setting the functions necessary for the operation.




The "Setup Parameter Setting Display" has the parameters for setting the basic functions of the controller.



#### 4.1 Overview of Display Switch and Operation Keys


The display pattern of the UT32A is as follows; the Menu Display and Parameter Setting Display.

For the Operation Display, see Chapter 6, "Monitoring and Control of Regular Operations."

Display	Description
<p><b>Menu Display</b></p>	<p>The Menu Display is segmented by the function and optional terminal position. The scrolling guide for the menu is displayed on PV display. The guide display can be turned on/off with the Fn key.</p> <p>Menu Display of Operation Parameter</p>  <p>The scrolling guide for the menu is displayed.</p> <p>OPE.M is displayed.</p> <p>Menu symbol is displayed.</p> <p>Group number or Terminal area is displayed.</p> <p>Menu Display of Setup Parameter</p>  <p>The scrolling guide for the menu is displayed.</p> <p>SET.M is displayed.</p> <p>Menu symbol is displayed.</p> <p>Group number or Terminal area is displayed.</p>
<p><b>Parameter Setting Display</b></p>	<p>The following is the Display for displaying and setting a parameter. The parameters have three types of display levels; Easy setting mode, Standard setting mode, and Professional setting mode. The parameters to be displayed can be limited according to the setting of the parameter display level. The scrolling guide for the parameter is displayed on PV display. The guide display can be turned on/off with the Fn key.</p> <p>Parameter Setting Display (Example of Operation Parameter Setting Display)</p>  <p>The scrolling guide for the parameter is displayed.</p> <p>Setpoint is displayed.</p> <p>Parameter symbol is displayed.</p> <p>Group number or Terminal area is displayed.</p>

**Display Shown at the End (the Lowest Level) of the Parameter Setting Display**

As shown in the figure below, the END Display is shown to indicate the end of the Menu Display and Parameter Setting Display. There are no setting items.

**Basic Key Operation Sequence**

- **To move to the Setup Parameter Setting Display**

Hold down the PARA key and the Left arrow key simultaneously for 3 seconds.



- **To move to the Operation Parameter Setting Display**

Hold down the PARA key for 3 seconds.



- **To move to the Operation Display**

Press the DISP key once.



## 4.2 How to Set Parameters

The following operating procedure describes an example of setting alarm setpoint (A1).

### Operation

1. Hold down the **PARA** key for 3 seconds in the Operation Display to call up the **[MODE]** Menu Display.



2. Press the **Right arrow** key to display the **[SP]** Menu Display.



3. Press the **SET/ENTER** key to display the **[SP]** Parameter Setting Display.



4. Press the **Down arrow** key to display the **[A1]** Parameter Setting Display.



5. Press the **SET/ENTER** key to blink the setpoint.



6. Press the **Up** or **Down arrow** key to change the setpoint.  
(Change the setpoint using the Up/Down arrow keys to increase and decrease the value and the Left/Right arrow keys to move between digits.)



7. Press the **SET/ENTER** key to register the setpoint (the setpoint stops blinking).



8. Press the **PARA** key once to return to the Menu Display. Press the **DISP** key once to return to the Operation Display.

This completes the setting procedure.

### How to Cancel Parameter Setting

To cancel parameter setting when a parameter is being set (setpoint is blinking), press the **PARA** key once.

## How to Set Parameter Setpoint

### Numeric Value Setting



1. Display the Parameter Setting Display.



2. Press the SET/ENTER key to move to the setting mode (the setpoint blinks).



3. Press the Left arrow key to move one digit to the left. (Press the Right arrow key to move one digit to the right.)



4. Press the Up or Down arrow key to change the setpoint. Press the Up arrow key when 9 is displayed to move one digit to the left. Press the Down arrow key when 0 is displayed to move one digit to the right.



5. Press the SET/ENTER key to register the setpoint.

### Selection Data Setting



1. Display the Parameter Setting Display.



2. Press the SET/ENTER key to move to the setting mode (the setpoint blinks).



3. Press the Up arrow key to change the setpoint (press the Down arrow key to change the setpoint).



4. Press the SET/ENTER key to register the setpoint.

## Time (minute.second) Setting



Example of 17 minutes 59 seconds



1. Display the Parameter Setting Display.



2. Press the SET/ENTER key to move to the setting mode (the setpoint blinks).



3. Press the Left arrow key to move one digit to the left. (press the Right arrow key to move one digit to the right.)



4. Press the Up or Down arrow key to change the setpoint. Press the Up arrow key when 5 is displayed to move one digit to the left. Press the Down arrow key when 0 is displayed to move one digit to the right.



5. Press the SET/ENTER key to register the setpoint.



---

Blank Page

## 5.1 Setting Using Quick Setting Function

### Description


The Quick setting function is a function to easily set the basic function of the controller. The Quick setting function starts when the power is turned on after wiring.

The following lists the items to set using the Quick setting function.

- (1) Control type (PID control, ON/OFF control.)
- (2) Input function (PV input, range, scale (at voltage/current input), etc.)
- (3) Output function (cycle time)

## 5.1 Setting Using Quick Setting Function

### Flowchart of Quick Setting Function



**Setting Example**

Set the following parameters to set to PID control, thermocouple Type K (range: 0.0 to 500.0°C), and current control output. No need to change the parameters other than the following parameters.

Set QSM = YES to enter the quick setting mode.

- (1) Set CNT = PID.
- (2) Set IN = K1.
- (3) Set UNIT = C (initial value).
- (4) Set RH = 500.0.
- (5) Set RL = 0.0.

Set EXIT = YES to quit the quick setting mode.  
The Operation Display is shown.

**Setting Details****Control Type**

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>CNT</b>	Control type	EASY	PID: PID control ONOF: ON/OFF control (1 point of hysteresis) ONOF2: ON/OFF control (2 points of hysteresis)	CTL <b>Set</b>

▶ [Control type: 8.2 Setting Control Type \(CNT\)](#)

## 5.1 Setting Using Quick Setting Function

### Input Function

Parameter symbol	Name	Display level	Setting range	Menu symbol
IN	PV input type	EASY	OFF: Disable K1: -270.0 to 1370.0 °C / -450.0 to 2500.0 °F K2: -270.0 to 1000.0 °C / -450.0 to 2300.0 °F K3: -200.0 to 500.0 °C / -200.0 to 1000.0 °F J: -200.0 to 1200.0 °C / -300.0 to 2300.0 °F T1: -270.0 to 400.0 °C / -450.0 to 750.0 °F T2: 0.0 to 400.0 °C / -200.0 to 750.0 °F B: 0.0 to 1800.0 °C / 32 to 3300 °F S: 0.0 to 1700.0 °C / 32 to 3100 °F R: 0.0 to 1700.0 °C / 32 to 3100 °F N: -200.0 to 1300.0 °C / -300.0 to 2400.0 °F E: -270.0 to 1000.0 °C / -450.0 to 1800.0 °F L: -200.0 to 900.0 °C / -300.0 to 1600.0 °F U1: -200.0 to 400.0 °C / -300.0 to 750.0 °F U2: 0.0 to 400.0 °C / -200.0 to 1000.0 °F W: 0.0 to 2300.0 °C / 32 to 4200 °F PL2: 0.0 to 1390.0 °C / 32.0 to 2500.0 °F P2040: 0.0 to 1900.0 °C / 32 to 3400 °F WRE: 0.0 to 2000.0 °C / 32 to 3600 °F JPT1: -200.0 to 500.0 °C / -300.0 to 1000.0 °F JPT2: -150.0 to 150.0 °C / -200.0 to 300.0 °F PT1: -200.0 to 850.0 °C / -300.0 to 1560.0 °F PT2: -200.0 to 500.0 °C / -300.0 to 1000.0 °F PT3: -150.0 to 150.0 °C / -200.0 to 300.0 °F 0.4-2V: 0.400 to 2.000 V 1-5V: 1.000 to 5.000 V 4-20: 4.00 to 20.00 mA 0-2V: 0.000 to 2.000 V 0-10V: 0.00 to 10.00 V 0-20 : 0.00 to 20.00 mA -1020: -10.00 to 20.00 mV 0-100: 0.0 to 100.0 mV	PV <b>Set</b>
UNIT	PV input unit	EASY	-: No unit C: Degree Celsius -: No unit - -: No unit - - -: No unit F: Degree Fahrenheit	
RH	Maximum value of PV input range	EASY	Depends on the input type. - For temperature input - Set the temperature range that is actually controlled. (RL<RH)	
RL	Minimum value of PV input range	EASY	- For voltage / current input - Set the range of a voltage / current signal that is applied. The scale across which the voltage / current signal is actually controlled should be set using the maximum value of input scale (SH) and minimum value of input scale (SL). (Input is always 0% when RL=RH.)	

Note1: W:W-5% Re/W-26% Re(Hoskins Mfg. Co.). ASTM E988  
 WRE: W97Re3-W75Re25

## Input Function (Continued)

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>SDP</b>	PV input scale decimal point position	EASY	0: No decimal place 1: One decimal place 2: Two decimal places 3: Three decimal places 4: Four decimal places	PV <b>Set</b>
<b>SH</b>	Maximum value of PV input scale	EASY	-19999 to 30000, (SL<SH),   SH - SL   ≤ 30000	
<b>SL</b>	Minimum value of PV input scale	EASY		

▶ Input setting: 7.1 Setting Functions of PV Input

## Output Function

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>CT</b>	Control output cycle time	EASY	0.5 to 1000.0 s	OUT <b>Set</b>

▶ Output type: 10.1 Setting Control Output Type

## 5.2 Restarting Quick Setting Function

Once functions have been built using the Quick setting function, the Quick setting function does not start even when the power is turned on. The following methods can be used to restart the Quick setting function.

- Set the parameter QSM (Quick setting mode) to ON and turn on the power again.
- Set the parameter IN (PV input type) to OFF and turn on the power again.

### CAUTION

The parameters related to the range or scale are initialized if the PV input type is changed.


#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>IN</b>	PV input type	EASY	OFF: Disable	PV <b>Set</b>
<b>QSM</b>	Quick setting mode	EASY	OFF: Disable ON: Enable	SYS <b>Set</b>

# 6.1 Monitoring and Control of Operation Displays

## 6.1.1 Operation Display Transitions.

- ▶ Display/Non-display of Operation Display: 13.3.5 Setting Display/Non-display of Operation Display
- ▶ Registration of SELECT Display: 13.1.3 Registering SELECT Display (Up to 5 displays)








## 6.1 Monitoring and Control of Operation Displays



### Details of the Operation Display

The following is the Operation Display types and each display and operation description.





Operation Display	Display and operation description
<p><b>SP Display</b></p>	<p>PV display: Displays measured input value (PV).            Setpoint display: Displays and changes target setpoint (SP).</p>  <p>Target setpoint Symbol            Target setpoint (SP) number</p> <p>The Display is switched to the SP Display if the operation mode is switched to AUTO, LCL, or REM when other Operation Display is shown.</p> <p><b>[SP Change Operation]</b>            (1) Press the SET/ENTER key to move to the setting mode (the setpoint blinks).            (2) Use the Left or Right arrow key to move between digits (the setpoint blinks).            (3) Use the UP or Down arrow key to change the value (the setpoint blinks).            (4) Press the SET/ENTER key to register the setpoint. (the setpoint stops blinking).            * Only Up or Down arrow key operation is also possible.</p> <p>When the operation mode is remote (REM lamp is lit):</p>  <p>Remote setpoint Symbol            Target setpoint (SP) number in LOCAL mode</p>

(Continued)

Operation Display	Display and operation description
<p><b>OUT Display</b></p>	<p>PV display: Displays measured input value (PV).                      Setpoint display: Displays control output value and changes control output value in MAN mode.</p>  <p>Control output                      Symbol                      Target setpoint (SP) number</p> <p>The Display is switched to the OUT Display if the operation mode is switched to MAN when other Operation Display is shown.                      The Display is switched to the OUT Display while auto-tuning is performed.</p> <p><b>[OUT Change Operation]</b>                      The control output value can be changed with the Up or Down arrow key in MAN mode (MAN lamp is lit).                      The control output value is changed by direct operation (without pressing the SET/ENTER key), and cannot be changed by moving between digits using the Left and Right arrow keys.</p>
<p><b>PID Number Display</b></p>	<p>PV display: Displays measured input value (PV).                      Setpoint display: Displays PID number currently being used.</p>  <p>PID number                      Symbol                      Target setpoint (SP) number</p>

**6.1 Monitoring and Control of Operation Displays**


(Continued)

Operation Display	Display and operation description
<p><b>Analog Input Display</b></p>	<p>PV display: Displays measured input value (PV).                      Setpoint display: Displays PV analog input value.</p> <p>PV analog input value</p>  <p>The screenshot shows a digital display with a black background and yellow characters. At the top left, there is a green exclamation mark icon. To its right, the letters 'PV' are displayed in a large font. Below 'PV', the number '1750' is displayed in a slightly smaller font. Three red lines with dots at the end point to specific elements: one points to the 'PV' text (labeled 'Symbol'), one points to the '1750' text (labeled 'PV input'), and one points to the right side of the display area (labeled 'Target setpoint (SP) number').</p>
<p><b>SELECT Display</b></p>	<p>SELECT Display is for registering frequently-used parameters from Parameter Setting Display, and for displaying them on Operation Display so that the parameter settings can be easily changed in normal operation.</p> <p>PV display: Displays measured input value (PV).                      Setpoint display: Displays and changes the registered parameter.</p> <p>The following is the display example when the parameter A1 (alarm-1 setpoint) is registered.</p>  <p>The screenshot shows a digital display with a black background and yellow characters. At the top left, there is a green exclamation mark icon. To its right, the letters 'A1' are displayed in a large font. Below 'A1', the number '1250' is displayed in a slightly smaller font. Three red lines with dots at the end point to specific elements: one points to the 'A1' text (labeled 'Symbol'), one points to the '1250' text (labeled 'Alarm setpoint'), and one points to the right side of the display area (labeled 'Target setpoint (SP) number').</p>

## 6.2 Setting Target Setpoint

### Operation in the Operation Display

#### Operation



1. Bring the SP Display into view.
2. Press the SET/ENTER key to move to the setting mode (the setpoint blinks).
3. Press the Left arrow key to move one digit to the left. (Press the Right arrow key to move one digit to the right.)
4. Press the Up or Down arrow key to change a setpoint. Press the Up arrow key when 9 is displayed to move one digit to the left. Press the Down arrow key when 0 is displayed to move one digit to the right.
5. Press the SET/ENTER key to register the setpoint. Control with the new setpoint.

## 6.2 Setting Target Setpoint

### Operation in Parameter Setting Display

#### Setting Display

Parameter Setting Display Operation Display > **PARA** key for **3 seconds** (to [MODE] Menu Display) > **Right arrow** key (to [SP] Menu Display) > **SET/ENTER** key (The setting parameter is displayed.)



Press the Right arrow key until the [SP] Menu Display appears.

In the Setting Display for the target setpoint parameter, pressing the Left or Right arrow keys changes the group. (The group number is displayed on Group display.)

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>SP</b>	Target setpoint	EASY	0.0 to 100.0% of PV input range (EU) (Setting range: SPL to SPH)	SP <b>Open</b>
<b>SPGR.</b>	Number of SP groups	STD	1 to 4	CTL <b>Set</b>

Note1: If the SP limiter is set, the setting can be made within the range of the SP limiter.

#### Description

The controller has four target setpoints (SP).

- ▶ [SP limiter: 9.1 Setting SP Limiter](#)
- ▶ [SELECT parameter: 13.1.5 Registering SELECT Parameter Display \(Up to 10 Displays\)](#)

## 6.3 Performing and Canceling Auto-tuning

### Setting Display

Operation Mode Setting Display    Operation Display > **PARA** key for **3 seconds** (to [MODE] Menu Display) > **SET/ENTER** key (The operation mode is displayed.) > **Down arrow** key (The operation mode is displayed.)



The parameter AT is displayed when the operation mode is AUTO.

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
AT	AUTO-tuning switch	EASY	OFF: Disable 1: Perform auto-tuning. Tuning result is stored in the PID of group 1. 2: Perform auto-tuning. Tuning result is stored in the PID of group 2. 3: Perform auto-tuning. Tuning result is stored in the PID of group 3. 4: Perform auto-tuning. Tuning result is stored in the PID of group 4. R: Tuning result is stored in the PID for reference deviation.	MODE <b>Ope</b>
AT.BS	SP bias in auto-tuning	PRO	-100.0 to 100.0% of PV input range span (EUS)	TUNE <b>Ope</b>

### CAUTION

Set the operation mode to AUTO and RUN to perform auto-tuning.

### Lamp Status

Status	STOP lamp	MAN lamp
During auto-tuning	Unlit	Blinking

### 6.3 Performing and Canceling Auto-tuning

#### Description


Auto-tuning is a function with which the controller automatically measures the process characteristics and sets PID constants, which are control-related parameters, to optimum values for the setpoint. Auto-tuning temporarily executes ON/OFF control, calculates appropriate PID constants from response data obtained, and sets these constants.

#### CAUTION


Do not perform auto-tuning for the following processes.

Tune PID manually.

- Processes with fast response such as flow rate control and pressure control.
- Processes which do not allow the output to be turned on and off even temporarily.
- Processes which prohibit output changes at control valves (or other actuators).
- Processes in which product quality can be adversely affected if PV values fluctuate beyond their allowable ranges.



#### When SP bias in auto-tuning is set



**Tuning Point and Storage Location of Tuning Results**

The tuning point when performing auto-tuning is the target setpoint that is currently used for control computation.

PID constants after the tuning are stored in the PID group that is specified when performing auto-tuning.

Operation mode	AT setpoint	Tuning point	Storage location
Local	1 to 4, R	Setpoint that is currently used	P, I, and D of the PID group specified in AT.
Remote	1 to 4, R	Remote setpoint	P, I, and D of the PID group specified in AT.

When the setpoint of AT is "R," the AT result is stored in the PID group for reference deviation.

When performing auto-tuning in AT setpoint "R", set the parameter ZON to other than 0 and 3, and set the parameter RDV to other than 0.

Auto-tuning cannot be performed when the control type (CNT) is as follows.

- ON/OFF control (1 point of hysteresis)
- ON/OFF control (2 points of hysteresis)

In addition, auto-tuning cannot be performed in the following cases (no error indication).

- Input error occurs. (Input burnout, ADC error, etc.)
- The operation mode is STOP.
- The operation mode is MAN.
- Output limiter setpoint at auto-tuning:  $AT.OL \geq AT.OH$

**Start and Stop of Auto-tuning**

Start and stop of auto-tuning can be set by parameter setting, or.

Auto-tuning is stopped in the following cases.

- Switch to MAN
- Switch to STOP
- The parameter AT is set to OFF.
- Power failure
- Auto-tuning is not finished even after the time-out detection time is elapsed.

The time-out detection time is about 24 hours.

When the auto-tuning error occurs, the error code is shown in the Operation Display. Press any key to erase it.

- ▶ [Auto-tuning time output limiter: 8.8 Adjusting Auto-tuning Operation](#)



## 6.4 Adjusting PID Manually

### Setting Display

Parameter Setting Display Operation Display > **PARA** key for **3 seconds** (to [MODE] Menu Display) > **Right arrow** key (to [PID] Menu Display) > **SET/ENTER** key (The setting parameter is displayed.) > **Down arrow** key (The setting parameter is displayed.)



In the Setting Display for the PID parameters, Displays can be arbitrarily switched using the Up, Down, Left or Right arrow key. Pressing the Left or Right arrow key changes the group. (The group number is displayed on Group display.)

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>P</b>	Proportional band	EASY	0.0 to 999.9% When 0.0% is set, it operates as 0.1%.	PID <b>Ope</b>
<b>I</b>	Integral time	EASY	OFF: Disable 1 to 6000 s	
<b>D</b>	Derivative time	EASY	OFF: Disable 1 to 6000 s	
<b>PIDN</b>	PID number selection	EASY	1 to 4	SP <b>Ope</b>
<b>PIDG.</b>	Number of PID groups	STD	1 to 4	CTL <b>Set</b>

#### Note

When changing the setpoint of the parameter PIDG., if the setpoint of the parameter PIDN which belongs to the SP menu is larger than that of the parameter PIDG., the PIDN setpoint is changed to the PIDG. setpoint.

There are four groups of PID parameters.

The PID parameters can be selected by using the following two methods:

#### (1) SP group number selection

The PID group which is set in the PID number selection (PIDN) of each SP group is used.

SP number (SPNO)	Target setpoint (SP)	Setting range of PID number selection (PIDN)
1	SP	1 to 4
2	SP	1 to 4
3	SP	1 to 4
4	SP	1 to 4

When the SP parameter is displayed, the SP number is shown on Group display.

When the PID parameters are displayed, the PID number is shown on Group display.

▶ Selection by keystroke: 6.6 Selecting Target Setpoint Number (SPNO)


#### (2) Zone PID selection

▶ Selection by each Zone: 8.4 Switching PID

**Description**


**Description and Tuning of Proportional Band**

The proportional band is defined as the amount of change in input (or deviation), as a percent of span, required to cause the control output to change from 0% to 100%. Because a narrower proportional band gives greater output change for any given deviation, it therefore also makes the control performance more susceptible to oscillation. At the same time, a narrower proportional band reduces the offset. Reducing the proportional band to its smallest limit (proportional band = 0%) results in ON/OFF control.



To fine-tune a proportional band obtained using auto-tuning, or to manually tune the proportional band:

- Work from larger to smaller numbers (wider to narrower).
- If cycling appears, that means that the proportional band is too narrow.
- Proportional band tuning cannot cancel an offset.




► Offset: 10.8 Canceling Offset of PV and SP (Manual Reset)

### Description and Tuning of Integral Time

The integral action (I action) is a function that will automatically diminish the offset (steady-state deviation) that is inherently unavoidable with proportional action alone. The integral action continuously increases or decreases the output in proportion to the time integral of the deviation (the product of the deviation and the time that the deviation continues.)


The integral action is normally used together with proportional action as proportional-plus-integral action (PI action).

The integral time (I) is defined as the time required to develop, when a stepwise change in deviation is imposed, an output change due to integral action that is exactly equal to the change due to proportional action. The longer the integral time set, the slower the change in output; the smaller the time, the faster the output changes.



To manually tune the integral time

- The main goal is to reduce the offset.
- Adjust from longer time to shorter time.
- If you see an oscillation at a longer period than that seen when the proportional band is too narrow, then you have made the integral time too short.



Use the manual reset (MR) to cancel an offset when the integral action is disabled.

- ▶ [Manual reset: 10.8 Canceling Offset of PV and SP \(Manual Reset\)](#)


### Description and Tuning of Derivative Time

If the control object has a large time constant or dead time, the corrective action will be too slow with proportional action or proportional-plus-integral action alone, causing overshoot. However, even just sensing whether the deviation is on an increasing or a decreasing trend and adding some early corrective action can improve the controllability. Thus the derivative action (D action) is action that changes the output in proportion to the deviation derivative value (rate-of-change).

The derivative time is defined as the time required with PD action to develop, when a constant-slope change in deviation is imposed, an output change due to derivative action that is exactly equal to the change due to proportional action.

$$\text{Output} = \frac{100}{P} \left( e + T_D \frac{d}{dt} e \right)$$

e : Deviation  
T<sub>D</sub>: Derivative time




To manually tune the derivative time

- Adjust from shorter time to longer time.
- If you see a short-period oscillation, the time is too long.

The longer the derivative time set, the stronger the corrective action, and the more likely the output will become oscillatory. Oscillations due to derivative action are characterized by a short period.

D = OFF should always be used when controlling fast-responding inputs such as pressure and flow rate, or inputs characterized by rapid fluctuation, such as optical sensors.



### Manual PID Tuning Procedure

- (1) In principle, auto-tuning must be used.
- (2) Tune PID parameters in the order of P, I, and D. Adjust a numeric slowly by observing the result, and keep notes of what the progress is.
- (3) Gradually reduce P from a larger value. When the PV value begins to oscillate, stop tuning and increase the value somewhat.
- (4) Also gradually reduce I from a larger value. When the PV value begins to oscillate (with long period), stop tuning and increase the value somewhat.
- (5) Gradually increase D from a smaller value. When the PV value begins to oscillate (with short period), stop tuning and lower the value slightly.

#### Reference Values for Manual Tuning of Temperature, Pressure, and Flow Rate

		Setting range (reference)	Initial value for tuning (reference)
Pressure	P	100 to 300%	200%
	I	5 to 30 s	15 s
	D	OFF	OFF
Flow rate	P	100 to 240%	150%
	I	8 to 30 s	20 s
	D	OFF	OFF
Temperature (electric furnace)	P	1 to 20%	5%
	I	180 to 600 s	240 s
	D	1/4 to 1/6 of I	60 s

## 6.5 Setting Alarm Setpoint

### Setting Display

Parameter Setting Display Operation Display > **PARA** key for **3 seconds** (to [MODE] Menu Display) > **Right arrow** key (to [SP] Menu Display) > **SET/ENTER** key (The setting parameter is displayed.) > **Down arrow** key (The setting parameter is displayed.)



In the setting Display for the alarm parameters, Displays can be arbitrarily switched using the Up, Down, Left or Right arrow key. Pressing the Left or Right arrow key changes the group. (The group number is displayed on Group display.)

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>A1 to A4</b>	Alarm-1 to -4 setpoint	EASY	Set a display value of setpoint of PV alarm, SP alarm, deviation alarm, output alarm, or velocity alarm. -19999 to 30000 (Set a value within the input range.) Decimal point position depends on the input type	SP <b>Ope</b>
<b>ALNO.</b>	Number of alarms	PRO	0 to 4	CTL <b>Set</b>

Note:1 When the alarm setpoint parameter is displayed, the group number is shown on Group display.

Note2: The initial value of the parameter ALNO. is "4." Four alarm setpoint parameters are displayed for each SP group.

### Description

Each alarm type has four alarm setpoints.

Specifying the SP number (SPNO) determines the alarm setpoint to be used.

Alarm-related parameter	Number of settings
Alarm type	4 (number of settings)
PV velocity alarm time setpoint	4 (number of settings)
Alarm hysteresis	4 (number of settings)
Alarm delay timer	4 (number of settings)
Alarm setpoint	4 (number of settings) x 4 (number of groups)

▶ Alarm type: Chapter 11 Alarm Functions

## 6.6 Selecting Target Setpoint Number (SPNO)

### Setting Display

Parameter Setting Display Operation Display > **PARA** key for **3 seconds** (to [MODE] Menu Display) > **SET/ENTER** key (The setting parameter is displayed.) > **Down arrow** key (The setting parameter is displayed.)



### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>SPNO.</b>	SP number selection	EASY	1 to 4 (Depends on the setup parameter SPGR. setting.)	MODE <b>Ope</b>
<b>SPGR.</b>	Number of SP groups	STD	1 to 4	CTL <b>Set</b>

### Description

The SP number (SPNO) selection can be used when the parameter ZON (zone PID selection) is set to "SP group number selection."

#### SP Group Number Selection

The PID group which is set in the PID number selection (PIDN) of each SP group is used.

SP number (SPNO)	Target setpoint (SP)	Setting range of PID number selection (PIDN)
1	SP	1 to 4
2	SP	1 to 4
3	SP	1 to 4
4	SP	1 to 4


When the SP parameter is displayed, the SP number is shown on Group display.

## 6.7 Switching Operation Modes

### 6.7.1 Switching between AUTO and MAN

Direct Operation by A/M Key


#### Operation



#### Description

AUTO/MAN switching can be performed by any of the following:

- (1) A/M key
- (2) Communication
- (3) User function key



- ▶ Switch by user function key: [13.2 Assigning Function to User Function Key and A/M key](#)

Switch	Output action
AUTO→MAN	Holds the control output value from AUTO mode. The control output value can be bump to the manual preset output value by the setting of parameter MPO. The output value can be changed in manual mode.
MAN→AUTO	The control output value does not bump (bumpless). Does not work when Integral time (I) = OFF.

- ▶ Switch from AUTO to MAN, and MPON: [10.12.2 Setting Output Value When Switched to MAN Mode \(Manual Preset Output\)](#)



## 6.7 Switching Operation Modes

---

### Operation Display in AUTO and MAN Modes

“OUT” is displayed on Symbol display and “Output value” is displayed on Data display in MAN mode. (The OUT Display is shown.)



SP Display is shown in AUTO mode.



### Lamp Status

Status	MAN lamp
Automatic operation (AUTO)	Unlit
Manual operation (MAN)	Lit

## 6.7.2 Switching between STOP and RUN

## Setting Display

Operation Mode Setting Display Operation Display > **PARA** key for **3 seconds** (to [MODE] Menu Display) > **SET/ENTER** key (The operation mode is displayed.) > **Down arrow** key (The operation mode is displayed.)




## Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>S.R</b>	STOP/RUN switch	EASY	STOP: Stop mode RUN: Run mode	MODE <b>Ope</b>

## Description


STOP/RUN switching can be performed by any of the following:

- (1) Parameter
- (2) Communication
- (3) User function key



► Switch by user function key: 13.2 Assigning Function to User Function Key and A/M key

Switch	Output action
RUN→STOP	The control output bumps.
STOP→RUN	The control output does not bump (bumpless).



► Preset output value: 10.12.1 Setting Output Value in STOP Mode (Preset Output)

## 6.7 Switching Operation Modes

---

### Operation Display in STOP and RUN Modes

“STOP” is displayed on Symbol display and “Output value” is displayed on Data display in STOP mode. Preset output value is displayed.



The display at operation start differs depending on AUTO or MAN mode. SP Display is shown in AUTO mode and OUT Display is shown in MAN mode.

### SP Display



### OUT Display



### Lamp Status

Status	STOP lamp
Operation start (RUN)	Unlit
Operation Stop (STOP)	Lit

### 6.7.3 Switching between REM (Remote) and LCL (Local)

#### Setting Display

Operation Mode Setting Display Operation Display > **PARA** key for **3 seconds** (to [MODE] Menu Display) > **SET/ENTER** key (The operation mode is displayed.) > **Down arrow** key (The operation mode is displayed.)



The parameter R.L is displayed when the the communication is specified.


#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
R.L	REMOTE/LOCAL switch	EASY	LCL: Local mode REM: Remote mode	MODE <b>Ope</b>

#### Description

REMOTE/LOCAL switching can be performed by any of the following:

- (1) Parameter
- (2) Communication
- (3) User function key



- ▶ Switch by user function key: [13.2 Assigning Function to User Function Key and A/M key](#)

The PID group before switching from LOCAL to REMOTE is applied to the PID in remote operation.

#### SP Action in REM/LCL Switch

Switch	SP action
LCL→REM	The local target setpoint bumps to the remote target setpoint.
REM→LCL	The remote target setpoint bumps to the local target setpoint. Or forces the local target setpoint to track the remote target setpoint.


- ▶ Tracking: [9.4 Forcing SP to Track Remote Input \(SP Tracking\)](#)

#### Lamp Status

Status	REM lamp
Local (LCL)	Unlit
Remote (REM)	Lit

## 6.8 Manipulating Control Output during Manual Operation

### Operation



**Direct key method**  
 The value specified by the Up and Down arrow keys is output as is.  
 Press the Up arrow key to increase the control output.  
 Press the Down arrow key to decrease the control output.

**SET/ENT key method**  
 Set the control output on the setting display and press the SET/ENT key to confirm the value to output it.

### Description

In MAN mode, the control output is manipulated by direct key operation. (The value changed using the Up or Down arrow key is output as is.)  
 Manipulation of the control output is not possible in STOP mode (the STOP lamp is lit).  
 Output manipulation differs depending on the ON or OFF setting of the control output limiter (OH, OL).

▶ [10.4 Disabling Output Limiter in MAN mode](#)

### OUT Display



When the control output low limit is set to “SD” while the control output type is 4 to 20 mA, the control output value can be lowered down to 0 mA.

▶ [10.6 Reducing 4-20 mA Current Output to 0 mA \(Tight Shut Function\)](#)

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
MAN.T	Manual output operation type	PRO	Selects how to manipulate the control output during manual operation. (Note) DT.ET: Direct key method (The value specified by the Up and Down arrow keys is output as is.) ST.ET: SET/ENT key method (The value specified on the setting display and confirmed with the SET/ENT key is output.)	OUT <b>Ope</b>

## 6.9 Releasing On-State (Latch) of Alarm Output

### Description

Alarm latch can be released by any of the following.

- (1) User function key
- (2) Communication

For the switching operation by using the above, the last switching operation is performed.

Releasing the alarm latch function releases all of the latched alarm outputs.

By factory default, the function is not assigned to the user function key. Assign and use the function in accordance with the reference sections below.

- ▶ [Release by user function key: 13.2 Assigning Function to User Function Key and A/M key](#)
- ▶ [Release via communication: UTAdvanced Series Communication Interface User's Manual](#)



# 7.1 Setting Functions of PV Input


## 7.1.1 Setting Input Type, Unit, Range, Scale, and Decimal Point Position

**Description**

The figure below describes the case of PV input.


**Example of Temperature Input**

The figure below is an example of setting Type K thermocouple and a measurement range of 0.0 to 800.0 °C.



**Example of Voltage and Current Inputs**

The figure below is an example of setting 2-4 V DC and a scale of 0.0 to 50.0 m³/h.



When using 1-5 V DC signal as is, set RH = 5.000 V, RL = 1.000 V, SDP=1, and SH = 50.0, and SL=0.0.



## 7.1 Setting Functions of PV Input

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>IN</b>	PV input type	EASY	OFF: Disable K1: -270.0 to 1370.0 °C / -450.0 to 2500.0 °F K2: -270.0 to 1000.0 °C / -450.0 to 2300.0 °F K3: -200.0 to 500.0 °C / -200.0 to 1000.0 °F J: -200.0 to 1200.0 °C / -300.0 to 2300.0 °F T1: -270.0 to 400.0 °C / -450.0 to 750.0 °F T2: 0.0 to 400.0 °C / -200.0 to 750.0 °F B: 0.0 to 1800.0 °C / 32 to 3300 °F S: 0.0 to 1700.0 °C / 32 to 3100 °F R: 0.0 to 1700.0 °C / 32 to 3100 °F N: -200.0 to 1300.0 °C / -300.0 to 2400.0 °F E: -270.0 to 1000.0 °C / -450.0 to 1800.0 °F L: -200.0 to 900.0 °C / -300.0 to 1600.0 °F U1: -200.0 to 400.0 °C / -300.0 to 750.0 °F U2: 0.0 to 400.0 °C / -200.0 to 1000.0 °F W: 0.0 to 2300.0 °C / 32 to 4200 °F (Note1) PL2: 0.0 to 1390.0 °C / 32.0 to 2500.0 °F P2040: 0.0 to 1900.0 °C / 32 to 3400 °F WRE: 0.0 to 2000.0 °C / 32 to 3600 °F JPT1: -200.0 to 500.0 °C / -300.0 to 1000.0 °F JPT2: -150.0 to 150.0 °C / -200.0 to 300.0 °F PT1: -200.0 to 850.0 °C / -300.0 to 1560.0 °F PT2: -200.0 to 500.0 °C / -300.0 to 1000.0 °F PT3: -150.0 to 150.0 °C / -200.0 to 300.0 °F 0.4-2V: 0.400 to 2.000 V 1-5V: 1.000 to 5.000 V 4-20: 4.00 to 20.00 mA 0-2V: 0.000 to 2.000 V 0-10V: 0.00 to 10.00 V 0-20 : 0.00 to 20.00 mA -1020: -10.00 to 20.00 mV 0-100: 0.0 to 100.0 mV	PV <b>Set</b>
<b>UNIT</b>	PV input unit	EASY	-: No unit C: Degree Celsius -: No unit --: No unit ---: No unit F: Degree Fahrenheit	PV <b>Set</b>
<b>RH (Physical quantity)</b>	Maximum value of PV input range	EASY	Depends on the input type. - For temperature input - Set the temperature range that is actually controlled. (RL<RH) - For voltage / current input - Set the range of a voltage / current signal that is applied. The scale across which the voltage / current signal is actually controlled should be set using the maximum value of input scale (SH) and minimum value of input scale (SL). (Input is always 0% when RL = RH.)	PV <b>Set</b>
<b>RL (Physical quantity)</b>	Minimum value of PV input range	EASY	Same as RH	PV <b>Set</b>

Note1: W: W-5% Re/W-26% Re(Hoskins Mfg. Co.). ASTM E988  
 WRE: W97Re3-W75Re25

(Continued)

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>SDP</b> (Scaling)	PV input scale decimal point position	EASY	0: No decimal place 1: One decimal place 2: Two decimal places 3: Three decimal places 4: Four decimal places	PV <b>Set</b>
<b>SH</b> (Scaling)	Maximum value of PV input scale	EASY	-19999 to 30000, (SL<SH),   SH - SL   ≤ 30000	PV <b>Set</b>
<b>SL</b> (Scaling)	Minimum value of PV input scale	EASY	-19999 to 30000, (SL<SH),   SH - SL   ≤ 30000	PV <b>Set</b>

IN, UNIT, RH, and RL described above are the parameters to be used for processing before the input ladder calculation program.

The following parameters are used for processing after the input ladder calculation program.

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>P.UNI</b>	Control PV input unit	STD	-: No unit C: Degree Celsius - -: No unit - - -: No unit F: Degree Fahrenheit	MPV <b>Set</b>
<b>P.DP</b>	Control PV input decimal point position		0: No decimal place 1: One decimal place 2: Two decimal places 3: Three decimal places 4: Four decimal places	
<b>P.RH</b>	Maximum value of control PV input range		-19999 to 30000, (P.RL<P.RH),   P.RH - P.RL   ≤ 30000	
<b>P.RL</b>	Minimum value of control PV input range			

## 7.1.2 Setting Burnout Detection for Input

### Description

The input value when input burnout occurs can be determined.

The input value is 105.0% of the input range when the upscale is set, and -5.0% of the input range when the downscale is set.

Burnout detection is activated for TC, RTD, and standard signal (0.4–2 V or 1–5 V).

For standard signal, burnout is determined to have occurred if it is 0.1 V or less for the range of 0.4–2 V and 1–5V, or if it is 0.4 mA or less for the range of 4–20 mA.

When input burnout occurs, the error preset output (EPO) is output as control output.

- ▶ [Input error preset output: 10.12.3 Setting Output Value When Error Occurs \(Input Error Preset Output\)](#)

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>BSL</b>	PV input burnout action	STD	OFF: Disable UP: Upscale DOWN: Downscale	PV <b>Set</b>

### 7.1.3 Setting Reference Junction Compensation (RJC) or External Reference Junction Compensation (ERJC)

**Description**


**Reference Junction Compensation (RJC)**

When TC input is selected, presence/absence of input reference junction compensation can be set.

Usually input values are compensated with the RJC function provided for the controller. However, if it is necessary to rigorously compensate the values with a device other than the function of the controller, for example with a zero-compensator, the RJC function of the controller can be turned off.

**External Reference Junction Compensation (ERJC)**

For TC input, a temperature compensation value for external device can be set. The external RJC can be used only when RJC = OFF.



**Setting Details**

Parameter symbol	Name	Display level	Setting range	Menu symbol
RJC	PV input reference junction compensation	PRO	OFF: RJC OFF ON: RJC ON	PV <b>Set</b>
ERJC	PV input external RJC setpoint	PRO	-10.0 to 60.0°C	PV <b>Set</b>

## 7.1.4 Correcting Input Value

### (1) Setting Bias and Filter


#### Description

##### PV Input Bias

The PV input bias allows bias to be summed with input to develop a measured value for display and control use inside the controller.

This function can also be used for fine adjustment to compensate for small inter-instrument differences in measurement reading that can occur even if all are within the specified instrument accuracies.



PV input bias is used for normal operation.



##### PV Input Filter

If input noise or variations cause the low-order display digits to fluctuate so that the displayed value is difficult to read, a digital filter can be inserted to smooth operation. This filter provides a first-order lag calculation, which can remove more noise the larger the time constant becomes. However, an excessively large time constant will distort the waveform.

PV input filter is used for normal operation.



##### Analog Input Bias

Analog input bias is used to correct sensor-input characteristics, compensating lead wire errors, and so on.


##### Analog Input Filter



The analog input filter is used to remove noise from an input signal. This filter provides a first-order lag calculation, which can remove more noise the larger the time constant becomes. However, an excessively large time constant will distort the waveform.

## 7.1 Setting Functions of PV Input

---

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>BS</b>	PV input bias	EASY	-100.0 to 100.0% of PV input range span (EUS)	PVS 
<b>FL</b>	PV input filter	EASY	OFF, 1 to 120 s	

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>A.BS</b>	PV analog input bias	STD	-100.0 to 100.0% of each input range span (EUS)	PV 
<b>A.FL</b>	PV analog input filter	STD	OFF, 1 to 120 s	PV 

## 8.1 Control Function Block Diagrams

### 8.1.1 Single-loop Control

#### Description

These control functions provide the basic control function having one control computation unit.

Single-loop control can be used for Standard type controller.

- ▶ [PID control: 8.2 Setting Control Type \(CNT\)](#)

The Function block diagram describes only the basic functions.


Parameter symbols in the Function block diagram describe representative parameters.

For the functions and parameters which are not described in Function block diagram, see the following.

- ▶ [Contact output assignment to retransmission output terminal: 10.1 Setting Control Output Type](#)
- ▶ [Analog output range change: 10.14 Changing Current Output Range](#)

# 8.1 Control Function Block Diagrams

## ■ Single-loop Control Function Block Diagram



## 8.2 Setting Control Type (CNT)

The following table shows combination of Standard type.

Control type	Suffix code: Type 1
	Standard type
PID control	√
ON/OFF control (1 point of hysteresis)	√
ON/OFF control (2 points of hysteresis)	√

√: Available, N/A: Not available

The following table shows combination of control type (CNT) and output type.

Control type	Output type		
	Current output	Time proportional output	ON/OFF output
PID control	√	√	N/A
ON/OFF control (1 point of hysteresis)	√	N/A	√
ON/OFF control (2 points of hysteresis)	√	N/A	√

√: Available, N/A: Not available

► [Output type: 10.1 Setting Control Output Type](#)



## 8.2 Setting Control Type (CNT)

### 8.2.1 PID Control

#### Description

PID control is a general control using control-related parameters PID.  
When PID control is selected, PID should be obtained by auto-tuning after setting SP or PID should be set manually.

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>CNT</b>	Control type	EASY	PID: PID control ONOF: ON/OFF control (1 point of hysteresis) ONOF2: ON/OFF control (2 points of hysteresis)	CTL <b>Set</b>
<b>P</b>	Proportional band	EASY	0.0 to 999.9% When 0.0% is set, it operates as 0.1%.	PID <b>Ope</b>
<b>I</b>	Integral time	EASY	OFF: Disable 1 to 6000 s	
<b>D</b>	Derivative time	EASY	OFF: Disable 1 to 6000 s	
<b>MR</b>	Manual reset	EASY	-5.0 to 105.0%	
<b>PIDN</b>	PID number selection	EASY	1 to 4	SP <b>Ope</b>
<b>PIDG.</b>	Number of PID groups	STD	1 to 4	CTL <b>Set</b>

Note 1: The PID number (1 to 4, or R) is displayed on Group display while the parameter P, I, D, or MR is displayed.

#### Note

When changing the setpoint of the parameter PIDG., if the setpoint of the parameter PIDN which belongs to the SP menu is larger than that of the parameter PIDG., the PIDN setpoint is changed to the PIDG. setpoint.

### 8.2.2 ON/OFF Control (1 point of hysteresis / 2 points of hysteresis)

**Description**

ON/OFF control compares the SP and PV and outputs an on or off signal according to the positive or negative deviation (PV – SP). Hysteresis can be set in the vicinity of the on/off output operating point.


If the SP and PV become close and the polarity of the deviation reverses frequently, the on/off output will cycle repeatedly. The life of the output relay will therefore be dramatically shortened.

In such a case, set a wider hysteresis so that the relay's frequent on/off output (chattering) will not occur.


When the control type (CNT) is set to "ONOF," one point of hysteresis can be set to the operating point.

When the control type (CNT) is set to "ONOF2," two points of hysteresis (deviation positive hysteresis and deviation negative hysteresis) can be set to the operating point.

**1 point of hysteresis**



**2 points of hysteresis**



## 8.2 Setting Control Type (CNT)

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>CNT</b>	Control type	EASY	PID: PID control ONOF: ON/OFF control (1 point of hysteresis) ONOF2: ON/OFF control (2 points of hysteresis)	CTL <b>Set</b>
<b>HYS</b>	Hysteresis	EASY	In ON/OFF control: 0.0 to 100.0% of PV input range span (EUS)	PID <b>Ope</b>
<b>HY.UP</b>	Upper-side hysteresis (in ON/OFF control)	EASY	0.0 to 100.0% of PV input range span (EUS)	
<b>HY.LO</b>	Lower-side hysteresis (in ON/OFF control)	EASY		
<b>PIDN</b>	PID number selection	EASY	1 to 4	SP <b>Ope</b>
<b>PIDG.</b>	Number of PID groups	STD	Set a number of PID groups to use. 1 to 4	CTL <b>Set</b>

Note1: The PID number (1 to 4, or R) is displayed on Group display while the parameter HYS, HY.UP or HY.LO is displayed.

### **Note**

When changing the setpoint of the parameter PIDG., if the setpoint of the parameter PIDN which belongs to the SP menu is larger than that of the parameter PIDG., the PIDN setpoint is changed to the PIDG. setpoint.

### 8.2.3 PD Control (Stable Control in Which a Setpoint is not Exceeded)

#### Description

This control type performs control in which integral action (I action) is excluded from PID action.

Set the integral time (I or I<sub>c</sub>) to OFF.

It is useful when stable control in which a setpoint is not exceeded is desired for integral processes in which constant flows are delivered.

The following shows the PID control computation formula.

$$\text{OUT} = \frac{100}{P} \left( e + T_d \frac{d}{dt} \cdot \Delta \text{PV} \right) + \text{MR}$$

where OUT: control output, e: deviation (PV-SP), P: proportional band, T<sub>d</sub>: derivative time, ΔPV: PV<sub>n</sub>-PV<sub>n-1</sub> (n-1: value before one control period), and MR: manual reset

The following table shows combination of PD control and output method.

	Output method		
	Current output	Time proportional output	ON/OFF output
PD control	√	√	N/A

√: Available, N/A: Not available

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>P</b>	Proportional band	EASY	0.0 to 999.9% When 0.0% is set, it operates as 0.1%.	PID <b>Ope</b>
<b>D</b>	Derivative time	EASY	OFF: Disable 1 to 6000 s	
<b>MR</b>	Manual reset	EASY	-5.0 to 105.0%	
<b>PIDG.</b>	Number of PID groups	STD	1 to 4	CTL <b>Set</b>

Note1: The PID number (1 to 4, or R) is displayed on Group display while the parameter P, D, or MR is displayed.

#### Note

When changing the setpoint of the parameter PIDG., if the setpoint of the parameter PIDN which belongs to the SP menu is larger than that of the parameter PIDG., the PIDN setpoint is changed to the PIDG. setpoint.

## 8.3 Setting PID Control Mode (ALG)

### Description

There are two PID control modes: standard PID control mode and fixed-point control mode.

Select a PID control computation formula shown in the following table according to the control mode or operation mode.

	Operation mode	
	AUTO+Local	AUTO+Remote
Standard PID control mode	PV derivative type (output bump at SP change)	Deviation derivative type
Fixed-point control mode	PV derivative type (output bumpless at SP change)	PV derivative type (output bump at SP change)


### PV Derivative Type PID

This is a PID control method in which the derivative action works only on the PV. It can also eliminate output bump due to SP changing operation in Local mode. The following shows the PV derivative type PID control computation formula.


$$\text{OUT} = \frac{100}{P} \left( e + \frac{1}{T_i} \int e \cdot dt + T_d \frac{d}{dt} \cdot \Delta PV \right)$$

where OUT: control output, e: deviation (PV-SP), P: proportional band, Ti: integral time, Td: derivative time, and  $\Delta PV$ :  $PV_n - PV_{n-1}$  (n-1: value before one control period)

#### PV Derivative Type PID (output bump at SP change)



#### PV Derivative Type PID (output bumpless at SP change)




**Deviation Derivative Type PID**

The PID control method in which derivative action works for the deviation value = PV – SP.

The following shows the deviation derivative type PID control computation formula.

$$OUT = \frac{100}{P} \left( e + \frac{1}{Ti} \int e \cdot dt + Td \frac{d}{dt} \cdot e \right)$$

where OUT: control output, e: deviation (PV-SP), P: proportional band, Ti: integral time, and Td: derivative time



**Setting Details**

Parameter symbol	Name	Display level	Setting range	Menu symbol
ALG	PID control mode	PRO	0: Standard PID control mode 1: Fixed-point control mode.	CTL <b>Set</b>

## 8.4 Switching PID

### 8.4.1 Switching PID According to Target Setpoint Number (SPNO)

#### Description

The SP group number selection selects a group of target setpoint (SP) and PID parameters by switching the SP number (SPNO).

The PID number selection (PIDN) can be set for each SP group.

SP number (SPNO)	SP	PID parameter group
1	SP of group 1	Specify using the parameter PIDN of group 1
2	SP of group 2	Specify using the parameter PIDN of group 2
3	SP of group 3	Specify using the parameter PIDN of group 3
4	SP of group 4	Specify using the parameter PIDN of group 4

When ZON=0 (SP group number selection 1): In coordinated operation, slaves operate with the same PID number as that of the master.

The setpoint in the PID number selection (PIDN) within the SP group is ignored.

When ZON=3 (SP group number selection 2): In coordinated operation, slaves operate with the setpoint in the PID number selection (PIDN) within the SP group.

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
ZON	Zone PID selection	STD	0: SP group number selection 1 1: Zone PID selection (selection by PV) 2: Zone PID selection (selection by target SP) 3: SP group number selection 2 4: Zone PID selection (selection by SP)	CTL <b>Set</b>
PIDN	PID number selection	EASY	1 to 4 (Depends on the setup parameter PIDG. setting.)	SP <b>Ope</b>
PID	PID number (display only)	EASY	1 to 4	MODE <b>Ope</b>
PIDG.	Number of PID groups	STD	1 to 4	CTL <b>Set</b>

Note1: The initial values for PIDN of the four groups are same as SP number selection (SPNO.). Set a PID number to use as necessary.

Note3: A currently-used PID number is displayed for the parameter PID.

#### Note

When changing the setpoint of the parameter PIDG., if the setpoint of the parameter PIDN which belongs to the SP menu is larger than that of the parameter PIDG., the PIDN setpoint is changed to the PIDG. setpoint.

## 8.4.2 Switching PID According to PV


### Description

The PID switching according to PV is a function that switches between the groups of PID parameters according to the PV.

The maximum number of PID groups to be switched is 8. (Set RP1 to RP3.)

This function is useful for reactors in which the chemical reaction gain changes depending on the temperature.

The figure below shows an example of dividing the PV input range from the maximum value to the minimum value into four zones by reference points 1 to 3. (Set RP1 to RP3.)



The PV input range can be divided into the number of zones that is set in the reference point.

Hysteresis at the time of zone switch can be set.

► [Setpoint PD: 8.4.6 Setting Hysteresis at Time of Zone Switch](#)

Reference deviation can be set at the same time.

► [Reference deviation: 8.4.5 Switching PID according to Deviation \(Reference Deviation\)](#)



## 8.4 Switching PID

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>ZON</b>	Zone PID selection	STD	0: SP group number selection 1 1: Zone PID selection (selection by PV) 2: Zone PID selection (selection by target SP) 3: SP group number selection 2 4: Zone PID selection (selection by SP)	CTL <b>Set</b>
<b>RP1 to RP3</b>	Reference point 1 to 3	STD	0.0 to 100.0% of PV input range (EU) ( $RP1 \leq RP2 \leq RP3$ )	ZONE <b>Ope</b>
<b>PIDG.</b>	Number of PID groups	STD	1 to 4	CTL <b>Set</b>
<b>PID</b>	PID number (display only)	EASY	1 to 4, R: PID group for reference deviation	MODE <b>Ope</b>

Note1: A currently-used PID number is displayed for the parameter PID.

### **Note**

When changing the setpoint of the parameter PIDG., if the setpoint of the parameter PIDN which belongs to the SP menu is larger than that of the parameter PIDG., the PIDN setpoint is changed to the PIDG. setpoint.


## 8.4.3 Switching PID According to SP

**Description**

The zone PID selection by SP switches between the groups of PID parameters according to the SP.

The maximum number of PID groups to be switched is 4. (Set RP1 to RP3)

The figure below shows the example of switching the group of PID parameters according to the SP. It shows an example of dividing the PV input range from the maximum value to the minimum value into four zones by reference points 1 to 3. (Set RP1 to RP3.)



The PV input range can be divided into the number of zones that is set in the reference point.

Reference deviation can be set at the same time.

► [Reference deviation: 8.4.5 Switching PID according to Deviation \(Reference Deviation\)](#)

## 8.4 Switching PID

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>ZON</b>	Zone PID selection	STD	0: SP group number selection 1 1: Zone PID selection (selection by PV) 2: Zone PID selection (selection by target SP) 3: SP group number selection 2 4: Zone PID selection (selection by SP)	CTL <b>Set</b>
<b>RP1 to RP3</b>	Reference point 1 to 3	STD	0.0 to 100.0% of PV input range (EU) ( $RP1 \leq RP2 \leq RP3$ )	ZONE <b>Ope</b>
<b>PIDG.</b>	Number of PID groups	STD	1 to 4	CTL <b>Set</b>
<b>PID</b>	PID number (display only)	EASY	1 to 4, R: PID group for reference deviation	MODE <b>Ope</b>

Note1: A currently-used PID number is displayed for the parameter PID.

#### **Note**


When changing the setpoint of the parameter PIDG., if the setpoint of the parameter PIDN which belongs to the SP menu is larger than that of the parameter PIDG., the PIDN setpoint is changed to the PIDG. setpoint.

## 8.4.4 Switching PID According to Target SP

### Description

The zone PID selection by target SP switches between the groups of PID parameters according to the target SP.

The figure below shows the example of switching the group of PID parameters according to the target SP. It shows an example of dividing the PV input range from the maximum value to the minimum value into four zones by reference points 1 to 3. (Set RP1 to RP3.)



The PV input range can be divided into the number of zones that is set in the reference point.

Reference deviation can be set at the same time.

► [Reference deviation: 8.4.5 Switching PID according to Deviation \(Reference Deviation\)](#)

## 8.4 Switching PID

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>ZON</b>	Zone PID selection	STD	0: SP group number selection 1 1: Zone PID selection (selection by PV) 2: Zone PID selection (selection by target SP) 3: SP group number selection 2 4: Zone PID selection (selection by SP)	CTL <b>Set</b>
<b>RP1 to RP3</b>	Reference point 1 to 3	STD	0.0 to 100.0% of PV input range (EU) ( $RP1 \leq RP2 \leq RP3$ )	ZONE <b>Ope</b>
<b>PIDG.</b>	Number of PID groups	STD	1 to 4	CTL <b>Set</b>
<b>PID</b>	PID number (display number)	EASY	1 to 4, R: PID group for reference deviation	MODE <b>Ope</b>

Note1: A currently-used PID number is displayed for the parameter PID.

### **Note**

When changing the setpoint of the parameter PIDG., if the setpoint of the parameter PIDN which belongs to the SP menu is larger than that of the parameter PIDG., the PIDN setpoint is changed to the PIDG. setpoint.

### 8.4.5 Switching PID According to Deviation (Reference Deviation)


#### Description

The zone PID selection by deviation switches between the groups of PID parameters according to the amount of deviation.

This function is called “reference deviation.”

In the fixed point control, if the actual amount of deviation exceeds the setpoint of the reference deviation, the controller automatically changes to the PID parameter group (PID of group R) set for the zone. If the actual amount of deviation becomes smaller than the setpoint of reference deviation, the controller changes to the PID parameter group appropriate for the zone.

For example, if the deviation is large, PV can be reached more rapidly to SP by increasing the proportional gain (i.e., narrowing the proportional band). Switching PID according to deviation is effective when ZON is set to 1, 2, 4. The zone PID selection by reference deviation has priority over other zone PID selections.



#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>ZON</b>	Zone PID selection	STD	0: SP group number selection 1 1: Zone PID selection (selection by PV) 2: Zone PID selection (selection by target SP) 3: SP group number selection 2 4: Zone PID selection (selection by SP)	CTL <b>Set</b>
<b>RDV</b>	Reference deviation	STD	OFF: Disable 0.0 + 1 digit to 100.0% of PV input range span (EUS)	ZONE <b>Ope</b>
<b>PID</b>	PID number (display only)	EASY	1 to 4, R: PID group for reference deviation	MODE <b>Ope</b>


Note1: A currently-used PID number is displayed for the parameter PID.

### 8.4.6 Setting Hysteresis at Time of PID Switch

**Description**

When the zone PID selection is selected, hysteresis at time of each zone switch can be set.

The following shows the operation example of hysteresis at time of zone switch.



**Setting Details**


Parameter symbol	Name	Display level	Setting range	Menu symbol
RHY	Zone PID switching hysteresis	STD	0.0 to 10.0% of PV input range span (EUS)	ZONE <b>Ope</b>

## 8.5 Suppressing Overshoot (Super Function)


### Description

The Super function monitors the deviation for evidence that there is a danger of overshoot, and on sensing such danger automatically changes the setpoint temporarily to a somewhat lower value (sub-SP). Once the danger of overshoot appears diminished, the function returns the effective SP gradually to the true SP. "Fuzzy ratiocination" techniques are employed in the algorithms used to change the SP to the lower temporary value, and to return it gradually to the true SP.

### Operation Diagram




### Control System Block Diagram






## 8.5 Suppressing Overshoot (Super Function)

### Example of Overshoot Suppression Control for Setpoint Changes



### Example of Overshoot Suppression Control for Ramp-to-soak Transition



### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
SC	Super function	EASY	OFF: Disable 1: Overshoot suppressing function (normal mode) 2: Hunting suppressing function (stable mode) 3: Hunting suppressing function (response mode) 4: Overshoot suppressing function (strong suppressing mode)	TUNE <b>Ope</b>

The setting SC=4 is effective compared with SC=1. However, the hunting may occur until the PV reaches SP. Use it as usage.


Do not use the Super function for the Sample PI control.

## 8.6 Suppressing Hunting (Super2 Function)


### Description

The Super2 function suppresses the hunting effect of the controller without re-tuning the PID parameters.

Hunting means the PV becomes unstable and oscillates around SP.




- In hunting condition, the Super2 function selects the output from process model as PV signal.
- The process model removes a factor of dead time from the actual process.
- The real process is under the open-loop condition.
- After hunting is suppressed, the Super2 function selects real PV signal, and carry out the standard feedback control.




### Effects of Super2

Load change



Temperature change



## 8.6 Suppressing Hunting (Super2 Function)

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
SC	Super function	EASY	OFF: Disable 1: Overshoot suppressing function (normal mode) 2: Hunting suppressing function (stable mode) 3: Hunting suppressing function (response mode) 4: Overshoot suppressing function (strong suppressing mode).	TUNE <b>Ope</b>

Set SC=2 when there are a lot of disturbances, and much hunting occurs.


Set SC=3 when SP is changed frequently. Hunting suppressing effect is smaller than that of SC=2, however, responsiveness is good.

The Super function does not work in direct action.

## 8.7 Suppressing Integral Action (Anti-reset Wind-up)

### Description

Where there is a large deviation at the start of the control operation, for example, integral outputs are accumulated and the PV exceeds the SP, thereby causing the output to overshoot. To avoid this, the controller provides an anti-reset wind-up function for suppressing an extreme integral output by stopping PID computations. Same applies to the case of undershoot.



The parameter AR sets the point (by deviation band (%)) to restart the PID computation that is suspended by the controller's anti-reset windup function. PID computation restarts when the deviation band has decreased to the AR setpoint. When the parameter AR is set to AUTO, the controller automatically determines the point at which to restart the PID computation.

$$\text{Deviation band (= Setpoint of AR)} = \frac{|PV - SP|}{\text{Proportional band}} \times 100 (\%)$$

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
AR	Anti-reset windup	STD	AUTO, 50.0 to 200.0%	TUNE <b>Ope</b>

## 8.8 Adjusting Auto-tuning Operation

### Description

#### Auto-tuning Type

“Normal” of auto-tuning type requires a rapidly rising PID constant. This type is useful for processes that allow some overshooting.

On the other hand, “stable” of auto-tuning type requires a slowly rising PID constant.

#### Auto-tuning Output Limiter


When executing auto-tuning, the control output high and low limits can be set.

When the control output low limit > AT.OL, or AT.OH < control output high limit, auto-tuning is limited by the control output low or high limit.

#### Note

In time proportional output, the output is turned on and off irrespective of the upper/lower limit.


### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
AT.TY	Auto-tuning type	STD	0: Normal 1: Stability	TUNE 
AT.OH	Output high limit in auto-tuning	PRO	-5.0 to 105.0%	
AT.OL	Output low limit in auto-tuning	PRO		

# 9.1 Setting SP Limiter

## Description

The SP high and low limits can be set to restrict the SP to the range between those limits whether in REM (remote) or LCL (local) mode. They works to the SP of all SP groups.



▶ SP group: 6.2 Setting Target Setpoint

## Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>SPH</b>	SP high limit	STD	0.0 to 100.0% of PV input range (EU), (SPL<SPH)	MPV <b>Set</b>
<b>SPL</b>	SP low limit	STD		

## 9.2 Changing SP at a Fixed Rate (SP Ramp-Rate Setting Function)

### Description

SP ramp-rate setting function forces SP to change at a fixed rate when SP is changed in order to prevent abrupt changes in SP.


Velocity (rate-of-change) can be set for both the SP ramp-up rate (UPR) and SP ramp-down rate (DNR). Set the ramp-rate time unit (TMU) per hour or minute.

The SP ramp-rate setting function works when:


- (1) SP is changed.
- (2) SP is changed by switching SP number (SPNO).
- (3) Power is turned on or has recovered from a failure (PV tracking=ON); or
- (4) Operation mode is switched from MAN to AUTO (PV tracking=ON).

SP ramp-rate setting action starts from PV when the PV tracking function is used.



(1) When SP is changed




(2) When SP No. (SPNO) is switched



(3) When power is turned on (or power has recovered)  
(4) When operation mode is switched from MAN to AUTO



## 9.2 Changing SP at a Fixed Rate (SP Ramp-Rate Setting Function)



$$\text{UPR} = \frac{\text{Temperature difference (}^\circ\text{C)}}{\text{Time (min)}} = \frac{140^\circ\text{C}}{2 \text{ min}} = 70 (^\circ\text{C/min)}$$

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>UPR</b>	SP ramp-up rate	EASY	OFF, 0.0 + 1 digit to 100.0% of PV input range span (EUS)	SPS <b>Ope</b>
<b>DNR</b>	SP ramp-down rate	EASY		
<b>TMU</b>	SP ramp-rate time unit	EASY	HOUR: Ramp-up rate or ramp-down rate per hour MIN: Ramp-up rate or ramp-down rate per minute	



## 9.3 Forcing SP to Track PV (PV Tracking)


### Description

PV tracking function is used to prevent abrupt PV changes. With PV tracking, SP is first aligned with PV and then changed to its original SP at the SP ramp rate.

► [SP ramp-rate setting function: 9.2 Changing SP at a Fixed Rate \(SP Ramp-Rate Setting Function\)](#)

PV tracking function works when:

- (1) Power is turned on or has recovered from a failure,
- (2) SP number (SPNO) is changed,
- (3) Operation mode is switched from STOP to RUN,
- (4) Operation mode is switched from MAN to AUTO



### Setting Details


Parameter symbol	Name	Display level	Setting range	Menu symbol
PVT	PV tracking selection	STD	OFF, ON	SPS <b>Ope</b>

## 9.4 Forcing SP to Track Remote Input (SP Tracking)

### Description

SP tracking function is the function to force the local setpoint (SP) to track the remote setpoint (RSP) when the operation mode is switched from REM (remote) to LCL (local) mode.

The function is effective to prevent abrupt PV changes.



### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>SPT</b>	SP tracking selection	STD	OFF, ON	SPS <b>Ope</b>

Displayed only in cases where the communication is specified.

## 9.5 Setting Controller Action at Power ON (Restart Mode)

### Description

For details, see Chapter 15, "Power Failure Recovery Processing."

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
R.MD	Restart Mode	STD	Set how the controller should recover from a power failure of 5 seconds or more. CONT: Continue action set before power failure. MAN: Start from MAN. AUTO: Start from AUTO.	SYS <b>Set</b>

The preset output (PO) is output in MAN or AUTO mode.

## 9.6 Setting Time between Powering on Controller and Starting Control (Restart Timer)

### Description

The time between power on and the instant where controller starts control computation can be set.

Operation start time = Operating time of controller initialization after power on.

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>R.TM</b>	Restart Timer	STD	0 to 10 s	SYS <b>Set</b>



# 10.1 Control Output Functions



## Description

### Time Proportional Relay Output (suffix code: -R) / Time Proportional Voltage Pulse Output (suffix code: -V)

In time proportional output, the control computation result is output in the form of an on/off signal pulse width proportional to the time. The pulse width is calculated as follows with the cycle time (control output cycle) at 100%.

$$\text{Control output pulse width} = \text{Control output (\%)} \times \text{Cycle time}$$



The output type is selected as either the relay output or the voltage pulse output.



► Cycle time: 10.2 Setting Control Output Cycle Time

### Current Output (suffix code: -C)

In current output, the control computation result is output as a current signal. (Example of 4 to 20 mA)




### ON/OFF Output

ON/OFF control compares the SP and PV and outputs an on or off signal according to the positive or negative deviation (PV – SP).


## 10.2 Setting Control Output Cycle Time

### Description

Cycle time is the basic cycle period for a signal full cycle of ON/OFF operation for a relay or voltage pulse output. Reducing cycle time results in faster cycling and finer control. In contrast, reducing the ON/OFF period also reduces relay life. For relay output, set the control output cycle time to 30 to 200 seconds according to the process speed.



Comparison of operations for the same control output (50%)



### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
CT	Control output cycle time	EASY	0.5 to 1000.0 s	OUT <b>Set</b>

## 10.3 Setting Limiter to Control Output


### Description

Control output high and low limits can be set to restrict the control output to the operation range between those limits.

The output limiter is prepared for each PID group, and works according to the selected PID group.

This, however, excludes preset output in STOP mode.

▶ [PID group: 6.4 Adjusting PID Manually](#)



### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>OH</b>	Control output high limit	EASY	-4.9 to 105.0%, (OL<OH)	PID <b>Ope</b>
<b>OL</b>	Control output low limit	EASY	-5.0 to 104.9%, (OL<OH), SD: Tight shut	PID <b>Ope</b>
<b>PIDN</b>	PID number selection	EASY	1 to 4	SP <b>Ope</b>
<b>PIDG.</b>	Number of PID groups	STD	1 to 4	CTL <b>Set</b>

Note1: The PID number (1 to 4, R) is displayed on Group display while each parameter is displayed.

Note2: When the setting is low limit  $\geq$  high limit, the controller operates as low limit = high limit - 1 digit.

### Note

When changing the setpoint of the parameter PIDG., if the setpoint of the parameter PIDN which belongs to the SP menu is larger than that of the parameter PIDG., the PIDN setpoint is changed to the PIDG. setpoint.



## 10.4 Disabling Output Limiter in MAN mode

### Description

Output limiter can be released when in MAN mode.

Note that the output bump is caused if the operation mode is changed from MAN to AUTO while the control output is out of the range between the control output high limit (OH) and control output low limit (OL).

Control output bumps to OH in MAN mode when it is larger than OH.

Moreover, it bumps to OL when smaller than OL.


### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>OLMT</b>	Output limiter switch	PRO	OFF: Disable output limiter in MAN mode ON: Enable output limiter in MAN mode	TUNE <b>Ope</b>

# 10.5 Setting Velocity Limiter to Control Output

## Description

Output velocity limiter prevents the control output signal from changing suddenly in order to protect the control valves (or other actuators) and controlled process. The output velocity limiter does not work in MAN or STOP mode or when input burnout or A/D error occurs. Note that setting an output velocity limit may cancel the effects of derivative action. The following shows the operation example of output velocity limiter.



In ON/OFF control, the setting is invalid even if the output velocity limiter is set.

## Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
OPR	Output velocity limiter	STD	OFF: Disable 0.1 to 100.0%/s	TUNE <b>Ope</b>

## 10.6 Reducing 4-20 mA Current Output to 0 mA (Tight Shut Function)

### Description

Tight shut function fully closes the control valve (or other actuators) (i.e., so that output is zero) beyond its positioner dead band.


When the output low limit is set to "SD," the output is as follows in MAN or AUTO mode.

#### • In MAN mode

When the output is reduced with the Down arrow key and "SD" is displayed as the output value, the output level reaches tight shut level. The control output delivers a tight shut signal (about 0.0 mA).

#### • In AUTO mode

The output is limited by the output low limit (OL). It does not decrease to 0.0 mA.



### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>OL</b>	Control output low limit	EASY	-5.0 to 104.9%, (OL<OH), SD: Tight shut (0 mA output in MAN mode)	PID <b>Ope</b>
<b>PIDN</b>	PID number selection	EASY	1 to 4	SP <b>Ope</b>
<b>PIDG.</b>	Number of PID groups	STD	1 to 4	CTL <b>Set</b>

Note1: The PID number (1 to 4, R) is displayed on Group display while each parameter is displayed.

#### **Note**

When changing the setpoint of the parameter PIDG., if the setpoint of the parameter PIDN which belongs to the SP menu is larger than that of the parameter PIDG., the PIDN setpoint is changed to the PIDG. setpoint.


# 10.7 Setting ON/OFF Control Hysteresis

## Description

In ON/OFF control, since the only two possible output states are ON and OFF, the control output cycles are as shown in the figure below. ON/OFF becomes quite narrow, so that if relay output is used, chattering occurs. In this case, the hysteresis should be set wider to prevent relay chattering and for the service life of the relay.


### One Point of Hysteresis

For one point of hysteresis, set one point of hysteresis.



### Two Points of Hysteresis

For two points of hysteresis, set two points of hysteresis (upper-side hysteresis and lower-side hysteresis).



## 10.7 Setting ON/OFF Control Hysteresis

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>HYS</b>	Hysteresis (in ON/OFF control)	EASY	In ON/OFF control: 0.0 to 100.0% of PV input range span (EUS)	PID <b>Ope</b>
<b>HY.UP</b>	Upper-side hysteresis (in ON/OFF control)	EASY	0.0 to 100.0% of PV input range span (EUS)	
<b>HY.LO</b>	Lower-side hysteresis (in ON/OFF control)	EASY		
<b>PIDN</b>	PID number selection	EASY	1 to 4	SP <b>Ope</b>
<b>PIDG.</b>	Number of PID groups	STD	1 to 4	CTL <b>Set</b>

Note1: The PID number (1 to 4, R) is displayed on Group display while each parameter is displayed.

### **Note**

When changing the setpoint of the parameter PIDG., if the setpoint of the parameter PIDN which belongs to the SP menu is larger than that of the parameter PIDG., the PIDN setpoint is changed to the PIDG. setpoint.

## 10.8 Canceling Offset of PV and SP (Manual Reset)

### Description

Manual reset can be used when the integral action is disabled.

When the integral action is disabled, there will be an offset of PV and SP. Manual reset cancels this offset.

The manual reset value equals the output value when PV = SP is true.

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>MR</b>	Manual reset	EASY	-5.0 to 105.0%	PID <b>Ope</b>
<b>PIDN</b>	PID number selection	EASY	1 to 4	SP <b>Ope</b>
<b>PIDG.</b>	Number of PID groups	STD	1 to 4	CTL <b>Set</b>

Note1: The PID number (1 to 4, or R) is displayed on Group display while each parameter is displayed.

### Note

When changing the setpoint of the parameter PIDG., if the setpoint of the parameter PIDN which belongs to the SP menu is larger than that of the parameter PIDG., the PIDN setpoint is changed to the PIDG. setpoint.

## 10.9 Setting Preset Output Value


### 10.9.1 Setting Output Value in STOP Mode (Preset Output)

#### Description

Preset output becomes the output when the operation mode is switched from RUN to STOP.

The preset output is not limited by the output high and low limits.

The preset output is prepared for each PID parameter group, and works according to the selected PID parameter group.



► [Output limiter: 10.3 Setting Limiter to Control Output](#)

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>PO</b>	Preset output	EASY	In STOP mode, fixed control output can be generated. -5.0 to 105.0%	PID <b>Ope</b>
<b>PIDN</b>	PID number selection	EASY	1 to 4	SP <b>Ope</b>
<b>PIDG.</b>	Number of PID groups	STD	1 to 4	CTL <b>Set</b>

Note1: The PID number (1 to 4, R) is displayed on Group display while each parameter is displayed.

#### Note

When changing the setpoint of the parameter PIDG., if the setpoint of the parameter PIDN which belongs to the SP menu is larger than that of the parameter PIDG., the PIDN setpoint is changed to the PIDG. setpoint.

For ON/OFF output, 0.0% is output when the setting value is 0.0% or less and 100.0% is output when 0.1% or more.

## 10.9.2 Setting Output Value When Switched to MAN Mode (Manual Preset Output)


### Description

When the operation mode is switched from AUTO to MAN, each of the following can be selected.

- The control output takes over the control output as is.
- The control output bumps to the manual preset output.

When the manual preset output is output, the manual operation is possible after the bump.

Manual preset output is limited by the output high and low limits. (when Output limiter switch (OLMT) = ON)



When the operation mode is switched from MAN to AUTO, transferred without bump from the manual output to the control output.

- ▶ [Output limiter: 10.3 Setting Limiter to Control Output](#)
- ▶ [Output limiter switch: 10.4 Disabling Output Limiter in MAN mode](#)

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>MPON</b>	Manual preset output number selection	STD	OFF: Hold the control output in AUTO mode (bumpless) 1: Use manual preset output 1 (output bump) 2: Use manual preset output 2 (output bump) 3: Use manual preset output 3 (output bump) 4: Use manual preset output 4 (output bump) 5: Use manual preset output 5 (output bump)	TUNE <b>Ope</b>
<b>MPO1 to MPO5</b>	Manual preset output 1 to 5	STD	-5.0 to 105.0%	



### 10.9.3 Setting Output Value When Error Occurs (Input Error Preset Output)

#### Description

The 0% control output, 100% control output, or input preset output can be selected and output as input error preset output in the following conditions.

- The input burnout occurs during operation in AUTO mode and RUN mode.
- The ADC error occurs during operation in AUTO mode and RUN mode.

However, the manual output becomes the output when the input burnout occurs in MAN mode and RUN mode.

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
EPO	Input error preset output	STD	0: Preset output 1: 0% output 2: 100% output	SYS <b>Set</b>

## 10.10 Changing Current Output Range

### Description

The analog output type can be selected from among 4 to 20, 0 to 20, 20 to 4, or 20 to 0 mA.

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
OU.A	OUT current output range	STD	4-20: 4 to 20 mA, 0-20: 0 to 20 mA, 20-4: 20 to 4 mA, 20-0: 20 to 0 mA	OUT <b>Set</b>

### Parameters and Corresponding Terminals

OU.A	OUT terminal
------	--------------



# 11.1 Setting Alarm Type

## Description

The alarm-related parameters consist of the alarm type (type, stand-by action, energized/de-energized, and latch function), PV velocity alarm time setpoint, alarm hysteresis, alarm (On-/Off-) delay timer, and alarm setpoint.


Alarm-related parameter	Number of settings
Alarm type	4 (number of settings)
PV velocity alarm time setpoint	4 (number of settings)
Alarm hysteresis	4 (number of settings)
Alarm (on-/off-) delay timer	4 (number of settings)
Alarm setpoint	4 (number of settings) x 4 (number of groups)

- ▶ Alarm hysteresis: [11.3 Setting Hysteresis to Alarm Operation](#)
- ▶ Alarm delay timer: [11.4 Delaying Alarm Output \(Alarm Delay Timer\)](#)
- ▶ Alarm setpoint: [6.5 Setting Alarm Setpoint](#)


Factory default: Only four groups of alarm-related parameters are displayed.

- ▶ Terminal function: [17.4.7 Contact Output Wiring](#)

To read the conditions of alarms, outputs, or latches via communication, see Communication Interface User's Manual.




### PV High Limit Alarm and PV Low Limit Alarm




Contact type in the figure above: Energized when an event occurs (factory default).

### SP High Limit Alarm and SP Low Limit Alarm



Contact type in the figure above: Energized when an event occurs (factory default).


### Deviation High Limit Alarm and Deviation Low Limit Alarm



Contact type in the figure above: Energized when an event occurs (factory default).


When a negative setpoint is set for the deviation high limit alarm setpoint, the deviation setpoint will be lower than the SP. Moreover, when a positive setpoint is set for the deviation low limit alarm setpoint, the deviation setpoint will be higher than the SP.

### Deviation High and Low Limits Alarm




Contact type in the figure above: Energized when an event occurs (factory default).

### Deviation within High and Low Limits Alarm




Contact type in the figure above: Energized when an event occurs (factory default).

**Target SP High Limit Alarm and Target SP Low Limit Alarm**



Contact type in the figure above: Energized when an event occurs (factory default).

**Target SP Deviation High Limit Alarm and Target SP Deviation Low Limit Alarm**




Contact type in the figure above: Energized when an event occurs (factory default).

\* Target SP: a set target setpoint. When the ramp-rate is set, it becomes a final target setpoint.


When a negative setpoint is set for the deviation high limit alarm setpoint, the deviation setpoint will be lower than the target SP.  
 Moreover, when a positive setpoint is set for the deviation low limit alarm setpoint, the deviation setpoint will be higher than the target SP.

### Target SP Deviation High and Low Limits Alarm



Contact type in the figure above: Energized when an event occurs (factory default).


### Target SP Deviation within High and Low Limits Alarm



Contact type in the figure above: Energized when an event occurs (factory default).




**Control Output High Limit Alarm and Control Output Low Limit Alarm**



Contact type in the figure above: Energized when an event occurs (factory default).


**Analog Input PV High Limit Alarm and Analog Input PV Low Limit Alarm**

These alarms monitor the input value after the analog input computation process (entrance to the input ladder calculation) is completed.



Contact type in the figure above: Energized when an event occurs (factory default).

## PV Velocity Alarm



Contact type in the figure above: Energized when an event occurs (factory default).

The PV velocity alarm function does not work the alarm hysteresis, the stand-by action and the alarm delay timer functions.

## Fault diagnosis Alarm

The function outputs an alarm signal in the following cases.

The corresponding event (EV) lamp is lit and the contact output turns on (when the contact type is energized).

- Burnout of PV input
- ADC failure of PV input
- Reference junction compensation (RJC) error of PV input

The fault diagnosis alarm does not work the stand-by action functions.

## FAIL output

When the FAIL condition is caused (faulty MCU or system data error), DO (alarm output) turned off regardless of contact type.

The FAIL output does not work the alarm latch, the energized/de-energized and the stand-by action functions.


### Stand-by Action

The stand-by action is a function for ignoring the alarm condition and keeps the alarm off until the alarm condition is removed. Once the alarm condition is removed, the stand-by action is cancelled.

It is effective in the following cases where;

- The power is turned on
- SP is changed
- SP number is switched (however, except for remote setpoint) (The SP must be changed.)
- The alarm type is changed
- Forced stand-by via communication

The following shows the behavior of an alarm with the stand-by action at power ON.



### Alarm Latch Function

The alarm latch function is a function for keeping the alarm output (keeping the alarm output on) after entering the alarm condition (alarm output is turned on) until an order to release the alarm latch is received.

The alarm latch function has the following four types of action.

#### Latch 1

Cancels the alarm output when an order to release the alarm latch is received. (Alarm output OFF.)

However, an order to release the alarm latch is ignored if the order is received during alarm condition.

#### Latch 2

Always forces cancelling of the alarm output when an order to release the alarm latch is received. (Alarm output OFF)


#### Latch 3

Cancels the alarm output when an order to release the alarm latch is received or when the alarm condition is removed. (Alarm output OFF.)

#### Latch 4

Cancels the alarm output when an order to release the alarm latch is received. (Alarm output OFF.)

However, cancels the alarm output for the duration of the sampling period (control period) if an order to release the alarm latch is received during alarm condition. (Alarm output OFF)




Contact type in the figure above: Energized when an event occurs (factory default).

**Release of Alarm Latch**

The alarm latch function can be cancelled by the user function key, or via communication. Cancelling the alarm latch function cancels all latched alarm outputs.

- ▶ Release by user function key: [13.2 Assigning Function to User Function Key and A/M key](#)
- ▶ Release via communication: [UTAdvanced Series Communication Interface User's Manual](#)




Contact type in the figure above: Energized when an event occurs (factory default).

**Operation of Alarm Output and Display Lamp (EV)**

The contact output and display lamp (EV) are usually output and displayed according to the setpoint of the alarm type. However, the alarm conditions (operations) of the normal action, and latch action can be assigned to the contact output and display lamp (EV), regardless of the setpoint of the alarm type. (Two operations can be assigned simultaneously.)


- ▶ Display lamp action: [13.1 Setting Display Functions](#)
- ▶ Contact output action: [12.2.1 Setting Function of Contact Output](#)

## Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
AL1 to AL4	Alarm-1 to -4 type	EASY	See the table below.	ALRM 
VT1 to VT4	PV velocity alarm time setpoint 1 to 4	EASY	00.01 to 99.59 (minute.second)	

Note1: The initial values of the parameters AL1 to AL4 and VT1 to VT4 are "4". The number of alarms can be changed using the parameter ALNO.

The following shows the example of setting PV high limit (01), With stand-by action (1), De-energized (1), and Latch 1 action (1).



Name	Latch action (Note 1)	Energized (0) / de-energized (1)	Stand-by action Without (0) / with (1)	Alarm type
Disable	- (Note 2)	- (Note 2)	- (Note 2)	00
PV high limit	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	01
PV low limit	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	02
SP high limit	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	03
SP low limit	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	04
Deviation high limit	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	05
Deviation low limit	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	06
Deviation high and low limits	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	07
Deviation within high and low limits	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	08
Target SP high limit	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	09
Target SP low limit	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	10
Target SP deviation high limit	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	11
Target SP deviation low limit	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	12
Target SP deviation high and low limits	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	13
Target SP deviation within high and low limits	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	14
Control output high limit	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	15
Control output low limit	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	16
Analog input PV high limit	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	19
Analog input PV low limit	0 / 1 / 2 / 3 / 4	0 / 1	0 / 1	20
PV velocity	0 / 1 / 2 / 3 / 4	0 / 1	- (Note 2)	29
Fault diagnosis	0 / 1 / 2 / 3 / 4	0 / 1	- (Note 2)	30
FAIL	- (Note 2)	- (Note 2)	- (Note 2)	31

Note 1: 0: No latch function, 1: Latch 1, 2: Latch 2, 3: Latch 3, 4: Latch 4

Note 2: -: Alarm function doesn't work even if any value is set.

## 11.2 Setting Number of Alarm Groups to Use

### Description

Up to four alarm groups of alarm type, alarm hysteresis, alarm (On-/Off-) delay timer, and alarm setpoint are available.

Unused alarm parameters can be hidden and their functions can be turned off.

The initial value of parameter ALNO. is "4."

When ALNO. = 4, for example, only the four groups of alarm type, PV velocity alarm time setpoint, alarm hysteresis, alarm delay timer, and alarm setpoint are displayed.

### Setting Details


Parameter symbol	Name	Display level	Setting range	Menu symbol
ALNO.	Number of alarm groups	PRO	0 to 4	CTL <b>Set</b>

# 11.3 Setting Hysteresis to Alarm Operation


## Description

If the On/Off switch of the alarm output is too busy, you can alleviate the busyness by increasing the alarm hysteresis.

### Hysteresis for PV High Limit Alarm



### When Setting Hysteresis of 5°C and 15°C for PV High Limit Alarm



## Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
HY1 to HY4	Alarm-1 to -4 hysteresis	EASY	Sets the hysteresis setpoint as a display value. -19999 to 30000 (set it within the input range) The decimal point position depends on the input type.	ALRM <b>Ope</b>




## 11.4 Delaying Alarm Output (Alarm Delay Timer)

### Description

The alarm on-delay timer is a function for turning on the alarm when the alarm condition occurs, and the timer starts and the set time elapses.

The timer is reset if the alarm condition is removed while the timer is running. No alarm is generated.

The figure below shows the example of the On-delay timer



Contact type in the figure above: Energized when an event occurs (factory default).

The alarm Off-delay timer is a function for turning off the alarm when the alarm condition is removed (normal condition), and the timer starts and the set time elapses.

The timer is reset if the alarm condition occurs again while the timer is running. The alarm is not cancelled.

### Setting Details


Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>DYN1 to DYN4</b>	Alarm-1 to -4 On-delay timer	STD	0.00 to 99.59 (minute.second)	ALRM <b>Ope</b>
<b>DYF1 to DYF4</b>	Alarm-1 to -4 Off-delay timer	PRO		

## 11.5 Setting Alarm Action According to Operation Mode

### Description

The alarm action usually functions regardless of operation modes. Setting the alarm mode allows the alarm action to be disabled in STOP or in STOP or MAN mode.

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
AMD	Alarm mode	STD	0: Always active 1: Not active in STOP mode 2: Not active in STOP or MAN mode	ALRM 



## 12.1 Contact Output Functions

### 12.1.1 Setting Function of Contact Output


#### Description

The contact output function works by setting a status such as an alarm to the contact output.

This explanation assumes that the contact type is energized. (The contact is turned on when an event occurs.)

#### Setting Details

##### Contact Output Equipped as Standard

Parameter symbol	Name	Display level	Setting range	Menu symbol
AL1.S	AL1 function selection	STD	See the following section.	ALM 
AL2.S	AL2 function selection	STD		

Note1: Nothing is displayed on Group display when each parameter is displayed.

##### Alarm Status

The alarm status can be output to the contact output. (The setpoints below are I relay numbers.)

▶ [I relay: UTAdvanced Series Communication Interface \(RS-485, Ethernet\) User's Manual](#)

Setpoint		Function
Alarm status	Alarm output status	
4321	4353	Alarm 1
4322	4354	Alarm 2
4323	4355	Alarm 3
4325	4357	Alarm 4

- Alarm status: The internal alarm status is turned on when an alarm occurs and turned off in normal condition
- Alarm output status: Contact output status when an alarm occurs (ON in alarm condition and OFF in normal condition)

However, the output status depends on the settings of energized/de-energized of alarm, latch action, and contact type.

The above assumes that the contact type is energized. (Then contact is turned on when an event occurs.)

To output the normal alarm to the contact output, assign the alarm output status.

▶ [Alarm action: 11.1 Setting Alarm Type](#)

## 12.1 Setting Contact Input Function

### Alarm Latch Status

The alarm latch status can be output to another contact output irrespective of the setting of alarm-1 to -4 type (AL1 to AL4). (The setpoints below are I relay numbers.)

▶ [I relay: UTAdvanced Series Communication Interface \(RS-485, Ethernet\) User's Manual](#)

Setpoint				Function
Alarm output latch 1 status	Alarm output latch 2 status	Alarm output latch 3 status	Alarm output latch 4 status	
4385	4417	4449	4481	Alarm 1
4386	4418	4450	4482	Alarm 2
4387	4419	4451	4483	Alarm 3
4389	4421	4453	4485	Alarm 4

- Alarm output latch 1, 2, 3, and 4 status: ON in the latch status of the contact output when an alarm occurs and OFF in the latch release status of the contact output in normal condition

However, the output status depends on the settings of contact type.

▶ [Alarm latch action: 11.1 Setting Alarm Type](#)

### Key and Display Status

The key and display status can be output to the contact output. (The setpoints below are I relay numbers.)

Setpoint	Function	Contact status	
		ON	OFF
4705	PARA key	Key is pressed	Key is not pressed
4706	DISP key		
4707	Right arrow key		
4708	Down arrow key		
4709	SET/ENTER key		
4710	Up arrow key		
4711	Left key		
4714	A/M key		
4715	Fn key		

### Operation Mode and Status

Setpoint	Function	Contact status	
		ON	OFF
4193	AUTO/MAN	MAN	AUTO
4194	Remote/Local	Remote	Local
4195	STOP/RUN	STOP	RUN
4201	Output tracking status	Tracking ON	Tracking OFF
4207	During auto-tuning	During AT	–
4256	FAIL output	Normal status	FAIL status

**System Error Status**

Setpoint	Function	Contact status	
		ON	OFF
4769	Message display interruption 1 status	With interruption	Without interruption
4770	Message display interruption 2 status	With interruption	Without interruption
4771	Message display interruption 3 status	With interruption	Without interruption
4773	Message display interruption 4 status	With interruption	Without interruption

**Error Status**

Setpoint	Function	Contact status	
		ON	OFF
4065	PV input ADC error	Error occurs	Normal
4073	PV input burnout error		
4070	PV input RJC error		
4097	PV input burnout error		
4101	PV input over-scale		
4102	PV input under-scale		
4111	Auto-tuning time out		

**System Error Status**

Setpoint	Function	Contact status	
		ON	OFF
4001	System data error	Error occurs	Normal
4002	Calibration value error		
4003	User (parameter) default value error		
4005	Setup parameter error		
4006	Operation parameter error		
4017	Corrupted ladder program		
4009	Faulty FRAM		

## 12.1 Setting Contact Input Function

### 12.1.2 Changing Contact Type of Contact Output

#### Description

The contact type can set the action direction of contact output assigned to the function.

#### Setting Details

##### Contact Output Equipped as Standard

Parameter symbol	Name	Display level	Setting range	Menu symbol
AL1.D	AL1 contact type	PRO	0: When the event of assigned function occurs, the contact output is closed. 1: When the event of assigned function occurs, the contact output is opened.	ALM <b>Set</b>
AL2.D	AL2 contact type	PRO		

Note1: Nothing is displayed on Group display when each parameter is displayed.

▶ [Terminal arrangement: 17.4 Wiring](#)

# 13.1 Setting Display Functions

## 13.1.1 Setting Active Color PV Display Function

The active color PV display function changes the PV display color when an event occurs.

**Description**

**Link to Alarm**


The PV display color changes by linking to the alarm 1 or alarm 2.

The following is an example of operation linking to alarm 1.

Set the alarm-1 type to "PV high limit alarm" and alarm-1 setpoint to "80°C."

When the active color PV display switch is set to "2," PV display color changes from white to red if PV exceeds the alarm-1 setpoint.

The red-to-white switching action can be set.




**Change by Deviation**

The PV display color changes by deviation (PV – SP).

Set the PV color change high limit to "10°C" and the PV color change low limit to "5°C" as deviation band for the current target setpoint "50°C." PV display color changes from white to red if PV is out of the deviation.

The red-to-white switching action can be set. There is no hysteresis.






**Link to PV**


The PV display color changes by linking to PV.

Set the PV color change high limit to “70°C” and the PV color change low limit to “20°C.”  
 PV display color changes from white to red if PV is out of the range.  
 The red-to-white switching action can be set. There is no hysteresis.




**Use in Fixed Color**

PV display color can be fixed in red. It can also be fixed in white.



## Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>PCMD</b>	Active color PV display switch	EASY	0: Fixed in white 1: Fixed in red 2: Link to alarm 1 (Alarm OFF: white, Alarm ON: red) 3: Link to alarm 1 (Alarm OFF: red, Alarm ON: white) 4: Link to alarm 1 or 2 (Alarm OFF: white, Alarm ON: red) 5: Link to alarm 1 or 2 (Alarm OFF: red, Alarm ON: white) 6: PV limit (Within range: white, Out of range: red) 7: PV limit (Within range: red, Out of range: white) 8: SP deviation (Within deviation: white, Out of deviation: red) 9: SP deviation (Within deviation: red, Out of deviation: white)	DISP 
<b>PCH</b>	PV color change high limit	EASY	Set a display value when in PV limit or SP deviation.	
<b>PCL</b>	PV color change low limit	EASY	-19999 to 30000 (Set a value within the input range.) Decimal point position depends on the input type.	

## 13.1 Setting Display Functions


### 13.1.2 Masking Arbitrary Display Value in Operation Display

#### Description

Display/non-display of the PV display, Setpoint display, and Status display in the Operation Display can be set.

Items that you do not want to display can be set to non-display. For example, when the Setpoint display is set to non-display, SP of the SP Display and OUT of the OUT Display are not displayed.

When an error at power-on or hardware malfunction error occurs, Operation display cannot be set to non-display.



#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
PV.D	PV display area ON/OFF	PRO	OFF: Nondisplay ON: Display	DISP <b>Set</b>
SP.D	Setpoint display area ON/OFF	PRO		
STS.D	Status display area ON/OFF	PRO		



## 13.1 Setting Display Functions

### 13.1.4 Changing Event Display

#### Description

The UT32A has four event (EV) lamps.  
The alarms 1 to 4 are assigned to EV1 to EV4.

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>EV1 to EV4</b>	EV1 to EV4 display condition registration	PRO	Setting range: 4001 to 6304 OFF: Disable 4321: Link to alarm 1 (Lit when the alarm occurs) 4322: Link to alarm 2 (Lit when the alarm occurs) 4323: Link to alarm 3 (Lit when the alarm occurs) 4325: Link to alarm 4 (Lit when the alarm occurs)  5153 to 5154: Link to AL1-AL2 (Lit when the contact is closed)  For other functions, see the UTAdvanced Series Communication Interface User's Manual.	DISP <b>Set</b>

Relay Number	Description	Reference in Communication Interface User's Manual
4001 to 4064	System error	Section 9.3.1
4065 to 4128	Input error	
4129 to 4192	Free area	
4193 to 4256	Operation mode	
4257 to 4320	Free area	
4321 to 4384	Alarm	
4385 to 4528	Alarm latch	
4577 to 4640	SP number and PID number	
4641 to 4704	Free area	
4705 to 4768	Key	
4769 to 4832	Display	
4833 to 5024	Free area	
5025 to 5152	Input relay	
5153 to 5280	Output relay	
5281 to 5408	Control computation output	
5409 to 5472	Special relay	
5473 to 5536	Free area	
5537 to 5792	Internal relay	
5793 to 6048	Free area	
6433 to 6560	DO terminals	

### 13.1.5 Registering SELECT Parameter Display (Up to 10 Displays)


**Description**

Registering frequently changed operation parameters (change frequency is lower than SELECT Display) in the SELECT Parameter Display will allow you to change parameter settings easily. A maximum of ten Displays can be registered.

Set the D register number of the parameter you wish to register for the registration to the SELECT Parameter Display.

However, the parameters in the following menus cannot be set:  
 CTL, PV, MPV, OUT, R485, KEY, DISP, CSEL, KLOC, MLOC, ALM, I/O, SYS, INIT, VER, and LVL.

When each parameter is displayed, the terminal area (E1) is displayed on Group display according to the suffix code.



## 13.1 Setting Display Functions

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>CS10 to CS19</b>	SELECT parameter-10 to -19 registration	PRO	OFF: No registration D register number (2301 to 5000)	CSEL <b>Set</b>

For D register numbers, see sections 8.4.2 and 8.4.5 of UTAdvanced Series Communication Interface User's Manual.


D Resistor Number	Category	Description	Reference in Communication Interface User's Manual
2301 to 2500	Operation Mode Parameters	Operation Mode	Section 8.4.2
2501 to 2700	Operation Parameters	SPs and alarm setpoints setting	Section 8.4.3
2701 to 2800		SP-related settings	
2801 to 2900		Alarm function settings	
2901 to 3000		PV-related settings	
3001 to 3500		PID settings	
3501 to 3600		Control action-related settings	

### 13.1.6 Setting Bar-graph Display Function

**Description**


The bar-graph display is provided on the front of the controller. PV or OUT can be displayed. Data which can be displayed on Bar-graph display are as follows.

**OUT, Output**




For relay, OFF is equivalent to 0% and ON is equivalent to 100%.

**PV, SP**




**Deviation**

When the deviation display band (BDV) is 10%:



Deviation negative side and deviation positive side are displayed by 10% increment of deviation. Indication is unlit when  $SP - (\text{deviation display band (BDV)}) \leq PV \leq SP + (\text{deviation display band (BDV)})$ .


IN = TC Type K -270.0 to 1370.0°C  
 BDV = 82°C (5%), SP = 500.0°C, PV = 800.0°C





## 13.1 Setting Display Functions

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>BAR1</b>	Bar-graph display registration	STD	0: Disable 1:OUT 3: PV 4: SP 5: Deviation 6 to 16: Disable 18: PV terminals analog input 27: TSP 28: Deviation between the TSP	DISP 
<b>BDV</b>	Bar-graph deviation display band	STD	0.0 to 100.0% of PV input range span (EUS)	

Note1: The bar-graph deviation display band (BDV) is enabled when the deviation is set to the BAR1.

### 13.1.7 Masking Least Significant Digit of PV Display

#### Description

With and without least significant digit of the PV in the Operation Display can be set. When without least significant digit is set, the value of the least significant digit is truncated and not displayed. The internal value is not changed depending on whether with or without least significant digit (the value is for display only). This parameter does not function for the PV without decimal point.

Least significant digit is displayed.



Least significant digit is not displayed.



The following shows the example of with and without least significant digit

PV display		
With least significant digit	Without least significant digit	
	Truncated	Not displayed
1.4999	1.499	1500
1.5000	1.500	1500
1.9999	1.999	2000
2.0000	2.000	2000
3000.0	3000	3000
3000.9	3000	3001
3001.0	3001	3001

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>MLSD</b>	Least significant digital mask of PV display	STD	OFF: With least significant digit ON: Without least significant digit	DISP <b>Set</b>
<b>MKTP</b>	Method for least significant digital mask of PV display	STD	0: Rounding 1: Rounding-off	

### 13.1.8 Setting Economy Mode

#### Description

The LCD backlight ON/OFF can be set in the following methods.  
Setting the LCD backlight to OFF saves energy.

#### User Function Keys

The LCD backlight ON/OFF switch can be assigned to the user function key.  
▶ [User function key: 13.2 Assigning Function to User Function Key and A/M Key](#)


#### Backlight OFF timer

The backlight OFF timer sets the economy mode parameter to ON.  
If no keys are pressed for 30 minutes, the LCD backlight goes off automatically.  
The backlight OFF can be set to turn off the backlight for the whole display or a display other than the PV display.  
To turn on the LCD backlight, press any key.

In the following cases, the LCD backlight does not go off.

- when an alarm occurs
- When an error at power-on or a hardware malfunction error occurs

#### Setting Details


Parameter symbol	Name	Display level	Setting range	Menu symbol
ECO	Economy mode	STD	OFF: Disable 1: Economy mode ON (All indications except PV display OFF) 2: Economy mode ON (All indications OFF) 3: Brightness 10 % (all indications)	DISP 

### 13.1.9 Selecting the Initial Operation Display that Appears at Power ON

#### Description

The initial Operation Display that appears when the power is turned on can be set.

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
HOME	Home Operation Display setting	PRO	SP1: SP Display OUT1: OUT Display PID1: PID Number Display PV: PV Analog Input Display CS1 to CS5: SELECT Display 1 to 5 PVO: PV Display	DISP 

### 13.1.10 Switching Guide Display Language

#### Description

The guide display language that appears when the parameter or the menu is displayed can be switched.

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
LANG	Guide display language	EASY	ENG: English FRA: French GER: German SPA: Spanish	SYS <b>Set</b>

### 13.1.11 Changing Guide Scroll Speed

#### Description

The scroll speed can be changed when the guide for the parameter or menu is displayed.

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
SPD	Scroll speed	PRO	(Slow) 1 to 8 (Quick)	DISP <b>Set</b>

### 13.1.12 Turning Guide Display ON/OFF

#### Description

The guide display that appears when the parameter or the menu is displayed can be switched.

The guide display can be turned on and off by the Fn key in the Menu Display and Parameter Setting Display.

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
GUID	Guide display ON/OFF	STD	OFF: Nondisplay ON: Display	DISP <b>Set</b>

## 13.1 Setting Display Functions

### 13.1.13 Setting Automatic Return to Operation Display

#### Description

The Display will automatically revert to the Operation Display if no keys are pressed for 5 minutes in Menu Display or Parameter Setting Display.

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
OP.JP	Automatic return to Operation Display	PRO	ON: Automatically returned to the Operation Display. OFF: Not automatically returned to the Operation Display.	DISP <b>Set</b>

### 13.1.14 Setting Brightness and Contrast Adjustment of LCD and Display Update Cycle

#### Description

The brightness and contrast for PV, Setpoint, Bar-graph, and Status indicator can be adjusted.

Brightness ranges for each display can be set.

The LCD has a characteristic that the display action becomes late at the low temperature. This can be solved by adjusting the display update cycle (D.CYC).

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
BRI	Brightness	EASY	(Dark) 1 to 5 (Bright)	DISP <b>Set</b>
B.PVW	White brightness adjustment of PV display	PRO	Adjusts the white brightness of PV display. (Dark) -4 to 4 (Bright)	
B.PVR	Red brightness adjustment of PV display	PRO	Adjusts the red brightness of PV display. (Dark) -4 to 4 (Bright)	
B.SP	Brightness adjustment of Setpoint display	PRO	Adjusts the brightness of SP display. (Dark) -4 to 4 (Bright)	
B.BAR	Brightness adjustment of Bar-graph display	PRO	Adjusts the brightness of SP display. (Dark) -4 to 4 (Bright)	
B.STS	Brightness adjustment of Status indicator	PRO	Adjusts the brightness of Status indicator. (Dark) -4 to 4 (Bright)	
D.CYC	Display update cycle	PRO	1: 100 ms 2: 200 ms 3: 500 ms 4: 1 s 5: 2 s	

## 13.2 Assigning Function to User Function Key and A/M Key

### Description


The UT32A has one user function key on the front panel. Various functions (operation mode switch etc.) can be assigned to the user function key. Press the user function key to perform the assigned function. The User function key is available only on the Operation Display. The assigned function does not work on the Parameter Setting Display. However, the Fn key can be used to turn on/off the guide display.



User function keys

### 13.2 Assigning Function to User Function Key and A/M Key

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>Fn</b>	User function key action setting	EASY	See the table below	KEY 
<b>A/M</b>	A/M key action setting	PRO		

Setpoint	Function	Action	Availability (Note 1)			
			F1	F2	Fn	A/M
OFF	Unassigned	–	√	√	√	√
A/M	AUTO/MAN switch	AUTO and MAN switches every time the user function key is pressed.	√	√	√	√√
R/L1	REM/LCL switch	Remote and Local switches every time the user function key is pressed. (Displayed only in cases where the communication is specified.)	√	√	√	√
S/R	STOP/RUN switch	STOP and START switches every time the user function key is pressed.	√	√	√	√
AUTO	Switch to AUTO	Pressing the user function key switches to AUTO.	√	√	√	√
MAN	Switch to MAN	Pressing the user function key switches to MAN.	√	√	√	√
REM1	Switch to REM	Pressing the user function key switches to Remote. (Displayed only in cases where the communication is specified.)	√	√	√	–
LCL1	Switch to LCL	Pressing the user function key switches to Local. (Displayed only in cases where the communication is specified.)	√	√	√	–
STOP	Switch to STOP	Pressing the user function key stops the operation.	√	√	√	–
RUN	Switch to RUN	Pressing the user function key starts the operation.	√	√	√	–
AT	Auto-tuning	Pressing the user function key executes auto-tuning	√	√	√	–
LTUP	LCD brightness UP	The current brightness gradually increases every time the function key is pressed.	√	√	√	–
LTDN	LCD brightness DOWN	The current brightness gradually decreases every time the function key is pressed.	√	√	√	–
BRI	Adjust LCD brightness	The current brightness gradually increases every time the function key is pressed. Pressing the function key after reaching the maximum brightness changes to the minimum brightness. Thereafter, minimum brightness→maximum brightness→maximum brightness is repeated.	√	√	√	–
LCD	LCD Backlight ON/OFF switch	The LCD backlight turns on and off every time the user function key is pressed.	√	√	√	–
LAT	Latch release	Latch 1 to latch 4 are released every time the user function key is pressed.	√	√	√	–
PID	PID Tuning switch	Pressing the function key during operation displays the first parameter (proportional band) of the currently selected PID parameter group and enables the setting to be changed. As with the operation to change the parameter setpoint, the sequence is P→I→D→...→P→... Pressing the function key again, or pressing the DISP key returns to the initial Operation Display. The PARA key does not switch to the Menu Display.	√	√	√√	–

Note 1: √ indicates available, – indicates unavailable, and √√ indicates initial value.

### Status of user function key

The status of the user function key can be identified by communication.

“1” can be read while the user function key is held down, and “0” can be read when the user function key is released. (Initial value: 0)

▶ [Reading via communication: UTAdvanced Series Communication Interface User's Manual](#)

### Fn key operation in the Parameter Setting Display

In the Menu Display and Parameter Setting Display, the guide is displayed on PV display. At this time, use the Fn key to turn on and off the guide display on PV display. A measured input value (PV) is displayed in the ON state.



## 13.3 Setting Security Functions

### 13.3.1 Setting/canceling a Password

#### Description

The password function can prevent inadvertent changes to the parameter settings. If a password is set, the checking is required when moving to the Setup Parameter Setting Display. When the password is verified, can be changed to the Setup Parameter Setting Display. The parameters in the following menu can be set only when the password is verified.

CTL, PV, MPV, OUT, R485, KEY, DISP, CSEL, KLOC, MLOC, ALM, I/O, SYS, INIT, VER, and LVL.

When each parameter is displayed, the terminal area (E1) is displayed on Group display according to the suffix code.

Always remember your password when using the password function.

パスワードを解除する場合は、パラメータ PASS に「0」を設定することによりパスワードが解除されます。

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
PASS	Password setting	EASY	0 (No password) to 65535	SYS <b>Set</b>

### 13.3.2 Setting Parameter Display Level

#### Description

Parameter display level can be set according to the setting level.

▶ [Parameter display level: Chapter 18 Parameters](#)

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
LEVL	Parameter display level	EASY	EASY: Easy setting mode STD: Standard setting mode PRO: Professional setting mode	LVL <b>Set</b>

### 13.3.3 Locking (Hiding) Parameter Menu Display

#### Description

The parameter menu display lock function hides the following Parameter Menu Displays.

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>CTL</b>	[CTL] menu lock	PRO	OFF: Display ON: Nondisplay	MLOC <b>Set</b>
<b>PV</b>	[PV] menu lock	PRO		
<b>MPV</b>	[MPV] menu lock	PRO		
<b>OUT</b>	[OUT] menu lock	PRO		
<b>R485</b>	[R485] menu lock	PRO		
<b>KEY</b>	[KEY] menu lock	PRO		
<b>DISP</b>	[DISP] menu lock	PRO		
<b>CSEL</b>	[CSEL] menu lock	PRO		
<b>KLOC</b>	[KLOC] menu lock	PRO		
<b>ALM</b>	[ALM] menu lock	PRO		
<b>DO</b>	[DO] menu lock	PRO		
<b>I/O</b>	[I/O] menu lock	PRO		
<b>SYS</b>	[SYS] menu lock	PRO		
<b>INIT</b>	[INIT] menu lock	PRO		
<b>VER</b>	[VER] menu lock	PRO		
<b>LVL</b>	[LVL] menu lock	PRO	OFF: Display ON: Nondisplay	MLOC <b>Set</b>
<b>MODE</b>	[MODE] menu lock	PRO		
<b>CS</b>	[CS] menu lock	PRO		
<b>SP</b>	[SP] menu lock	PRO		
<b>SPS</b>	[SPS] menu lock	PRO		
<b>ALRM</b>	[ALRM] menu lock	PRO		
<b>PVS</b>	[PVS] menu lock	PRO		
<b>PID</b>	[PID] menu lock	PRO		
<b>TUNE</b>	[TUNE] menu lock	PRO		
<b>ZONE</b>	[ZONE] menu lock	PRO		

Note1: When each parameter is displayed, the terminal area (E1) is displayed on Group display according to the suffix code and optional suffix code.


### 13.3 Setting Security Functions

#### 13.3.4 Key Lock

##### Description

The key lock function locks the key on the front panel to prohibit key operation. It can prohibit the operation mode switch or parameter setting change.

##### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>DATA</b>	Front panel parameter data key lock	STD	OFF: Unlock ON: Lock	KLOCK 
<b>A/M</b>	Front panel A/M key lock	STD		


#### 13.3.5 Setting Display/Non-display of Operation Display

##### Description

Display/non-display of the Operation Display can be set.

▶ [Operation Display: Chapter 6 Monitoring and Control of Regular Operations](#)

##### Setting Details


Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>U.SP</b>	SP Display lock	PRO	OFF: Display ON: Nondisplay	KLOC 
<b>U.OUT</b>	OUT Display lock	PRO		
<b>U.PID</b>	PID Number Display lock	PRO		
<b>U.PV</b>	PV Analog Input Display lock	PRO		
<b>U.PVO</b>	PV Display lock	PRO		

#### 13.3.6 Prohibiting Writing via Communication

##### Description

Writing data to each register via all communication methods can be permitted or prohibited. However, writing data via light-loader (front) or maintenance port (upper) is possible using LL50A Parameter Setting Software.

##### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>COM.W</b>	Communication write enable/disable	STD	OFF: Enable ON: Disable	KLOC 

Displayed only in cases where the communication is specified.

# 13.4 Confirmation of Key and I/O Condition and Version

## 13.4.1 Confirmation of Key and I/O Condition

### Description

Can be confirm the Key and I/O condition.


### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
KEY	Key status	PRO	Read only.	I/O <b>Set</b>
Y000	AL1-AL3 status (equipped as standard)	PRO		

Note: When each parameter is displayed, the terminal area (E1) is displayed on Group display according to the suffix code.

Key confirmation parameters are displayed in hexadecimal.

When the error occurs, "1" is set on the bit of corresponding error, and the bit data is displayed in hexadecimal.



Parameter KEY

Displayed digit	bit	Description
1st digit	0	PARA key (0: OFF, 1: ON)
	1	DISP key (0: OFF, 1: ON)
	2	RIGHT arrow key (0: OFF, 1: ON)
	3	DOWN arrow key (0: OFF, 1: ON)
2nd digit	4	SET/ENTER key (0: OFF, 1: ON)
	5	UP arrow key (0: OFF, 1: ON)
	6	LEFT arrow key (0: OFF, 1: ON)
	7	—
3rd digit	8	—
	9	A/M key (0: OFF, 1: ON)
	10	Fn key (0: OFF, 1: ON)
	11	—
4th digit	12	—
	13	—
	14	—
	15	—

## 13.4 Confirmation of Key and I/O Condition and Version

### Parameter Y000

Displayed digit	bit	Description
1st digit	0	AL1 status (0: OFF, 1: ON)
	1	AL2 status (0: OFF, 1: ON)
	2	–
	3	–
2nd digit	4	–
	5	–
	6	–
	7	–
3rd digit	8	–
	9	–
	10	–
	11	–
4th digit	12	–
	13	–
	14	–
	15	–

### 13.4.2 Confirmation of Version

#### Description

Can be confirm the version of the controller.

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>MCU</b>	MCU version	EASY	Read only.	VER <b>Set</b>
<b>DCU</b>	DCU version	EASY		
<b>ECU1</b>	ECU-1 version	EASY		
<b>PARA</b>	Parameter version	EASY		
<b>H.VER</b>	Product version	EASY		
<b>SER1</b>	Serial number 1	EASY		
<b>SER2</b>	Serial number 2	EASY		

## 14.1 Initializing Parameter Settings to Factory Default Values

### Description

Parameter settings can be initialized to the factory default values. The ladder program is also initialized to the factory default. Use the key or LL50A Parameter Setting Software to execute it.

### Note

The user setting values (defaults) are not initialized even if the parameter setting values are initialized to the factory default values.

### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>F.DEF</b>	Initialization to factory default value	PRO	-12345: Initialization, automatically returned to "0" after initialization.	INIT <b>Set</b>

## 14.2 Registering and Initializing User Default Values

### 14.2.1 Registering as User Setting (Default) Values

#### Description

The user default values can be registered as parameter default values.  
The ladder program can not be registered as user default values.  
Use the LL50A Parameter Setting Software to register user setting (default) values.

#### CAUTION

Before registering the user default value, make sure that the user setting value is set to the parameter.

### 14.2.2 Initializing to User Setting (Default) Values

#### Description

Parameter settings can be initialized to the user setting (default) values.  
The ladder program is not initialized to the factory default.  
Use the LL50A Parameter Setting Software to execute it.

#### Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
U.DEF	Initialization to user default value	PRO	12345: Initialization, automatically returned to "0" after initialization.	INIT <b>Set</b>

# 15.1 Remedies if Power Failure Occurs during Operations

## Description

The operation status and remedies after a power failure differ with the length of power failure time:

Regardless of the length of power failure time, all functions of the controller cannot be operated for about 10 seconds after recovery. However, the case of instantaneous power failure is excepted.

- 100–240 V AC: Instantaneous power failure of 20 ms or less
- 24 V AC/DC: Instantaneous power failure of 1 ms

A power failure is not detected. Normal operation continues.

- Power failure of about less than 5 seconds

The following shows effects caused in “settings” and “operation status.”

Alarm action	Does not continue. Alarm with stand-by function will enter stand-by status. Alarm latch will be initialized.
Setting parameter	Set contents of each parameter are retained.
Auto-tuning	Cancelled.
Control action	Action before power failure continues.
Timer, counter (ladder program)	Initialized.

- Power failure of about 5 seconds or more

The following shows effects caused in “settings” and “operation status.”

Alarm action	Does not continue. Alarm with stand-by function will enter stand-by status. Alarm latch will be initialized.	
Setting parameter	Set contents of each parameter are retained.	
Auto-tuning	Cancelled.	
Control action	Differs with setting of the parameter “R.MD” (restart mode).	
	R.MD setting	Control action after recovery from power failure
	<b>CONT</b>	Continues action before power failure. (Factory default)
	<b>MAN (*)</b>	Outputs the preset output value (PO) of the PID group used as control output and continues action in MAN mode.
	<b>AUTO (*)</b>	The control computation is executed in AUTO mode based on the preset output value (PO) of the PID group used as control output.

## Setting Details

Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>R.MD</b>	Restart mode	STD	CONT: Continue action set before power failure. MAN: Start from MAN. AUTO: Start from AUTO.	SYS <b>Set</b>



## 15.2 Power Frequency Setting

### Description

The power frequency can be set by automatic detection or manually. However, when the /DC option is specified, only manual setting is available. Set the range to the commercial frequency of the installation location.

### Setting Details


Parameter symbol	Name	Display level	Setting range	Menu symbol
<b>FREQ</b>	Power frequency	EASY	AUTO 60: 60 Hz 50: 50 Hz	SYS <b>Set</b>

# 16.1 Troubleshooting

## 16.1.1 Troubleshooting Flowchart

If the Operation Display does not appear after turning on the controller's power, follow the measures in the procedure below.

If a problem appears complicated, contact our sales representative.



\*: The LCD (a liquid crystal display) is used for a display portion of this product. The LCD has a characteristic that the display action becomes late at the low temperature. Additionally, the luminance and contrast degradation are caused due to aged deterioration. However, the control function is not affected.

## 16.1.2 Errors at Power On

The errors shown below may occur in the fault diagnosis when the power is turned on.

PV display (Operation Display)	Setpoint display (Operation Display)	Status indicator (Operation Display)	Parameter that displays error details	Error description	Cause and diagnosis	Remedy
Indication off	Indication off	—	—	Faulty MCU RAM / MCU ROM	MCU RAM / MCU ROM are failed.	Faulty. Contact us for repair.
ERR	SYS -----	—	—	System data error	System data is corrupted.	Faulty. Contact us for repair.
	PAR 0004 (for user default value error only)			User (parameter) default value error	User parameter is corrupted. Initialized to factory default value.	Check and reconfigure the initialized parameters. Error indication is erased when the power is turned on again.
	PAR 0010 (for setup parameter error only)			Setup parameter error	Setup parameter data is corrupted. Initialized to factory default value.	
	PAR 0020 (for operation parameter error only)			Operation parameter error	Operation parameter data is corrupted. Initialized to user default value.	
	PAR 0400			Control parameter (operation mode, output) error	Control parameter data is corrupted. Initialized to user default value.	
SLOT 0001 (0001: Error occurs to all hardware of E1 -terminal areas.)	—	Setup parameter (OP.ER)	Non responding hardware of extended function (E1-terminal areas)	Inconsistence of system data and hardware of extended function. Non responding communication between hardware of extended function (E1-terminal areas).	Faulty. Contact us for repair.	
Normal indication	Normal indication	Rightmost decimal point on PV display blinks.	Setup parameter (PA.ER)	Calibration value error	Initialized to calibrated default value because of corrupted factory default value.	Faulty. Contact us for repair.
		Right most decimal point on Symbol display blinks.		Faulty FRAM	Writing (storing) data to FRAM is impossible.	

Errors at Power On (Input/output Action)

Error description	PV input	Ladder calculation	Control computation	Control output	Retransmission output	Alarm action	Analog output (control output, retransmission output)	Voltage pulse output (control output)	Relay output (control output)	Contact (alarm) output	Communication
Faulty MCU RAM Faulty MCU ROM	Undefined	Stopped	Stopped	Undefined	Undefined	Stopped	0% or less	OFF	OFF	OFF	Stopped
System data error	Undefined	Stopped	Stopped	Undefined	Undefined	Stopped	0% or less	OFF	OFF	OFF	Normal action
User (parameter) default value error	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action
Setup parameter error											
Operation parameter error											
Control parameter error	Undefined	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action
Non responding hardware of extended function (E1-terminal areas)											
Calibration value error	Normal action (out of accuracy)	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action (out of accuracy)	Normal action	Normal action	Normal action	Normal action
Faulty FRAM	Normal action						Normal action				

### 16.1.3 Errors during Operation

#### Errors during Operation (1)

The errors shown below may occur during operation.

PV display (Operation Display)	Setpoint display (Operation Display)	Status indicator (Operation Display)	Parameter that displays error details	Error description	Cause and diagnosis	Remedy
AD.ERR	Normal indication (Note)	–	Setup parameter (AD1.E)	Analog input terminal ADC error • PV input	Analog input terminal AD value error	Faulty Contact us for repair.
RJC.E (Displays RJC.E and PV alternately.)	Normal indication (Note)	–	Setup parameter (AD1.E)	Universal input terminal RJC error • PV input	Universal input terminal RJC error	Faulty Contact us for repair. Set the parameter RJC to OFF to erase error indication.
B.OUT	Normal indication (Note)	–	Setup parameter (AD1.E)	Analog input terminal burnout error • PV input	Analog input terminal sensor burnout	Check wiring and sensor. Error indication is erased in normal operation.
			Setup parameter (PV1.E)	PV input burnout error	Burnout of analog input connected to PV	Check wiring and sensor of connected analog input terminal. Error indication is erased in normal operation.
OVER -OVER	Normal indication	–	Setup parameter (PV1.E)	PV input over-scale PV input under-scale (PV values out of -5 to 105%)	PV input is out of -5 to 105%. Also occurs when the data out of range which is the ladder computation result is input.	Check analog input value or ladder program.

Note: When an error occurs in input shown in Analog input display (Operation display).  
Setpoint display shows the same symbol as the PV display.

Errors during Operation (Input/output Action)

Error description	PV input	Ladder calculation	Control computation	Control output	Retransmission output	Alarm action	Analog output (control output, retransmission output)	Voltage pulse output (control output)	Relay output (control output)	Contact (alarm) output	Communication
Analog input terminal ADC error • PV input	105%	Normal action	Normal action	When in AUTO and RUN modes: Error preset output When in MAN mode: MAN output	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action
Universal input terminal RJC error • PV input	Normal action (without reference junction compensation)	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action
Analog input terminal burnout error • PV input	Depends on the parameter BSL. Upscale: 105% Downscale: -5%	Normal action	Normal action	When in AUTO and RUN modes: Error preset output When in MAN mode: MAN output	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action
PV input burnout error	Depends on the setting of the parameter BSL. Upscale: 105% Downscale: -5%										
PV input over-scale PV input under-scale (PV values out of -5 to 105%)	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action

## Errors during Operation (2)

The errors shown below may occur during operation.

PV display (Operation Display)	Setpoint display (Operation Display)	Status indicator (Operation Display)	Parameter that displays error details	Error description	Cause and diagnosis	Remedy
AT,E	Normal indication	–	Setup parameter (PV1.E)	Auto-tuning time-out	Auto-tuning does not end even when 24 hours have elapsed after the start of tuning.	Check the process. Hold down any key to erase the error indication
Normal indication	0.000 00000 (Decimal point on the left of the Symbol display blinks)	–	Setup parameter (OP.ER)	Communication error (RS-485 communication)	Framing parity error Buffer overflow Inter-character time-out Checksum error (PC link communication with checksum) CRC check error (Modbus/RTU) LRC check error (Modbus/ASCII)	Check the communication parameters. Recovery at normal receipt. Hold down any key to stop blinking.
Normal indication	0.000 00000 (Decimal point on the left of the Symbol display blinks)	–	Setup parameter (OP.ER)	Communication error (coordinated operation)	Inconsistence of loop between coordinated master and slaves Communication from coordinated master is interrupted for 2 seconds.	Check the communication parameters. Recovery at normal receipt. Change from remote to local mode to stop blinking. When the mode is changed from remote to local, SP tracking does not work even if it is set to ON.
Normal indication	Normal indication	Rightmost decimal point on Symbol display blinks.	Setup parameter (PA.ER)	Faulty FRAM	Writing (storing) data to FRAM is impossible.	Faulty. Contact us for repair.

Errors during Operation (Input/output Action)

Error description	PV input	Ladder calculation	Control computation	Control output	Retransmission output	Alarm action	Analog output (control output, retransmission output)	Voltage pulse output (control output)	Relay output (control output)	Contact (alarm) output	Communication
Auto-tuning time-out	Normal action	Normal action	Auto-tuning stopped, normal action	Auto-tuning stopped, Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action
Communication error (RS485 communication)	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action
Communication error (coordinated operation) Inconsistence of loop between coordinated master and slaves	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action
Communication error (coordinated operation) Communication from coordinated master is interrupted for 2 seconds.	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action
Faulty FRAM	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action	Normal action



### Errors during Operation (3)

The errors shown below may occur during operation.

PV display (Operation Display)	Data display (Operation Display)	Status indicator (Operation Display)	Parameter that displays error details	Error description	Cause and diagnosis	Remedy
Undefined	Undefined	–	–	Faulty MCU	MCU is corrupted.	Faulty Contact us for repair.
Undefined	Undefined	–	–	Faulty DCU (ROM/RAM error, corrupted)	DCU is corrupted.	Faulty Contact us for repair.

### Errors during Operation On (Input/output Action)


Error description	PV input	Ladder calculation	Control computation	Control output	Retransmission output	Alarm action	Analog output (control output, retransmission output)	Voltage pulse output (control output)	Relay output (control output)	Contact (alarm) output	Communication
Faulty MCU	Undefined	Stopped	Stopped	Undefined	Undefined	Stopped	0% or less	OFF	OFF	OFF	Stopped
Faulty DCU (ROM/RAM error, corrupted)	Undefined	Stopped	Stopped	Undefined	Undefined	Stopped	0% or less	OFF	OFF	OFF	Stopped

## Hexadecimal Display on Setpoint Display (Operation Display)

Some error codes are displayed in hexadecimal.

When the error occurs, "1" is set on the bit of corresponding error, and the bit data is displayed in hexadecimal.


If the setup parameter error or the operation parameter errors occur, it is displayed as follows:



Displayed digit	bit	Description
1st digit	0	System data error
	1	Calibration value error
	2	User (parameter) default value error
	3	—
2nd digit	4	Setup parameter error
	5	Operation parameter error
	6	—
	7	—
3rd digit	8	Faulty FRAM
	9	—
	10	Control parameter error
	11	—
4th digit	12	—
	13	—
	14	—
	15	—

## 16.1 Troubleshooting


If the hardware in E1-terminal area does not respond, it is displayed as follows:



Displayed digit	bit	Description
1st digit	0	Non responding hardware in E1-terminal area
	1	–
	2	–
	3	–
2nd digit	4	–
	5	–
	6	–
	7	–
3rd digit	8	Communication error in E1-terminal area
	9	–
	10	–
	11	–
4th digit	12	–
	13	–
	14	–
	15	–

## Hexadecimal Display of the Parameter which Shows the Error Details

Error confirmation parameters are displayed in hexadecimal.  
When the error occurs, "1" is set on the bit of corresponding error.



### Parameter PA.ER

Displayed digit	bit	Description
1st digit	0	System data error
	1	Calibration value error
	2	User (parameter) default value error
	3	–
2nd digit	4	Setup parameter error
	5	Operation parameter error
	6	–
	7	–
3rd digit	8	Faulty FRAM
	9	–
	10	Control parameter error
	11	–
4th digit	12	–
	13	–
	14	–
	15	–

## 16.1 Troubleshooting

### Parameter OP.ER

Displayed digit	bit	Description
1st digit	0	Non responding hardware in E1-terminal area
	1	–
	2	–
	3	–
2nd digit	4	–
	5	–
	6	–
	7	–
3rd digit	8	Communication error in E1-terminal area
	9	–
	10	–
	11	–
4th digit	12	–
	13	–
	14	–
	15	–

### Parameter AD1.E

Displayed digit	bit	Description
1st digit	0	ADC error of PV input
	1	–
	2	–
	3	–
2nd digit	4	–
	5	RJC error of PV input
	6	–
	7	–
3rd digit	8	PV input burnout error
	9	–
	10	–
	11	–
4th digit	12	–
	13	–
	14	–
	15	–

### Parameter PV1.E

Displayed digit	bit	Description
1st digit	0	PV input burnout error
	1	–
	2	–
	3	–
2nd digit	4	PV input over-scale
	5	PV input under-scale
	6	–
	7	–
3rd digit	8	–
	9	–
	10	–
	11	–
4th digit	12	–
	13	–
	14	Auto-tuning time-out
	15	–

---

## 16.2 Maintenance

### 16.2.1 Cleaning

The front panel and operation keys should be gently wiped with a cloth soaked with water and squeezed firmly.

---

#### **CAUTION**

In order to prevent LCD from static electricity damage, do not wipe with dry cloth. (When LCD is electrified, it returns to normal in several minutes.)  
Do not use alcohol, benzene, or any other solvents.

---

### 16.2.2 Packaging when Shipping the Product for Repair

Should the instrument break down and need to be shipped to our sales representative for repair, handle it as noted below:

---

#### **CAUTION**

Write down the settings of parameters for a repair request.

---

---

#### **WARNING**

Prior to shipping the instrument, put it into an antistatic bag and repackage it using the original internal packaging materials and packaging container.

---

### 16.2.3 Replacing Parts

Do not replace any parts inside the unit.

---

## **16.3 Periodic Maintenance**

Check the operating condition periodically to use this instrument with good condition.

---

## 16.4 Disposal

When disposing of this instrument, arrange for appropriate disposal as industrial waste according to the rules of a country, the area, or a local government.






## 17.1 Installation Location

The instrument should be installed in indoor locations meeting the following conditions:

- Instrumented panel  
This instrument is designed to be mounted in an instrumented panel. Mount the instrument in a location where its terminals will not inadvertently be touched.
- Well ventilated locations  
Mount the instrument in well ventilated locations to prevent the instrument's internal temperature from rising. However, make sure that the terminal portions are not exposed to wind. Exposure to wind may cause the temperature sensor accuracy to deteriorate. To mount multiple indicating controllers, see the external dimensions/ panel cutout dimensions which follow. If mounting other instruments adjacent to the instrument, comply with these panel cutout dimensions to provide sufficient clearance between the instruments.
- Locations with little mechanical vibration  
Install the instrument in a location subject to little mechanical vibration.
- Horizontal location  
Mount the instrument horizontally and ensure that it is level, with no inclination to the right or left.



### Note


If the instrument is moved from a location with low temperature and low humidity to a place with high temperature and high humidity, or if the temperature changes rapidly, condensation will result. Moreover, in the case of thermocouple inputs, measurement errors will result. To avoid such a situation, leave the instrument in the new environment under ambient conditions for more than 1 hour prior to using it.

## 17.1 Installation Location

---

Do not mount the instrument in the following locations:

- Outdoors
- Locations subject to direct sunlight, ultrared rays, ultraviolet rays, or close to a heater  
Install the instrument in a location with stable temperatures that remain close to an average temperature of 23°C. Do not mount it in locations subject to direct sunlight or close to a heater. Doing so adversely affects the instrument and LCD.
- Locations with substantial amounts of oily fumes, steam, moisture, dust, or corrosive gases  
The presence of oily fumes, steam, moisture, dust, or corrosive gases adversely affects the instrument. Do not mount the instrument in locations subject to any of these substances.
- Areas near electromagnetic field generating sources  
Do not place magnets or tools that generate magnetism near the instrument. If the instrument is used in locations close to a strong electromagnetic field generating source, the magnetic field may cause measurement errors.
- Locations where the display is difficult to see  
The instrument uses an LCD for the display unit, and this can be difficult to see from extremely oblique angles. Mount the instrument in a location where it can be seen as much as possible from the front.
- Areas close to flammable articles  
Absolutely do not place the instrument directly on flammable surfaces. If such a circumstance is unavoidable and the instrument must be placed close to a flammable item, provide a shield for it made of 1.43 mm thick plated steel or 1.6 mm thick unplated steel with a space of at least 150 mm between it and the instrument on the top, bottom and sides.



- Areas subject to being splashed with water

## 17.2 Mounting Method



### WARNING


Be sure to turn OFF the power supply to the controller before installing it on the panel to avoid an electric shock.

#### Mounting the Instrument Main Unit

Provide an instrumented panel steel sheet of 1 to 10 mm thickness.

After opening the mounting hole on the panel, follow the procedures below to install the controller:

1. Insert the controller into the opening from the front of the panel so that the terminal board on the rear is at the far side.
2. Set the brackets in place on the top and bottom of the controller as shown in the figure below, then tighten the screws of the brackets. Take care not to overtighten them.





To uninstall the controller, perform the procedure in the reverse order.

### CAUTION

- 1) Tighten the screws with appropriate tightening torque within 0.25 N·m. Otherwise it may cause the case deformation or the bracket damage.
- 2) Make sure that foreign materials do not enter the inside of the instrument through the case's slit holes.


# 17.3 External Dimensions and Panel Cutout Dimensions

UT32A




Unit: mm  
(approx. inch)

### General mounting



### Side-by-side close mounting



"N" stands for the number of controllers to be installed. However, the measured value applies if N≥5.

Normal tolerance:  
±(value of JIS B 0401-1998 tolerance class IT18)/2

## 17.4 Wiring


### 17.4.1 Important Information on Wiring



#### WARNING

- 1) Be sure to turn OFF the power supply to the controller before wiring to avoid an electric shock. Use a tester or similar device to ensure that no power is being supplied to a cable to be connected.
- 2) Wiring work must be carried out by a person with basic electrical knowledge and practical experience.
- 3) For the wiring cable, the temperature rating is 75 °C or more.

UT32A Terminal Block Diagram




#### CAUTION

- When connecting two or more crimp-on terminal lugs to the single terminal block, bend the crimp-on terminal lugs before tightening the screw.
- Note that the wiring of two or more crimp-on terminal lugs to the single high-voltage terminal of the power supply and relay, etc. does not comply with the safety standard.

**CAUTION**


Do not use an unassigned terminal as the relay terminal.

**Recommended Crimp-on Terminal Lugs**



Recommended tightening torque: 0.6 N·m  
 Applicable wire size: Power supply wiring 1.25 mm<sup>2</sup> or more

Applicable terminal lug	Applicable wire size mm <sup>2</sup> (AWG#)	(ød)	(A)	(F)
M3	0.25 to 1.65 (22 to 16)	3.3	5.5	4.2



**Cable Specifications**

Purpose	Name and Manufacturer
Power supply, relay contact output	600 V Grade heat-resistant PVC insulated wires, JIS C 3317(HIV), 0.9 to 2.0 mm <sup>2</sup>
Thermocouple	Shielded compensating lead wire JISC1610 For thermocouple input (PV input and remote input with direct input), shielded compensating lead wire of cross-sectional area less than or equal to 0.75 mm <sup>2</sup> is recommended. If the cross-sectional area is wide, the reference junction compensation error may be large.
RTD	Shielded wire (three/four conductors) UL2482 (Hitachi Cable)
Other signals (other than contact output)	Shielded wires
Other signals (contact output)	Non shielded wires
RS485 communication	Shielded wires

Recommended tightening torque: 0.5 to 0.6 N·m


**Note**

Communication wires of cross-sectional area less than or equal to 0.34 mm<sup>2</sup> may not be secured firmly to the terminals.  
 Check that the wire is firmly connected to the terminal by folding the conductor of the wire connected to the crimp-on lug.  
 Recommended length of the stripped wire: 7 mm

## 17.4.2 PV Input Wiring

**CAUTION**

- 1) Be careful of polarity when wiring inputs. Reversed polarity can damage the UT.
- 2) Keep the PV input signal line as far away as possible from the power supply circuit and ground circuit.
- 3) For TC input, use shielded compensating lead wires for wiring. For RTD input, use shielded wires that have low conductor resistance and cause no significant differences in resistance between the three wires.
- 4) If there is a risk of external lightning surges, use a lightning arrester etc.

**UT32A****Use**


PV input is used for PV input.



17.4.3 Control Output (Relay, Current, and Voltage Pulse) Wiring


**CAUTION**

- 1) The use of inductance (L) loads such as auxiliary relays, motors and solenoid valves causes malfunction or relay failure; always insert a CR filter for use with alternating current or a diode for use with direct current, as a spark-removal surge suppression circuit, into the line in parallel with the load.
- 2) If there is a risk of external lightning surges, use a lightning arrester etc.
- 3) Relays cannot be used for a small load of 10 mA or less.
- 4) Since the insulation provided to each relay output terminal is Functional insulation, provide Reinforced insulation to the external of the device as necessary. (Refer to the drawing below.)




**DC Relay Wiring**

UT32A




**AC Relay Wiring**

UT32A




### Transistor Output Wiring



### Relay Output

Suffix code : Type 1 = "-R"




Contact rating: 250 V AC, 3 A  
30 V DC, 3 A (resistance load)

Note: The control output should always be used with a load of 10 mA or more.

### Current and Voltage Pulse Output

Suffix code : Type 1 = "-V" or "-C"



Control valves  
(or other  
actuators)

Current:  
4 to 20 mA DC or 0 to 20 mA DC  
(resistance load: 600  $\Omega$  or less)

Voltage pulse:  
On-voltage: 12 V DC or more  
(load resistance: 600  $\Omega$  or more)  
Off-voltage: 0.1 V DC or less

#### Use

When current/voltage pulse output is not used for control output, it can be used for retransmission output.

When retransmission output terminal is not used for retransmission output, it can be used for optional control output. The current output range can be changed.


For control output setting, set the control type (CNT), then set the output terminal and output type in the output type selection (OT).

► [Control output type: 10.1 Setting Control Output Type](#)


17.4.4 Contact Output Wiring

**CAUTION**

- 1) Use an auxiliary relay for load-switching if the contact rating is exceeded.
- 2) Connect a bleeder resistor when a small current is used, so that a current exceeding 1 mA can be supplied.
- 3) The output relay has a limited service life. Be sure to connect a CR filter (for AC) or diode (for DC) to the load.
- 4) If there is a risk of external lightning surges, use a lightning arrester etc.
- 5) Since the insulation provided to each relay output terminal is Functional insulation, provide Reinforced insulation to the external of the device as necessary. (Refer to the drawing below.)



► When using auxiliary relay: 17.4.3 Control Output (Relay, Current, and Voltage Pulse) Wiring



Factory default: Function is not assigned to the additional contact outputs.


► Contact output function registration: 12.2 Setting Contact Output Function

The following table shows the initial status for control type.

AL1 terminal	AL2 terminal
Alarm 1 (PV high limit)	Alarm 2 (PV low limit)

### 17.4.5 24 V DC Loop Power Supply Wiring

This can be used when the optional suffix code /LP is specified. The controller with the optional suffix code /LP is equipped with an isolated loop power supply (21.6 to 28.0 V DC) for connecting a 2-wire transmitter.




### 17.4.6 RS-485 Communication Interface Wiring

Wire as follows for Modbus communication, PC link communication, or ladder communication.


Always connect a terminating resistor to the station at the end of the communication line.

► [Details of communication parameter settings and communication functions: UTAdvanced Series Communication Interface \(RS-485, Ethernet\) User's Manual](#)

#### 4-wire Wiring




#### 2-wire Wiring of 4-wire Terminal



**UT32A**

Terminal symbol above	Suffix code: Type 2 = "1"
RDB (+)	304
RDA (-)	305
SDB (+)	301
SDA (-)	302
SG	303

**2-wire Wiring**



**UT32A**


Terminal symbol above.	Suffix code: Type 2= "1"
RSB (+)	301
RSA (-)	302
SG	303

**Note**


ML2-x indicates a converter of YOKOGAWA. Other than this, RS232C/RS485 converters can also be used. If another converter is to be used, check the electrical specifications of the converter before using it.

17.4.7 Coordinated Operation Wiring


4-wire Wiring



2-wire Wiring of 4-wire Terminal (1)




2-wire Wiring of 4-wire Terminal (2)



**UT32A**

Terminal symbol above	Suffix code: Type 2 = "1"
RDB (+)	304
RDA (-)	305
SDB (+)	301
SDA (-)	302
SG	303

**2-wire Wiring**



**UT32A**

Terminal symbol above	Suffix code: Type 2= "1"
RSB (+)	301
RSA (-)	302
SG	303

## 17.4.8 Power Supply Wiring




### WARNING

- 1) Wiring work must be carried out by a person with basic electrical knowledge and practical experience.
- 2) Be sure to turn OFF the power supply to the controller before wiring to avoid an electric shock. Use a tester or similar device to ensure that no power is being supplied to a cable to be connected.
- 3) As a safety measure, always install a circuit breaker (an IEC 60947-compatible product, 5 A, 100 V or 220 V AC) in an easily accessible location near the instrument. Moreover, provide indication that the switch is a device for turning off the power to the instrument.
- 4) Install the power cable keeping a distance of more than 1 cm from other signal wires.
- 5) The power cable is required to meet the IEC standards concerned or the requirements of the area in which the instrument is being installed.
- 6) Wiring should be installed to conform to NEC (National Electrical Code: ANSI/NFPA-70) or the wiring construction standards in countries or regions where wiring will be installed.

### CAUTION

- 1) Provide electricity from a single-phase power supply. If the power is noisy, install an isolation transformer on the primary side, and use a line filter on the secondary side. When measures against noise are taken, do not install the primary and secondary power cables close to each other.
- 2) If there is a risk of external lightning surges, use a lightning arrester etc.







## 17.5 Attaching and Detaching Terminal Cover

After completing the wiring, the terminal cover is recommended to use for the instrument.

### Attaching Method


(1) Attach the terminal cover to the rear panel of the main unit horizontally.

(2) The following figure is a mounting image.



### Detaching Method

(1) Slide the terminal cover to the direction of the printed arrow.



# 18.1 Parameter Map

## Brief Description of Parameter Map

### Group Display

"E1" and "1 to 4, R" appearing in the parameter map are displayed on Group display (7 segments, 2 digits) while the menu or parameter is displayed.


**E1:** indicates the parameter in E1-terminal area  
1 to 4, R: indicate the group numbers

► [E1: Terminal assignments in 17.4 Wiring](#)

### Parameter Display Level

The marks below appearing next to the menu symbol and parameter symbol in the parameter map indicate the display/non-display level.

Mark	Display	Display level	Description
None	EASY	Easy setting mode: Displays the minimum parameters.	Corresponding parameters are displayed in all modes.
Ⓢ	STD	Standard setting mode: Displays a wider range of parameters than displayed in the Easy setting mode.	Corresponding parameters are displayed only in Standard setting mode and Professional setting mode. Parameter display level indicators "EASY" and "PRO" are unlit in Standard setting mode. *: "STD" is the symbol used in this manual only.
Ⓟ	PRO	Professional setting mode: Displays all parameters.	Corresponding parameters are displayed only in Professional setting mode.



► [Display level: 13.3.2 Setting Parameter Display Level](#)

### Function of Each Menu

Menu symbol	Function
<b>MODE</b>	Operation mode (STOP/RUN switch, REMOTE/LOCAL switch, Auto-tuning switch, SP number selection, etc.)

The parameters in the menu of the following table indicate the parameters to set the functions necessary for operation. The symbol in parentheses are shown on Group display.

Menu symbol	Function
<b>CS</b>	SELECT parameter
<b>SP</b>	SP and alarm setpoint
<b>SPS</b>	SP-related function
<b>ALRM</b>	Alarm function
<b>PVS</b>	PV-related function
<b>PID</b>	PID setting
<b>TUNE</b>	Super, Super 2, anti-reset windup, output velocity limiter, and manual preset output
<b>ZONE</b>	Zone control

The parameters in the menu of the following table indicate the parameters to set the basic functions of the controller. The symbol in parentheses are shown on Group display.


Menu symbol	Functions
PASS	Password setting (Displayed only when the password has been sent.)


Menu symbol	Functions
CTL	Control type, number of SP groups, number of PID groups, etc
PV	PV input type, range, scale, etc
MPV	Input range, SP limiters
OUT	Cycle time
R485 (E1)	RS-485 communication (E1-terminal area)
KEY	Function of User function key
DISP	Display functions
CSEL	SELECT Display, SELECT parameter registration
KLOC	Key lock
MLOC	Parameter menu lock
ALM	Alarm output function, contact output type
I/O	Input / output data display
SYS	Action setting when recovering from a power failure, guide display language, password setting, etc
INIT	Initialization of parameter
VER	Error status, version, etc
LVL	Parameter display level

**Note**


Some parameters are not displayed according to the setting such as control type, or input and output.

# 18.1 Parameter Map











## 18.2 List of Parameters

### 18.2.1 Operation Parameters

#### Operation Mode Menu (Menu: MODE)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>S.R</b>	STOP/RUN switch	EASY	STOP: Stop mode RUN: Run mode Preset output (PO) is generated in STOP mode.	RUN
<b>R.L</b>	REMOTE/LOCAL switch	EASY	LCL: Local mode REM: Remote mode (Displayed only in cases where the communication is specified.)	LCL
<b>AT</b>	Auto-tuning switch	EASY	OFF: Disable 1 to 4: Perform auto-tuning. Tuning result is stored in the specified numbered PID. R: Tuning result is stored in the PID for reference deviation.	OFF
<b>SPNO.</b>	SP number selection	EASY	1 to 4 (Depends on the setup parameter SPGR. setting.)	1
<b>PID</b>	PID number	EASY	The PID group number being selected is displayed. 1 to 4, R: PID group for reference deviation	1

#### SELECT Parameter Menu (Menu: CS)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>CS10 to CS19</b>	SELECT parameter 10 to 19	EASY	Setting range of a registered parameter.	-

#### SP and Alarm Setpoint Setting Menu (Menu: SP)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>SP</b>	Target setpoint	EASY	0.0 to 100.0% of PV input range (EU) (Setting range: SPL to SPH)	SPL
<b>PIDN</b>	PID number selection	EASY	1 to 4 (Depends on the PIDG. setting.)	Same as SP number.
<b>A1 to A4</b>	Alarm-1 to -4 setpoint	EASY	Set a display value of setpoint of PV alarm, SP alarm, deviation alarm, output alarm, or velocity alarm. -19999 to 30000 (Set a value within the input range.) Decimal point position depends on the input type.	0

## SP-related Setting Menu (Menu: SPS)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>RT</b>	Remote input ratio	STD	0.001 to 9.999 (Displayed only in cases where the communication is specified.)	1.000
<b>RBS</b>	Remote input bias	STD	-100.0 to 100.0% of PV input range span (EUS) (Displayed only in cases where the communication is specified.)	0.0 % of PV input range span
<b>UPR</b>	SP ramp-up rate	EASY	OFF, 0.0 + 1 digit to 100.0% of PV input range span (EUS)	OFF
<b>DNR</b>	SP ramp-down rate	EASY		OFF
<b>TMU</b>	SP ramp-rate time unit	EASY	HOUR: Ramp-up rate or ramp-down rate per hour MIN: Ramp-up rate or ramp-down rate per minute	HOUR
<b>SPT</b>	SP tracking selection	STD	OFF, ON	ON
<b>PVT</b>	PV tracking selection	STD	OFF, ON	OFF

## 18.2 List of Parameters

### Alarm Function Setting Menu (Menu: ALRM)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>AL1 to AL4</b>	Alarm-1 to -4 type	EASY	<p>Set a 5-digit value in the following order.                      [Latch action (0/1/2/3/4)] + [Energized (0) or De-energized (1)] + [Without (0) or With (1) Stand-by action] + [Alarm type: 2 digits (see below)]                      For latch action, see chapter 11.</p> <p>Alarm type: 2 digits                      00: Disable                      01: PV high limit                      02: PV low limit                      03: SP high limit                      04: SP low limit                      05: Deviation high limit                      06: Deviation low limit                      07: Deviation high and low limits                      08: Deviation within high and low limits                      09: Target SP high limit                      10: Target SP low limit                      11: Target SP deviation high limit                      12: Target SP deviation low limit                      13: Target SP deviation high and low limits                      14: Target SP deviation within high and low limits                      15: OUT high limit                      16: OUT low limit                      19: Analog input PV high limit                      20: Analog input PV low limit                      29: PV velocity                      30: Fault diagnosis                      31: FAIL</p>	<p>AL1, AL3:                      Latch action (0)                      Energized (0)                      Without Stand-by action (0)                      PV high limit (01)</p> <p>AL2, AL4:                      Latch action (0)                      Energized (0)                      Without Stand-by action (0)                      PV low limit (02)</p>
<b>VT1 to VT4</b>	PV velocity alarm time setpoint 1 to 4	EASY	0.01 to 99.59 (minute.second)	1.00
<b>HY1 to HY4</b>	Alarm-1 to -4 hysteresis	EASY	<p>Set a display value of setpoint of hysteresis.                      -19999 to 30000 (Set a value within the input range.)                      Decimal point position depends on the input type.                      When the decimal point position for the input type is set to "1", the initial value of the hysteresis is "1.0".</p>	10
<b>DYN1 to DYN4</b>	Alarm-1 to -4 On-delay timer	STD	0.00 to 99.59 (minute.second)	0.00
<b>DYF1 to DYF4</b>	Alarm-1 to -4 Off-delay timer	PRO		0.00
<b>AMD</b>	Alarm mode	STD	0: Always active 1: Not active in STOP mode 2: Not active in STOP or MAN mode	0

### PV-related Setting Menu (Menu: PVS)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>BS</b>	PV input bias	EASY	-100.0 to 100.0% of PV input range span (EUS)	0.0 % of PV input range span
<b>FL</b>	PV input filter	EASY	OFF, 1 to 120 s	OFF

## PID Setting Menu (Menu: PID)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>P</b>	Proportional band	EASY	0.0 to 999.9% When 0.0% is set, it operates as 0.1%.	5.0%
<b>I</b>	Integral time	EASY	OFF: Disable 1 to 6000 s	240 s
<b>D</b>	Derivative time	EASY	OFF: Disable 1 to 6000 s	60 s
<b>OH</b>	Control output high limit	EASY	-4.9 to 105.0%, (OL<OH)	100.0%
<b>OL</b>	Control output low limit	EASY	-5.0 to 104.9%, (OL<OH), SD: Tight shut	0.0%
<b>MR</b>	Manual reset	EASY	Enabled when integral time is OFF. The manual reset value equals the output value when PV = SP. -5.0 to 105.0%	50.0%
<b>HYS</b>	Hysteresis (in ON/OFF control)	EASY	In ON/OFF control: 0.0 to 100.0% of PV input range span (EUS)	In ON/OFF control : 0.5 % of PV input range span
<b>HY.UP</b>	Upper-side hysteresis (in ON/OFF control)	EASY	0.0 to 100.0% of PV input range span (EUS)	0.5 % of PV input range span
<b>HY.LO</b>	Lower-side hysteresis (in ON/OFF control)	EASY		0.5 % of PV input range span
<b>DR</b>	Direct/reverse action switch	STD	RVS: Reverse action, DIR: Direct action	RVS

## PID Setting Menu (Menu: PID) (Continued from previous page)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>PO</b>	Preset output	EASY	-5.0 to 105.0%	0.0%

## 18.2 List of Parameters

### Tuning Menu (Menu: TUNE)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>SC</b>	Super function	EASY	OFF: Disable 1: Overshoot suppressing function (normal mode) 2: Hunting suppressing function (stable mode) Enables to answer the wider characteristic changes compared with response mode. 3: Hunting suppressing function (response mode) Enables quick follow-up and short converging time of PV for the changed SP. 4: Overshoot suppressing function (strong suppressing mode)	OFF
<b>AT.TY</b>	Auto-tuning type	STD	0: Normal 1: Stability	0
<b>AT.OH</b>	Output high limit in auto-tuning	PRO	-5.0 to 105.0%	100.0%
<b>AT.OL</b>	Output low limit in auto-tuning	PRO		0.0%
<b>AT.BS</b>	SP bias in auto-tuning	PRO	-100.0 to 100.0% of PV input range span (EUS)	0.0 % of PV input range span
<b>AR</b>	Anti-reset windup (excess integration prevention)	STD	AUTO, 50.0 to 200.0%	AUTO
<b>OPR</b>	Output velocity limiter	STD	OFF: Disable 0.1 to 100.0%/s	OFF
<b>OLMT</b>	Output limiter switch	PRO	OFF: Disable output limiter in MAN mode ON: Enable output limiter in MAN mode	ON
<b>MPON</b>	Manual preset output number selection	STD	OFF: Hold the control output in AUTO mode (bumpless) 1: Use manual preset output 1 (output bump) 2: Use manual preset output 2 (output bump) 3: Use manual preset output 3 (output bump) 4: Use manual preset output 4 (output bump) 5: Use manual preset output 5 (output bump)	OFF
<b>MPO1 to MPO5</b>	Manual preset output 1 to 5	STD	-5.0 to 105.0%	0.0%

### Zone Control Menu (Menu: ZONE)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>RP1 to RP3</b>	Reference point 1 to 3	STD	0.0 to 100.0% of PV input range (EU) ( $RP1 \leq RP2 \leq RP3$ )	100.0 % of PV input range
<b>RHY</b>	Zone PID switching hysteresis	STD	0.0 to 10.0% of PV input range span (EUS)	0.5 % of PV input range span
<b>RDV</b>	Reference deviation	STD	OFF: Disable 0.0 + 1 digit to 100.0% of PV input range span (EUS)	OFF

## 18.2.2 Setup Parameters

Control Function Setting Menu (Menu: CTL)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>CNT</b>	Control type	EASY	PID: PID control ONOF: ON/OFF control (1 point of hysteresis) ONOF2: ON/OFF control (2 points of hysteresis)	Standard type: PID
<b>ALG</b>	PID control mode	PRO	0: Standard PID control mode 1: Fixed-point control mode	0
<b>SPGR.</b>	Number of SP groups	STD	1 to 4	4
<b>ALNO.</b>	Number of alarms	PRO	0 to 4	4
<b>ZON</b>	Zone PID selection	STD	0: SP group number selection 1 1: Zone PID selection (selection by PV) 2: Zone PID selection (selection by target SP) 3: SP group number selection 2 4: Zone PID selection (selection by SP)	0
<b>PIDG.</b>	Number of PID groups	STD	1 to 4	4

18.2 List of Parameters

PV Input Setting Menu (Menu: PV)

Parameter symbol	Name	Display level	Setting range	Initial value
IN	PV input type	EASY	OFF: Disable K1: -270.0 to 1370.0 (°C) / -450.0 to 2500.0 (°F) K2: -270.0 to 1000.0 (°C) / -450.0 to 2300.0 (°F) K3: -200.0 to 500.0 (°C) / -200.0 to 1000.0 (°F) J: -200.0 to 1200.0 (°C) / -300.0 to 2300.0 (°F) T1: -270.0 to 400.0 (°C) / -450.0 to 750.0 (°F) T2: 0.0 to 400.0 (°C) / -200.0 to 750.0 (°F) B: 0.0 to 1800.0 (°C) / 32 to 3300 (°F) S: 0.0 to 1700.0 (°C) / 32 to 3100 (°F) R: 0.0 to 1700.0 (°C) / 32 to 3100 (°F) N: -200.0 to 1300.0 (°C) / -300.0 to 2400.0 (°F) E: -270.0 to 1000.0 (°C) / -450.0 to 1800.0 (°F) L: -200.0 to 900.0 (°C) / -300.0 to 1600.0 (°F) U1: -200.0 to 400.0 (°C) / -300.0 to 750.0 (°F) U2: 0.0 to 400.0 (°C) / -200.0 to 1000.0 (°F) W: 0.0 to 2300.0 (°C) / 32 to 4200 (°F) PL2: 0.0 to 1390.0 (°C) / 32.0 to 2500.0 (°F) P2040: 0.0 to 1900.0 (°C) / 32 to 3400 (°F) WRE: 0.0 to 2000.0 (°C) / 32 to 3600 (°F) JPT1: -200.0 to 500.0 (°C) / -300.0 to 1000.0 (°F) JPT2: -150.00 to 150.00 (°C) / -200.0 to 300.0 (°F) PT1: -200.0 to 850.0 (°C) / -300.0 to 1560.0 (°F) PT2: -200.0 to 500.0 (°C) / -300.0 to 1000.0 (°F) PT3: -150.00 to 150.00 (°C) / -200.0 to 300.0 (°F) 0.4-2V: 0.400 to 2.000 V 1-5V: 1.000 to 5.000 V 4-20: 4.00 to 20.00 mA 0-2V: 0.000 to 2.000 V 0-10V: 0.00 to 10.00 V 0-20: 0.00 to 20.00 mA -1020: -10.00 to 20.00 mV 0-100: 0.0 to 100.0 mV  Note: W: W-5% Re/W-26% Re (Hoskins Mfg. Co.), ASTM E988 WRE: W97Re3-W75Re25	OFF
UNIT	PV input unit	EASY	-: No unit C: Degree Celsius -: No unit --: No unit ---: No unit F: Degree Fahrenheit	C
RH	Maximum value of PV input range	EASY	Depends on the input type. - For temperature input - Set the temperature range that is actually controlled. (RL<RH)	Depends on the input type
RL	Minimum value of PV input range	EASY	- For voltage / current input - Set the range of a voltage / current signal that is applied. The scale across which the voltage / current signal is actually controlled should be set using the maximum value of input scale (SH) and minimum value of input scale (SL). (Input is always 0% when RL = RH.)	Depends on the input type

## PV Input Setting Menu (Menu: PV) (Continued from previous page)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>SDP</b>	PV input scale decimal point position	EASY	0: No decimal place 1: One decimal place 2: Two decimal places 3: Three decimal places 4: Four decimal places	Depends on the input type
<b>SH</b>	Maximum value of PV input scale	EASY	-19999 to 30000, (SL<SH),   SH - SL   ≤ 30000	Depends on the input type
<b>SL</b>	Minimum value of PV input scale	EASY		Depends on the input type
<b>BSL</b>	PV input burnout action	STD	OFF: Disable UP: Upscale DOWN: Downscale	Depends on the input type
<b>RJC</b>	PV input reference junction compensation	PRO	OFF: RJC OFF ON: RJC ON	ON
<b>ERJC</b>	PV input external RJC setpoint	PRO	-10.0 to 60.0 (°C)	0.0
<b>A.BS</b>	PV analog input bias	STD	-100.0 to 100.0% of PV input range span (EUS)	0.0 % of PV input range span
<b>A.FL</b>	PV analog input filter	STD	OFF, 1 to 120 s	OFF

## Input Range / SP Limiter Setting Menu (Menu: MPV)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>P.UNI</b>	Control PV input unit	STD	-: No unit C: Degree Celsius -: No unit --: No unit ---: No unit F: Degree Fahrenheit	Same as PV input unit
<b>P.DP</b>	Control PV input decimal point position	STD	0: No decimal place 1: One decimal place 2: Two decimal places 3: Three decimal places 4: Four decimal places	1
<b>P.RH</b>	Maximum value of control PV input range	STD	-19999 to 30000, (P.RL<P.RH),   P.RH - P.RL   ≤ 30000	Depends on the input type
<b>P.RL</b>	Minimum value of control PV input range	STD		Depends on the input type
<b>SPH</b>	SP high limit	STD	0.0 to 100.0% of PV input range (EU), (SPL<SPH)	100.0 % of PV input range
<b>SPL</b>	SP low limit	STD		0.0 % of PV input range



## 18.2 List of Parameters

### Output Setting Menu (Menu: OUT)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>CT</b>	Control output cycle time	EASY	0.5 to 1000.0 s	30.0 s

### Output Setting Menu (Menu: OUT) (Continued from previous page)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>OU.A</b>	OUT current output range	STD	4-20: 4 to 20 mA 0-20: 0 to 20 mA 20-4: 20 to 4 mA 20-0: 20 to 0 mA	4-20

### RS-485 Communication Setting Menu (Menu: R485) (E1 terminal area)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>PSL</b>	Protocol selection	EASY	PCL: PC link communication PCLSM: PC link communication (with checksum) LADR: Ladder communication CO-M: Coordinated master station CO-S: Coordinated slave station MBASC: Modbus (ASCII) MBRTU: Modbus (RTU) CO-S1: Coordinated slave station (Loop-1 mode) CO-S2: Coordinated slave station (Loop-2 mode) P-P: Peer-to-peer communication	MBRTU
<b>BPS</b>	Baud rate	EASY	600: 600 bps 1200: 1200 bps 2400: 2400 bps 4800: 4800 bps 9600: 9600 bps 19200: 19.2k bps 38400: 38.4k bps	19200
<b>PRI</b>	Parity	EASY	NONE: None EVEN: Even ODD: Odd	EVEN
<b>STP</b>	Stop bit	EASY	1: 1 bit, 2: 2 bits	1
<b>DLN</b>	Data length	EASY	7: 7 bits, 8: 8 bits	8
<b>ADR</b>	Address	EASY	1 to 99	1
<b>RP.T</b>	Minimum response time	PRO	0 to 10 (x10ms)	0

## Key Action Setting Menu (Menu: KEY)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>Fn</b>	User function key-n action setting	EASY	OFF: Disable A/M: AUTO/MAN switch R/L1: REM/LCL switch S/R: STOP/RUN switch AUTO: Switch to AUTO MAN: Switch to MAN REM1: Switch to REM LCL1: Switch to LCL STOP: Switch to STOP RUN: Switch to RUN AT: Auto-tuning LTUP: LCD brightness UP LTDN: LCD brightness DOWN BRI: Adjust LCD brightness LCD: LCD backlight ON/OFF switch LAT: Latch release PID: PID tuning switch	PID
<b>A/M</b>	A/M key action setting	PRO	OFF: Disable A/M: AUTO/MAN switch R/L1: REM/LCL switch S/R: STOP/RUN switch AUTO: Switch to AUTO MAN: Switch to MAN	A/M

## Display Function Setting Menu (Menu: DISP)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>PCMD</b>	Active color PV display switch	EASY	0: Fixed in white 1: Fixed in red 2: Link to alarm 1 (Alarm OFF: white, Alarm ON: red) 3: Link to alarm 1 (Alarm OFF: red, Alarm ON: white) 4: Link to alarm 1 or 2 (Alarm OFF: white, Alarm ON: red) 5: Link to alarm 1 or 2 (Alarm OFF: red, Alarm ON: white) 6: PV limit (Within range: white, Out of range: red) 7: PV limit (Within range: red, Out of range: white) 8: SP deviation (Within deviation: white, Out of deviation: red) 9: SP deviation (Within deviation: red, Out of deviation: white)	0
<b>PCH</b>	PV color change high limit	EASY	Set a display value when in PV limit or SP deviation.	0
<b>PCL</b>	PV color change low limit	EASY	-19999 to 30000 (Set a value within the input range.) Decimal point position depends on the input type.	0
<b>BAR1</b>	Bar-graph display registration	STD	0: Disable 1:OUT3: PV 4: SP 5: Deviation 6 to 16: Disable 18: PV terminals analog input 27: TSP 28: Deviation between the TSP	5
<b>BDV</b>	Bar-graph deviation display band	STD	0.0 to 100.0% of PV input range span (EUS)	1.0 % of PV input range span

## 18.2 List of Parameters

Display Function Setting Menu (Menu: DISP) (Continued from previous page)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>EV1 to EV4</b>	EV1 to EV4 display condition registration	PRO	Setting range: 4001 to 6304 OFF: Disable 4321: Link to alarm 1 (Lit when the alarm occurs) 4322: Link to alarm 2 (Lit when the alarm occurs) 4323: Link to alarm 3 (Lit when the alarm occurs) 4325: Link to alarm 4 (Lit when the alarm occurs)  5153 to 5154: Link to AL1-AL2 (Lit when the contact is closed)  For other functions, see the UTAdvanced Series Communication Interface User's Manual.	EV1: 4321 EV2: 4322 EV3: 4323 EV4: 4325
<b>PV.D</b>	PV display area ON/OFF	PRO	OFF: Nondisplay, ON: Display	ON
<b>SP.D</b>	Setpoint display area ON/OFF	PRO		ON
<b>STS.D</b>	Status display area ON/OFF	PRO		ON
<b>SPD</b>	Scroll speed	PRO	(Slow) 1 to 8 (Quick)	4
<b>GUID</b>	Guide display ON/OFF	STD	OFF: Nondisplay ON: Display	ON
<b>HOME</b>	Home Operation Display setting	PRO	SP1: SP Display OUT1: OUT Display PID1: PID Number Display PV: PV Analog Input Display CS1 to CS5: SELECT Display 1 to 5	SP1
<b>ECO</b>	Economy mode	STD	OFF: Disable 1: Economy mode ON (All indications except PV display OFF) 2: Economy mode ON (All indications OFF) 3: Brightness 10 % (All indications)	OFF
<b>BRI</b>	Brightness	EASY	(Dark) 1 to 5 (Bright)	3

## Display Function Setting Menu (Menu: DISP) (Continued from previous page)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>B.PVW</b>	White brightness adjustment of PV display	PRO	Adjusts the white brightness of PV display. (Dark) -4 to 4 (Bright)	0
<b>B.PVR</b>	Red brightness adjustment of PV display	PRO	Adjusts the red brightness of PV display. (Dark) -4 to 4 (Bright)	0
<b>B.SP</b>	Brightness adjustment of Setpoint display	PRO	Adjusts the brightness of SP display. (Dark) -4 to 4 (Bright)	0
<b>B.BAR</b>	Brightness adjustment of Bar-graph display	PRO	Adjusts the brightness of SP display. (Dark) -4 to 4 (Bright)	0
<b>B.STS</b>	Brightness adjustment of Status indicator	PRO	Adjusts the brightness of Status indicator. (Dark) -4 to 4 (Bright)	0
<b>D.CYC</b>	Display update cycle	PRO	1: 100 ms 2: 200 ms 3: 500 ms 4: 1 s 5: 2 s	2
<b>OP.JP</b>	Autoreturn to operation display	PRO	Automatically returned to the Operation Display when there has been no keystroke operation for 5 minutes. OFF, ON	ON
<b>MLSD</b>	Least significant digital mask of PV display	STD	OFF: With least significant digit ON: Without least significant digit	OFF
<b>MKTP</b>	Method for least significant digital mask of PV display	STD	0: Rounding 1: Rounding-off	0

## SELECT Display Setting Menu (Menu: CSEL)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>CS1 to CS5</b>	SELECT Display-1 to -5 registration	STD	OFF, 2301 to 5000	OFF
<b>CS10 to CS19</b>	SELECT parameter-10 to -19 registration	PRO		OFF

## Key Lock Setting Menu (Menu: KLOC)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>U.SP</b>	SP Display lock	PRO	OFF: Display ON: Nondisplay	OFF
<b>U.OUT</b>	OUT Display lock	PRO		OFF
<b>U.PID</b>	PID Number Display lock	PRO		ON
<b>U.PV</b>	PV Analog Input Display lock	PRO		ON
<b>COM.W</b>	Communication write enable/disable	STD	OFF: Enable, ON: Disable	OFF
<b>DATA</b>	Front panel parameter data key lock	STD	OFF: Unlock ON: Lock	OFF
<b>A/M</b>	Front panel A/M key lock	STD		OFF
<b>U.PVO</b>	PV Display lock	STD		OFF

## 18.2 List of Parameters

### Menu Lock Setting Menu (Menu: MLOC)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>CTL</b>	[CTL] menu lock	PRO	OFF: Display ON: Nondisplay	OFF
<b>PV</b>	[PV] menu lock	PRO		
<b>MPV</b>	[MPV] menu lock	PRO		
<b>OUT</b>	[OUT] menu lock	PRO		
<b>R485</b>	[R485] menu lock	PRO		
<b>KEY</b>	[KEY] menu lock	PRO		
<b>DISP</b>	[DISP] menu lock	PRO		
<b>CSEL</b>	[CSEL] menu lock	PRO		
<b>KLOC</b>	[KLOC] menu lock	PRO		
<b>ALM</b>	[ALM] menu lock	PRO		
<b>I/O</b>	[I/O] menu lock	PRO		
<b>SYS</b>	[SYS] menu lock	PRO		
<b>INIT</b>	[INIT] menu lock	PRO		
<b>VER</b>	[VER] menu lock	PRO		
<b>LVL</b>	[LVL] menu lock	PRO	OFF: Display ON: Nondisplay	OFF
<b>MODE</b>	[MODE] menu lock	PRO		
<b>CS</b>	[CS] menu lock	PRO		
<b>SP</b>	[SP] menu lock	PRO		
<b>SPS</b>	[SPS] menu lock	PRO		
<b>ALRM</b>	[ALRM] menu lock	PRO		
<b>PVS</b>	[PVS] menu lock	PRO		
<b>PID</b>	[PID] menu lock	PRO		
<b>TUNE</b>	[TUNE] menu lock	PRO		
<b>ZONE</b>	[ZONE] menu lock	PRO		

### AL1-AL3 Function Registration Menu (Menu: ALM)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>AL1.S</b>	AL1 function selection	STD	Set an I relay number. Setting range: 4001 to 6000	4353
<b>AL2.S</b>	AL2 function selection	STD	No function: OFF Alarm 1: 4353 Alarm 2: 4354 Alarm 3: 4355 Alarm 4: 4357  AUTO (ON) / MAN (OFF) status: 4193 REM (ON) / LCL (OFF) status: 4194 STOP (ON) / RUN (OFF) status: 4195 FAIL (Normally ON) output: 4256	4354
<b>AL1.D</b>	AL1 contact type	PRO	0: When the event of assigned function occurs, the contact output is closed. 1: When the event of assigned function occurs, the contact output is opened.	0
<b>AL2.D</b>	AL2 contact type	PRO		0

## I/O Display Menu (Menu: I/O)

Parameter symbol	Name	Display level	Read only
<b>KEY</b>	Key status	PRO	See Chapter 13.
<b>Y000</b>	AL1-AL2 status (equipped as standard)	PRO	

## System Setting Menu (Menu: SYS)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>R.MD</b>	Restart mode	STD	CONT: Continue action set before power failure. MAN: Start from MAN. AUTO: Start from AUTO.	CONT
<b>R.TM</b>	Restart timer	STD	0 to 10 s	0
<b>EPO</b>	Input error preset output	STD	0: Preset output 1: 0% output 2: 100% output	0
<b>C.GRN</b>	Response as GREEN Series	PRO	OFF: Works as UT32A in communication of device information response or broadcasting. ON: Works as GREEN Series in communication of device information response or broadcasting.	OFF
<b>FREQ</b>	Power frequency	EASY	AUTO, 60: 60 Hz, 50: 50 Hz	AUTO
<b>QSM</b>	Quick setting mode	EASY	OFF: Disable ON: Enable	ON
<b>LANG</b>	Guide display language	EASY	ENG: English FRA: French GER: German SPA: Spanish	Depends on the Model and Suffix Codes
<b>PASS</b>	Password setting	EASY	0 (No password) to 65535	0
<b>SMEC</b>	Sampling period error counter	PRO	0 to 65535 (display only)	0 when power is turned on.

## 18.2 List of Parameters

### Initialization Menu (Menu: INIT)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>U.DEF</b>	Initialization to user default value	PRO	12345: Initialization, automatically returned to "0" after initialization.	0
<b>F.DEF</b>	Initialization to factory default value	PRO	-12345: Initialization, automatically returned to "0" after initialization.	0

### Error and Version Confirmation Menu (Menu: VER)

Parameter symbol	Name	Display level	Read only
<b>PA.ER</b>	Parameter error status	EASY	See Chapter 16.
<b>OP.ER</b>	Option error status	EASY	
<b>AD1.E</b>	A/D converter error status 1	EASY	
<b>PV1.E</b>	PV input error status	EASY	
<b>MCU</b>	MCU version	EASY	See Chapter 13.
<b>DCU</b>	DCU version	EASY	
<b>ECU1</b>	ECU-1 version	EASY	
<b>PARA</b>	Parameter version	EASY	
<b>H.VER</b>	Product version	EASY	
<b>SER1</b>	Serial number 1	EASY	
<b>SER2</b>	Serial number 2	EASY	

### Parameter Display Level Menu (Menu: LVL)

Parameter symbol	Name	Display level	Setting range	Initial value
<b>LEVL</b>	Parameter display level	EASY	EASY: Easy setting mode STD: Standard setting mode PRO: Professional setting mode	STD

# General Specifications

UT32A  
Digital Indicating Controller  
(Entry model)

UTAdvanced

Functional Enhancement

GS 05P01F31-01EN

## Overview

The UT32A entry model digital indicating controller is an easily configurable single-loop controller that can generate relay, voltage pulse, or current signals for control output. The short depth of the controller helps save instrument panel space.

## Features

- A 14-segment, active (PV display color changing function) color LCD display is employed. Two five-digit, high-resolution displays are possible. Alphabet letters can be displayed in an easy-to-read manner. The guide display shows parameter names.
- Easy to operate  
Navigation keys (SET/ENTER and Up/Down/Left/Right arrow keys) are employed to facilitate making settings.
- 65 mm depth  
The small depth enables the mounting in a thin and small instrumented panel.
- Quick setting function  
Setting only the minimum necessary parameters for operation is possible.
- Equipped with a multitude of functions  
Universal I/O is included as standard. PID control, ON/OFF control, etc. are available.
- LL50A Parameter Setting Software (sold separately)  
The parameters of UTAdvanced digital indicating controller can be built from a PC using this software. It makes data management even easier.
- Dust-proof and drip-proof  
IP66 (for front panel) (Not applicable to side-by-side close mounting.)  
NEMA4 (Hose-down test only)



- (b) Selecting the PID parameter group  
The following PID parameter groups can be selected.
  - Target setpoint number (SPNO) (The PID number can be set arbitrarily.)
  - Measured input zone PID
  - Target setpoint zone PID
  - Reached target setpoint zone PID
- (c) Auto-tuning
  - Tuning results can be selected from two options, Normal or Stable.
  - Tuning output limit can be set.
- (d) "Super" function: Overshoot-suppressing function
- (e) "Super 2" function: Hunting-suppressing function
- (f) STOP preset output function
- (g) Input ERROR preset output function
- (h) MANUAL preset output function

### (3) Operation Mode Switching

Operation mode switching	AUTO/MANUAL and RUN/STOP switching
--------------------------	------------------------------------

### (4) Control Parameter Setting Range

Proportional band	0.1 to 999.9%
Integral time	1 to 6000 sec. or OFF (using manual reset)
Derivative time	1 to 6000 sec. or OFF
ON/OFF control hysteresis (one or two hysteresis points)	0.0 to 100.0% of measured input range width
Preset output value	-5.0 to 105.0% (however, 0 mA or less cannot be output)
High/low output limiter	-5.0 to 105.0% Low limit setpoint < high limit setpoint
Tight shut function	When manual control is carried out with 4 to 20 mA output, control output can be reduced to about 0 mA.
Rate-of-change limiter of output	0.1 to 100.0%/sec., OFF

## Functional Specifications

### Control Specifications

- (1) Control Mode  
Single-loop control
- (2) Control period  
200 ms

### Control Computation Function

#### (1) Types of control

- PID control
- ON/OFF control

#### (2) Control Computation Function

- (a) Target setting point and the number of PID parameter groups  
Respectively, four sets of target setpoints, alarm setpoints, and PID parameters can be set.



## Alarm Functions

### • Types of Alarm

<b>Measured value alarm</b>	PV (measured value) high/low limit alarm Deviation high/low limit alarm
<b>Deviation alarm</b>	Deviation high and low limits alarm
<b>Rate-of-change alarm</b>	Deviation within high and low limits alarm Analog input PV high/low limit alarm PV rate-of-change alarm
<b>Setpoint alarm</b>	SP (setpoint) high/low limit alarm Target SP high/low limit alarm Target SP deviation high/low limit alarm Target SP deviation high and low limits alarm Target SP deviation within high and low limits alarm
<b>Output alarm</b>	Control output high/low limit alarm
<b>Other alarms</b>	Self-diagnosis alarm FAIL

### • Alarm Functions

<b>Alarm output action</b>	Alarm stand-by action Alarm latch (forced reset) function Alarm hysteresis Alarm ON/OFF delay timer
<b>Number of alarm settings</b>	4
<b>Number of alarm output points</b>	2

## Communication Function

	Function	Method	Interface	Targets	Max connection	Communication Data
Modbus (RTU/ASCII)	A standard industry protocol allowing communications between the controller and devices such as PCs, PLCs, and DCSs.	Slave	RS-485	PLC and others, UT75A/UT55A/UT52A/UT35A/UT32A/UP55A/UP35A/UP32A/UM33A (*1)	31 units	PV, ALM etc
PC link	The proprietary Yokogawa protocol allowing communications to PCs, PLCs and touch panels.					
Ladder	A protocol to communicate to PLCs.					

\*1: UT digital indication controllers can be connected.

## Physical Interface

### RS-485

Standard: EIA RS-485

Communication method: Two-wire half-duplex or four-wire half-duplex, start-stop synchronization, and non-procedural

Baud rate: 600,1200,2400,4800,9600,19200 or 38400bps

Maximum communication distance: 1200m

Terminating resistor: 220Ω (External)

## ■ Hardware Specifications

### Display Specifications

- PV display  
5-digit, 14-segment active color LCD (white/red)  
Character height: 13.0 mm
- Data display  
5-digit, 11-segment color LCD (orange)
- Bar graph display  
12-segment color LCD (orange)

### Universal Input Specifications

- Number of input points: 1
- Types of input, instrument range, and measurement accuracy (see the table below)

Types of input	Instrument range		Accuracy		
	°C	°F			
Thermocouple	K	-270.0 to 1370.0°C	-450.0 to 2500.0°F	±0.1% of instrument range ±1 digit for 0°C or more	
		-270.0 to 1000.0°C	-450.0 to 2300.0°F		
		-200.0 to 500.0°C	-200.0 to 1000.0°F		
	J	-200.0 to 1200.0°C	-300.0 to 2300.0°F	±0.2% of instrument range ±1 digit for less than 0°C	
		-270.0 to 400.0°C	-450.0 to 750.0°F		
	T	0.0 to 400.0°C	-200.0 to 750.0°F	However, ±2% of instrument range ±1 digit for less than -200°C of thermocouple K ±1% of instrument range ±1 digit for less than -200°C of thermocouple T	
	B	0.0 to 1800.0°C	32 to 3300°F	±0.15% of instrument range ±1 digit for 400°C or more ±5% of instrument range ±1 digit for less than 400°C	
	S	0.0 to 1700.0°C	32 to 3100°F	±0.15% of instrument range ±1 digit	
	R	0.0 to 1700.0°C	32 to 3100°F		
	N	-200.0 to 1300.0°C	-300.0 to 2400.0°F	±0.1% of instrument range ±1 digit ±0.25% of instrument range ±1 digit for less than 0°C	
	E	-270.0 to 1000.0°C	-450.0 to 1800.0°F	±0.1% of instrument range ±1 digit for 0°C or more	
	L	-200.0 to 900.0°C	-300.0 to 1600.0°F		
	U	-200.0 to 400.0°C	-300.0 to 750.0°F		
	Resistance-temperature detector (RTD) 3-wire	W <sup>(*)</sup>	0.0 to 2300.0°C	32 to 4200°F	±0.2% of instrument range ±1 digit
			Platinel 2	0.0 to 1390.0°C	
		PR20-40	0.0 to 1900.0°C	32 to 3400°F	±0.5% of instrument range ±1 digit for 800°C or more Accuracy not guaranteed for less than 800°C
W97 Re3-W75 Re25			0.0 to 2000.0°C	32 to 3600°F	±0.2% of instrument range ±1 digit
JPT100		-200.0 to 500.0°C	-300.0 to 1000.0°F	±0.1% of instrument range ±1 digit (*)	
		-150.00 to 150.00°C	-200.0 to 300.0°F	±0.1% of instrument range ±1 digit	
Pt100	-200.0 to 850.0°C	-300.0 to 1560.0°F	±0.1% of instrument range ±1 digit (*)		
	-200.0 to 500.0°C	-300.0 to 1000.0°F	±0.1% of instrument range ±1 digit		
Standard signal	0.400 to 2.0000 V	-	±0.1% of instrument range ±1 digit		
	1.000 to 5.000 V	-			
	4.00 to 20.00 mA	-			
DC voltage	0.000 to 2.000 V	-	±0.1% of instrument range ±1 digit		
	0.00 to 10.00 V	-			
	-10.00 to 20.00 mV	-			
DC current	0.00 to 20.00 mA	-			

The accuracy is that in the standard operating conditions: 23 ±2°C, 55 ±10%RH, and power frequency at 50/60 Hz.

\*1: ±0.3°C and ±1 digit in the range between 0 and 100°C  
±0.5°C ±1 digit in the range between -100 and 200°C

\*2: W-5% Re/W-26% Re (Hoskins Mfg.Co.), ASTM E988

- Applicable standards: JIS, IEC and DIN (ITS-90) for thermocouples and resistance-temperature detectors (RTD)
- Input sampling period: Synchronized to control period
- Burnout detection  
Upscale and downscale of function, and OFF can be specified for the standard signal of thermocouple and resistance-temperature detector (RTD).  
For integrated signal input, 0.1 V or 0.4 mA or less is judged as a burnout.

- Input bias current: 0.05 μA (for thermocouple and resistance-temperature detector (RTD))
- Resistance-temperature detector (RTD) measured current: About 0.16 mA
- Input resistance  
1 MΩ or more for thermocouple/mV input  
About 1 MΩ for voltage input  
About 250 Ω for current input (with built-in shunt resistance)
- Allowable signal source resistance  
250 Ω or less for thermocouple/mV input  
Effect of signal source resistance: 0.1 μV/Ω or less  
2 kΩ or less for DC voltage input  
Effect of signal source resistance: about 0.01%/100 Ω
- Allowable wiring resistance  
Up to 150 Ω per line for resistance-temperature detector (RTD) input (conductor resistance between the three lines shall be equal)  
Effect of wiring resistance: ±0.1°C/10 Ω
- Allowable input voltage/current  
±10 V DC for thermocouple/mV/mA or resistance-temperature detector (RTD) input  
±20 V DC for V input  
±40 mA DC for mA input
- Noise reduction ratio  
40 dB or more (at 50/60 Hz) in normal mode  
120 dB or more (at 50/60 Hz) in common mode
- Reference junction compensation error  
±1.0°C (15 to 35°C)  
±1.5°C (-10 to 5°C and 35 to 50°C)

### Analog Output Specifications (Suffix code: -C)

- Number of points  
Control output: 1 point
- Output functions  
Current output
- Current output  
4 to 20 mA DC or 0 to 20 mA DC/load resistance 600 Ω or less
- Current output accuracy  
±0.1% of span (however, ±5% of span for 1 mA or less)  
The accuracy is that in the standard operating conditions: 23 ±2°C, 55 ±10%RH, and power frequency at 50/60 Hz

### Analog Output Specifications (Suffix code: -V)

- Number of points  
Control output: 1 point
- Output functions  
Voltage pulse output

- Current output  
4 to 20 mA DC or 0 to 20 mA DC/load resistance  
600 Ω or less
- Voltage pulse output  
Application: time proportional output  
ON voltage: 12 V or more/load resistance of 600  
Ω or more  
OFF voltage: 0.1 V DC or less  
Time resolution: 10 ms or 0.1% of output value,  
whichever is larger

#### Contact Input Specifications (Suffix code: -R)

- Types of contact and number of points  
Control relay output: one, 1c-contact point
- Input type: no-voltage contact input or transistor con-  
tact input
- Contact rating  
1c-contact: 3 A at 250 V AC or 3 A at 30 V DC  
(resistance load)
- \*: The control output should always be used with a  
load of 10 mA or more.
- Application: ON/OFF output or time proportional  
output
- Time resolution for control output: 10 ms or 0.1% of  
output value, whichever is larger

#### Relay Contact Output Specifications

- Types of contact and number of points  
Alarm output: 2, 1a-contact points (Common is  
separated)
- Contact rating  
1a-contact:  
For alarm output: 1 A at 240 V AC or 1 A at  
30 V DC (resistance load)
- \*: The alarm output should always be used with a load of 1  
mA or more.
- Application: alarm output, FAIL output, etc.

#### 24 V DC Loop Power Supply Specifications (for /LP Option)

- Application: Power is supplied to the 2-wire transmitter.
- Supply voltage: 21.6 to 28.0 V DC
- Rated current: 4 to 20 mA DC
- Maximum supply current: About 30 mA (with short-  
circuit current limiting circuit)

#### Safety and EMC Standards

- Safety:  
Compliant with IEC/EN 61010-1 (CE), IEC/EN 61010-  
2-201 (CE), IEC/EN 61010-2-030 (CE), approved by  
CAN/CSA C22.2 No. 61010-1 (CSA), approved by UL  
61010-1.  
Installation category: II  
Pollution degree: 2  
Measurement category: I (CAT I) (UL, CSA)  
O (Other) (CE)  
Rated measurement input voltage: Max. 10 V DC  
Rated transient overvoltage: 1500 V (\*)
- \*: This is a reference safety standard value for measure-  
ment category I of CSA/UL 61010-1, and for measure-  
ment category O of IEC/EN 61010-2-030. This value is  
not necessarily a guarantee of instrument performance.
- EMC standards:  
Compliant with  
CE marking  
EN 61326-1 Class A, Table 2 (For use in industrial  
locations),  
EN 61326-2-3
- \*: The instrument continues to operate at a measurement  
accuracy of within ±20% of the range during testing.

EN 55011 Class A, Group 1

EN 61000-3-2 Class A

EN 61000-3-3

EMC Regulatory Arrangement in Australia and New Zealand

EN 55011 Class A, Group 1

- KC marking: Electromagnetic wave interference  
prevention standard, electromagnetic wave protection  
standard compliance

#### Power Supply Specifications and Isolation

- Power supply  
Rated voltage: 100 to 240 V AC (+10%/-15%), 50/60 Hz  
24 V AC/DC (+10%/-15%) (When the  
/DC option is specified)
- Power consumption: 15 VA (For the /DC option. DC:  
7 VA, AC: 11 VA)
- Storage: Nonvolatile memory
- Allowable power interruption time: 20 ms (at 100 V AC)
- Withstanding voltage  
2300 V AC for 1 minute between primary and  
secondary terminals (UL, CSA)  
3000 V AC for 1 minute between primary and  
secondary terminals (CE)  
1500 V AC for 1 minute between primary terminals  
500 V AC for 1 minute between secondary  
terminals  
(Primary terminals = Power (\*) and relay output  
terminals, Secondary terminals = Analog I/O signal  
terminals, communication terminals,  
and functional grounding terminals.)
- \*: Power terminals for 24 V AC/DC models are the  
secondary terminals.
- Insulation resistance  
Between power supply terminals and a grounding  
terminal: 20 MΩ or more at 500 V DC
- Isolation specifications

PV (universal) input terminal	Internal circuits	Power supply
Control (voltage pulse, analog) output terminal Control relay (c-contact) output terminal		
Alarm-1 relay (a-contact) output terminal		
Alarm-2 relay (a-contact) output terminal		
RS485 communication terminal		
24 V DC loop power supply terminal		

The circuits divided by lines are insulated mutually.

---

## Environmental Conditions

### Normal operating conditions

- Ambient temperature: -10 to 50°C (-10 to 40°C for side-by-side mounting of controllers)
- Ambient humidity: 20 to 90% RH (no condensation)
- Magnetic field: 400 A/m or less
- Continuous vibration (at 5 to 9 Hz) Half amplitude of 1.5 mm or less  
(at 9 to 150 Hz) 4.9 m/s<sup>2</sup> or less, 1 oct/min for 90 minutes each in the three axis directions
- Rapid vibration: 14.7 m/s<sup>2</sup>, 15 s or less
- Impact: 98 m/s<sup>2</sup> or less, 11 msec.
- Installation altitude: 2,000 m or less above sea level
- Warm-up time: 30 minutes or more after the power is turned on
- Start-up time within 10 s

### Transportation and Storage Conditions


- Temperature: -25 to 70°C
- Temperature change rate: 20°C per hour or less
- Humidity: 5 to 95%RH (no condensation)

### Effects of Operating Conditions



- Effect of ambient temperature  
For voltage or TC input:  
±1 μV/°C or ±0.01% of F.S. (instrument range)/°C, whichever is greater  
For RTD input:  
±0.05°C/°C (ambient temperature) or less  
For current input:  
±0.01% of F.S. (instrument range)/°C  
For analog output:  
±0.02% of F.S./°C or less
- Effect of power supply fluctuation:  
For analog input: ±0.05% of F.S. (instrument range) or less  
For analog output: ±0.05% of F.S. or less  
(Each within rated voltage range)

## Block Diagram

### Single Loop Control




## Terminal Arrangement



## External Dimensions and Panel Cutout Dimensions

Unit: mm



## Construction, Mounting, and Wiring

- Dust-proof and drip-proof: IP66 (Front panel) (Except for side-by-side close mounting)/NEMA4 \*
  - \*: Hose-down test only
- Material: Polycarbonate resin (Flame retardancy: UL94 V-0)
- Case color: White (Light gray) or Black (Light Charcoal gray)
- Weight: 0.5 kg or less
- External dimensions (mm): 48 (width) x 96 (height) x 65 (depth from the panel surface)
- Mounting: Direct panel mounting; mounting bracket, one each for upper and lower mounting
- Panel cutout dimensions (mm):  $45^{+0.6/0}$  (width) x  $92^{+0.8/0}$  (height)
- Mounting position: Up to 30 degrees above the horizontal. No downward tilting allowed.
- Wiring: M3 screw terminal with square washer (signal wiring and power)

## Model and Suffix Code

Model	Suffix code	Optional suffix code	Description
<b>UT32A</b>			Digital Indicating Controller (Power supply: 100-240 V AC) (provided with 2 DOs)
Type 1: Basic control	-V		Voltage pulse output type
	-C		Current output type
	-R		Relay output type
Type 2:Functions	0		None
	1		RS-485 communication (Max. 38.4 kbps, 2-wire/4-wire) <sup>(*)1</sup>
Type 3:Fixed code	0		None
Display language <sup>(*)2</sup>	-1		English (Default. Can be switched to other language by the setting.)
	-2		German (Default. Can be switched to other language by the setting.)
	-3		French (Default. Can be switched to other language by the setting.)
	-4		Spanish (Default. Can be switched to other language by the setting.)
Case color	0		White (Light gray)
	1		Black (Light charcoal gray)
Fixed code		-00	Always "-00"
Optional suffix codes		/LP	24 V DC loop power supply
		/DC	Power supply 24 V AC/DC
		/CT	Coating <sup>(*)3</sup>
		/CV	Terminal cover

\*1: When the /LP option is specified, the RS-485 communication of the Type 2 code "1" is 2-wire system.

\*2: English, German, French, and Spanish are available for the guide display.

\*3: When the /CT option is specified, the UT32A does not conform to the safety standards (UL and CSA) and CE marking (Products with /CT option are not intended for EEA-market).

## ■ Items to be specified when ordering

Model and suffix codes, whether User's Manual and QIC required.

## ■ Standard accessories

Brackets (mounting hardware), Unit label, Operation Guide

## ■ Special Order Items

Model code	Suffix code	Description
LL50A	-00	Parameter Setting Software
X010	See the General Specifications (*)	Resistance Module

\*: Necessary to input the current signal to the voltage input terminal.

Name	Model
Terminal cover (for UT32A)	UTAP002
User's Manual (CD)	UTAP003

## User's Manual

Product user's manuals can be downloaded or viewed at the following URL. To view the user's manual, you need to use Adobe Reader 7 or later by Adobe Systems.

**URL:** <http://www.yokogawa.com/ns/ut/im/>





---

# Revision Information

- Title : UT32A Digital Indicating Controller (Entry Model) User's Manual
- Manual No. : IM 05P01F31-01EN

**Apr. 2015/1st Edition**

Newly published

**Mar. 2016/2nd Edition**

Safety standard IEC/EN 61010-2-201 conformity and error correction.

- Written by Yokogawa Electric Corporation
  - Published by Yokogawa Electric Corporation  
2-9-32 Nakacho, Musashino-shi, Tokyo 180-8750, JAPAN
-





---

**YOKOGAWA ELECTRIC CORPORATION****Headquarters**

2-9-32, Nakacho, Musashino-shi, Tokyo, 180-8750 JAPAN  
Phone : 81-422-52-5555

**Branch Sales Offices**

Osaka, Nagoya, Hiroshima, Kurashiki, Fukuoka, Kitakyusyu

---

**YOKOGAWA CORPORATION OF AMERICA****Head Office**

12530 West Airport Blvd, Sugar Land, Texas 77478, USA  
Phone : 1-281-340-3800 Fax : 1-281-340-3838

**Georgia Office**

2 Dart Road, Newnan, Georgia 30265, USA  
Phone : 1-800-888-6400/ 1-770-253-7000 Fax : 1-770-254-0928

**YOKOGAWA AMERICA DO SUL LTDA.**

Praca Acapulco, 31 - Santo Amaro, São Paulo/SP, BRAZIL, CEP-04675-190  
Phone : 55-11-5681-2400 Fax : 55-11-5681-4434

**YOKOGAWA EUROPE B. V.**

Euroweg 2, 3825 HD Amersfoort, THE NETHERLANDS  
Phone : 31-88-4641000 Fax : 31-88-4641111

**YOKOGAWA ELECTRIC CIS LTD.**

Grokholskiy per 13 Building 2, 4th Floor 129090, Moscow, RUSSIA  
Phone : 7-495-737-7868 Fax : 7-495-737-7869

**YOKOGAWA CHINA CO., LTD.**

3F Tower D Cartelo Crocodile Building, No.568 West Tianshan Road,  
Shanghai 200335, CHINA  
Phone : 86-21-62396262 Fax : 86-21-62387866

**YOKOGAWA ELECTRIC KOREA CO., LTD.**

(Yokogawa B/D, Yangpyeong-dong 4-Ga), 21, Seonyu-ro 45-gil, Yeongdeungpo-gu,  
Seoul, 150-866, KOREA  
Phone : 82-2-2628-6000 Fax : 82-2-2628-6400

**YOKOGAWA ENGINEERING ASIA PTE. LTD.**

5 Bedok South Road, Singapore 469270, SINGAPORE  
Phone : 65-6241-9933 Fax : 65-6241-2606

**YOKOGAWA INDIA LTD.**

Plot No.96, Electronic City Complex, Hosur Road, Bangalore - 560 100, INDIA  
Phone : 91-80-4158-6000 Fax : 91-80-2852-1442

**YOKOGAWA AUSTRALIA PTY. LTD.**

Tower A, 112-118 Talavera Road, Macquarie Park NSW 2113, AUSTRALIA  
Phone : 61-2-8870-1100 Fax : 61-2-8870-1111

**YOKOGAWA MIDDLE EAST & AFRICA B.S.C.(C)**

P.O. Box 10070, Manama, Building 577, Road 2516, Busaiteen 225, Muharraq,  
Kingdom of BAHRAIN  
Phone : 973-17358100 Fax : 973-17336100

Apr. '15