

# Quick Start Manual



Read the user's manual carefully before starting to use the unit.  
Producer reserves the right to implement changes without prior notice.

### Symbol Explanation



This symbol denotes especially important guidelines concerning the installation and operation of the device. Not complying with the guidelines denoted by this symbol may cause an accident, damage or equipment destruction.

### Basic Requirements | User Safety




- Do not use the unit in areas threatened with excessive shocks, vibrations, dust, humidity, corrosive gasses and oils.
- Do not use the unit in areas where there is risk of explosions.
- Do not use the unit in areas with significant temperature variations, exposure to condensation or ice.
- The manufacturer is not responsible for any damages caused by inappropriate installation, not maintaining the proper environmental conditions and using the unit contrary to its assignment.
- If in the case of a unit malfunction there is a risk of a serious threat to the safety of people or property additional, independent systems and solutions to prevent such a threat must be used.
- The unit uses dangerous voltage that can cause a lethal accident. The unit must be switched off and disconnected from the power supply prior to starting installation of troubleshooting (in the case of malfunction).
- Do not attempt to disassemble, repair or modify the unit yourself. The unit has no user serviceable parts.
- Defective units must be disconnected and submitted for repairs at an authorized service center.

### Specifications

General		
Display	LED   4 x 20mm High   Red   Adjustable Brightness	
Displayed Values	-999 ± 9999   -99999 ± 999999*	
Stability	50 ppm   °C	
Transmission Parameters	1200...115200 bit/s, 8N1 / 8N2	
Protection Class	NEMA 4X   IP67	
Input Signal   Supply		
Standard	Current: 4-20mA   0-20mA   0-5V*   0-10V*	
Voltage	85 - 260V AC/DC   16 - 35V AC, 19 - 50V DC*	
Output Signal   Supply		
Standard	2 x Relays (5A)   1 x Relay (5A) + 4-20mA	
Voltage	24VDC	
Passive current output *	4-20mA   (Operating Range Max. 2.8 - 24mA)	
Performance		
Accuracy	0.1% @ 25°C One Digit	
Accuracy According to IEC 60770 - Limit Point Adjustment   Non-Linearity   Hysteresis   Repeatability		
Temperatures		
Operating Temperatures	-40 - 158°F   -40 - 70°C	
Materials   Wetted		
Housing	Polycarbonate	
Part Number	Input	Output
TVL-550-1821	4-20mA	2 Relay
TVL-550-1829	4-20mA	4-20mA + 1 Relay

\*Contact Factory for different options

### Front Panel Description



### Function of Push Buttons



Symbol used in the manual : [ESC/MENU]

**Functions:**

- Enter to main menu (press and hold for at least 2 sec.)
- Exit the current Screen and Enter to previous menu (or measure mode)
- Cancel the changes made in parameter being edited



Symbol used in the manual : [ENTER]

**Functions:**

- Start to edit the parameter
- Enter into the sub-menu
- Confirmation of changes made in parameter being edited



Symbol used in the manual : [^] [v]


**Functions:**

- Change of the present menu
- Modification of the parameter value
- Change of the display mode



### Wiring Diagram

#### One RELAY CONFIGURATION

#### One 4-20mA OUTPUT



#### 2 RELAY CONFIGURATION



#### WIRE INSTALLATION

- Insert screwdriver and push wire locking mechanism open
- Insert wire
- Remove screwdriver










**Due to possible significant interference in industrial installations, appropriate measures assuring correct operation of the unit must be applied.**

The unit is not equipped with an internal fuse or power supply circuit breaker.





















For this reason, an external time-delay cut-out fuse with a small nominal current value must be used (recommended bipolar, max. 2A) and a power supply circuit breaker located near the unit.

In the case of using a monopolar fuse it must be mounted on the phase cable.

### Programming 4-20mA Input

STEPS	DISPLAY	OPERATION
<p>1 Press <b>ESC/MENU</b> Button</p> 		Press & Hold <b>ESC/MENU</b> Button   3 Sec ( <b>Relay 1</b> Appears on Display)
<p>2 Press <b>DOWN</b> Arrow</p> 		Press <b>DOWN</b> Arrow (2x) ( <b>Input</b> Appears on Display)
<p>3 Press <b>ENTER</b> Button</p> 		Press <b>ENTER</b> Button ( <b>Type</b> Appears on Display)
<p>4 Press <b>DOWN</b> Arrow</p> 		Press <b>DOWN</b> Arrow (4x) ( <b>Lo C</b> Appears on Display   4mA Set Point)
<p>5 Press <b>UP</b> or <b>DOWN</b> Arrow</p> 		Press <b>ENTER</b> Button to set Lo C   4mA   Std = 0 Press <b>UP</b> or <b>DOWN</b> Arrows to Change Value (Use the <b>ENTER</b> button to advance to the next digit)
<p>6 Press <b>ENTER</b> Button</p> 		When desired number appears Press & Hold <b>ENTER</b> for 2 Sec to lock in the set point. ( <b>SET?</b> appears on display) Press <b>ENTER</b> to confirm
<p>7 Press <b>DOWN</b> Arrow</p> 		Press <b>DOWN</b> Arrow ( <b>Hi C</b> will appear on Display   20mA Set Point)
<p>8 Press <b>ENTER</b> Button</p> 		Press <b>ENTER</b> Button to set Hi C   20mA* Press <b>UP</b> or <b>DOWN</b> Arrows to Change Value (Use the <b>ENTER</b> button to advance to the next digit)
<p>9 Press <b>ENTER</b> Button</p> 		When desired number appears Press & Hold <b>ENTER</b> for 2 Sec to lock in the set point. ( <b>SET?</b> appears on display) Press <b>ENTER</b> to confirm
<p>10 Press <b>ESC/MENU</b> Button</p> 		Press <b>ESC/MENU</b> Button (2x) (Home Screen   Current Level Reading appears on display)

### Programming 4-20mA Output

STEPS	DISPLAY	OPERATION
<p>1 Press <b>ESC/MENU</b> Button</p> 		Press & Hold <b>ESC/MENU</b> Button   3 Sec ( <b>Relay 1</b> Appears on Display)
<p>2 Press <b>DOWN</b> Arrow</p> 		Press <b>DOWN</b> Arrow (3x) ( <b>Output</b> Appears on Display)
<p>3 Press <b>ENTER</b> Button</p> 		Press <b>ENTER</b> Button ( <b>Output Mode</b> Appears on Display)
<p>4 Press <b>DOWN</b> Arrow</p> 		Press <b>DOWN</b> Arrow (1x) ( <b>Out L</b> Appears on Display   4mA Set Point)
<p>5 Press <b>UP</b> or <b>DOWN</b> Arrow</p> 		Press <b>ENTER</b> Button to set Out L   4mA   Std = 0 Press <b>UP</b> or <b>DOWN</b> Arrows to Change Value (Use the <b>ENTER</b> button to advance to the next digit)
<p>6 Press <b>ENTER</b> Button</p> 		When desired number appears Press & Hold <b>ENTER</b> for 2 Sec to lock in the set point. ( <b>SET?</b> appears on display) Press <b>ENTER</b> to confirm
<p>7 Press <b>DOWN</b> Arrow</p> 		Press <b>DOWN</b> Arrow (1x) ( <b>Out H</b> will appear on Display   20mA Set Point)
<p>8 Press <b>ENTER</b> Button</p> 		Press <b>ENTER</b> Button to set Out H   20mA* Press <b>UP</b> or <b>DOWN</b> Arrows to Change Value (Use the <b>ENTER</b> button to advance to the next digit)
<p>9 Press <b>ENTER</b> Button</p> 		When desired number appears Press & Hold <b>ENTER</b> for 2 Sec to lock in the set point. ( <b>SET?</b> appears on display) Press <b>ENTER</b> to confirm
<p>10 Press <b>ESC/MENU</b> Button</p> 		Press <b>ESC/MENU</b> Button (2x) (Home Screen   Current Level Reading appears on display)

### Calculating 4-20mA Input

SENSOR TYPE	20mA Set Point
Submersible	Range of sensor / Specific Gravity = 20mA
Ultrasonic	Tank Height
Radar	Tank Height

### Programming Relays

STEPS	DISPLAY	OPERATION
1 Press <b>ESC/MENU</b> Button 		Press & hold <b>ESC/MENU</b> button   3 Sec ( <b>Relay 1</b> appears on display)
2 Press <b>ENTER</b> Button 		Press <b>ENTER</b> button ( <b>SETP</b> appears on display)
3 Press <b>ENTER</b> Button 		Press <b>ENTER</b> Button (Relay Set-Point Number appears on display with first digit flashing)
4 Press <b>UP</b> or <b>DOWN</b> Arrows 		Press <b>UP</b> or <b>DOWN</b> arrows to increase or decrease number to desired setpoint (Use the <b>ENTER</b> button to advance to the next digit)
5 Press <b>ENTER</b> Button 		When desired number appears Press & Hold <b>ENTER</b> for 2 Sec to lock in the set point. ( <b>SET?</b> appears on display) Press <b>ENTER</b> to confirm ( <b>SETP</b> appears on display)
6 Press <b>DOWN</b> Arrow 		Press <b>DOWN</b> arrow to select relay parameters ( <i>ON-OFF, HYSTERISIS, Mode, Time, Unit, Alarm</i> ) Repeat steps 3-5 for each parameter 
7 Press <b>ENTER</b> Button 		Once Relay Parameters are Set, Press & Hold <b>ENTER</b> for 2 Sec to lock in the set point. ( <b>SET?</b> appears on display) Press <b>ENTER</b> to confirm
8 Press <b>ESC/MENU</b> Button 		Press <b>ESC/MENU</b> Button (2x) (Home Screen   Current Level Reading appears on display)

### RS485 Modbus Programming

## 11. THE MODBUS PROTOCOL HANDLING

Transmission parameters: 1 start bit, 8 data bits, 1 or 2 stop bit (2 bits are send, 1 and 2 bits are accepted when receive), no parity control  
 Baud rate: selectable from: 1200 to 115200 bits/second  
 Transmission protocol: MODBUS RTU compatible

The device parameters and display value are available via RS-485 interface, as HOLDING-type registers (numeric values are given in U2 code) of Modbus RTU protocol. The registers (or groups of the registers) can be read by 03h function, and wrote by 06h (single registers) or 10h (group of the registers) accordingly to Modbus RTU specification. Maximum group size for 03h and 10h functions can not exceeds 16 registers (for single frame).



The device interprets the broadcast messages, but then do not sends the answers.

### 11.1. LIST OF REGISTERS

Register	Write	Range	Register description
01h	No	-999 ÷ 9999	Measurement value (no decimal point)
02h	No	0h, A0h, 60h	The status of the current measurement; <b>0h</b> - data valid; <b>A0h</b> - top border of the measurement range is exceeded; <b>60h</b> - bottom border of the measurement range is exceeded;
03h	Yes	0 ÷ 3	" <b>Pnt</b> " parameter in " <b>InPt</b> " menu (decimal point position) <b>0</b> - " 0"; <b>1</b> - " 0.0"; <b>2</b> - " 0.00"; <b>3</b> - "0.000"
04h	Yes	see descr.	State of the relays and alarm LED (binary format) (1 - on, 0 - off): <b>00000000 000e00ba</b> <b>a</b> - relay R1; <b>b</b> - relay R2; <b>e</b> - alarm LED; If written, only <b>a</b> , <b>b</b> bits are important (others are ignored) these bits allows user to control the relays via RS-485 interface
05h <sup>1</sup>	Yes	0h ÷ 1800h	State of active current output, expressed in 1/256 mA units – it means that high byte express integer part, and low byte fractional part of desired output current.
	Yes	2CCh÷1800h	State of passive current output, expressed in 1/256 mA units – it means that high byte express integer part, and low byte fractional part of desired output current.
	Yes	0h ÷ 1600h	State of active voltage output, expressed in 1/512 V units – it means that high byte express integer part, and low byte fractional part of desired output voltage.
06h	No	-999 ÷ 9999	Peak (drop) value (no decimal point)
10h	Yes	0 ÷ 5	" <b>tyPE</b> " parameter in " <b>InPt</b> " menu (nominal input range). <b>0</b> - 0-20 mA range; <b>1</b> - 4-20 mA range; <b>2</b> - 0-10 V range; <b>3</b> - 2-10 V range; <b>4</b> - 0-5 V range; <b>5</b> - 1-5 V range
11h	Yes	0 ÷ 5	" <b>CHAR</b> " parameter in " <b>InPt</b> " menu (characteristic type) <b>0</b> - linear; <b>1</b> - square; <b>2</b> - square root; <b>3</b> - user defined; <b>4</b> - volume characteristics of a cylindrical tank in the vertical position; <b>5</b> - volume characteristics of a cylindrical tank in the horizontal position
12h	Yes	0 ÷ 5	" <b>Filt</b> " parameter in " <b>InPt</b> " menu (measurement filtering rate)



### RS485 Modbus Programming

Register	Write	Range	Register description
13h	Yes	0 ÷ 3	“Pnt” parameter in “InPt” menu (the copy of 03h register, decimal point position) <b>0</b> - “ 0”; <b>1</b> - “ 0.0”; <b>2</b> - “ 0.00”; <b>3</b> - “0.000”
14h	Yes	-999 ÷ 9999	“Lo C” parameter in “InPt” menu, no decimal point included
15h	Yes	-999 ÷ 9999	“Hi C” parameter in “InPt” menu, no decimal point included
16h	Yes	0 ÷ 999	“Lo r” parameter in “InPt” menu, in 0.1%
17h	Yes	0 ÷ 199	“Hi r” parameter in “InPt” menu, in 0.1%
19h	Yes	0 ÷ 9999	“t h1” parameter in “InPt” menu, no decimal point included
1Ah	Yes	0 ÷ 9999	“t h2” parameter in “InPt” menu, no decimal point included
1Bh	Yes	0 ÷ 9999	“t h3” parameter in “InPt” menu, no decimal point included
1Ch	Yes	0 ÷ 9999	“t d” parameter in “InPt” menu, no decimal point included
1Dh	Yes	0 ÷ 9999	“t Sn” parameter in “InPt” menu, no decimal point included
1Eh	Yes	0 ÷ 9999	“t Sh” parameter in “InPt” menu, no decimal point included
20h <sup>2</sup>	Yes	0 ÷ 199	Device address
21h	No	21F0h	Device identification code (ID)
22h <sup>3</sup>	Yes	0 ÷ 7	“bAud” parameter in “rS” menu (baud rate); <b>0</b> - 1200 baud; <b>1</b> - 2400 baud; <b>2</b> - 4800 baud; <b>3</b> - 9600 baud; <b>4</b> - 19200 baud; <b>5</b> - 38400 baud; <b>6</b> - 57600 baud; <b>7</b> - 115200 baud
23h <sup>4</sup>	Yes	0 ÷ 1	“mbAc” parameter in “rS” menu (permission to write registers via RS-485 interface); <b>0</b> - write denied ; <b>1</b> - write allowed
24h	Yes	see descr.	Parameters of “SECU” menu (binary format (0 - „oFF”, 1 - „on”): <b>bit 0</b> - “A r1” parameter; <b>bit 1</b> - “A r2” parameter
25h	Yes	0 ÷ 5	“rESP” parameter in “rS” menu (additional response delay); <b>0</b> - no additional delay; <b>1</b> - “10c” option; <b>2</b> - “20c” option; <b>3</b> - “50c” option; <b>4</b> - “100c” option; <b>5</b> - “200c” option;
27h	Yes	0 ÷ 99	“mbtO” parameter in “rS” menu (maximum delay between received frames); <b>0</b> - no delay checking; <b>1 ÷ 99</b> - maximum delay expressed in seconds
2Dh	Yes	1 ÷ 8	“bri” parameter (display brightness); <b>1</b> - the lowest brightness; <b>8</b> - the highest brightness
2Fh	Yes	0 ÷ 1	“Edit” parameter (numerical parameters edit mode); <b>0</b> - „dig” mode; <b>1</b> - „SLid” mode
30h	Yes	-999 ÷ 9999	“SEtP” parameter in “rEL1” menu, no decimal point included
31h	Yes	-999 ÷ 999	“HySt” parameter in “rEL1” menu, no decimal point included
32h	Yes	0 ÷ 5	“modE” parameter in “rEL1” menu: <b>0</b> - “noAC” mode; <b>1</b> - “on” mode; <b>2</b> - “oFF” mode; <b>3</b> - “in” mode; <b>4</b> - “out” mode; <b>5</b> - “modb” mode
33h	Yes	0 ÷ 999	“t on” parameter in “rEL1” menu, expressed in tenth of seconds or tenth of minutes depend on “unit” parameter - register no. 35h)

### RS485 Modbus Programming

Register	Write	Range	Register description
34h	Yes	0 ÷ 999	“toFF” parameter in “rEL1” menu, expressed in tenth of seconds or tenth of minutes depend on “unit” parameter - register no. 35h)
35h	Yes	0 ÷ 1	“unit” parameter in “rEL1” menu: 0 - seconds; 1 - minutes
36h	Yes	0 ÷ 2	“AL” parameter in “rEL1” menu: 0 - no changes; 1 - on; 2 - off
37h	Yes	-999 ÷ 9999	“SEt2” parameter in “rEL1” menu, no decimal point included
38h	Yes	-999 ÷ 9999	“SEtP” parameter in “rEL2” menu, no decimal point included
39h	Yes	-999 ÷ 999	“HySt” parameter in “rEL2” menu, no decimal point included
3Ah	Yes	0 ÷ 5	“modE” parameter in “rEL2” menu: 0 - “noAC” mode; 1 - “on” mode; 2 - “oFF” mode; 3 - “in” mode; 4 - “out” mode; 5 - “modb” mode
3Bh	Yes	0 ÷ 999	“t on” parameter in “rEL2” menu, expressed in tenth of seconds or tenth of minutes depend on “unit” parameter - register no. 3Dh)
3Ch	Yes	0 ÷ 999	“toFF” parameter in “rEL2” menu, expressed in tenth of seconds or tenth of minutes depend on “unit” parameter - register no. 3Dh)
3Dh	Yes	0 ÷ 1	“unit” parameter in “rEL2” menu: 0 - seconds; 1 - minutes
3Eh	Yes	0 ÷ 2	“AL” parameter in “rEL2” menu: 0 - no changes; 1 - on; 2 - off
3Fh	Yes	-999 ÷ 9999	“SEt2” parameter in “rEL2” menu, no decimal point included
50h	Yes	0 ÷ 1	“modE” parameter in “HOLd” menu (type of detected changes): 0 - peaks; 1 - drops
51h	Yes	0 ÷ 9999	“PEA” parameter in “HOLd” menu (minimum detectable change, no decimal point included)
52h	Yes	0 ÷ 199	“timE” parameter in “HOLd” menu, maximum peaks' (or drops') display time expressed in seconds
53h	Yes	0 ÷ 1	“HdiS” parameter in “HOLd” menu: 0 - “rEAL” mode ; 1 - “HOLd” mode
54h	Yes	0 ÷ 1	“H r1” parameter in “HOLd” menu : 0 - “rEAL” mode ; 1 - “HOLd” mode
55h	Yes	0 ÷ 1	“H r2” parameter in “HOLd” menu: 0 - “rEAL” mode ; 1 - “HOLd” mode
58h <sup>1</sup>	Yes	0 ÷ 1	“HOut” parameter in “HOLd” menu: 0 - “rEAL” mode ; 1 - “HOLd” mode
70h <sup>5</sup>	Yes	-999 ÷ 1999	The value of „X” coordinate of point no. 1 of the user defined characteristic, expressed in 0.1%
71h <sup>5</sup>	Yes	-999 ÷ 9999	The value of „Y” coordinate of point no. 1 of the user defined characteristic, no decimal point included
72h <sup>5</sup> ÷ 95h <sup>5</sup>			Further pairs of „X” - „Y” coordinates of points no. 2 ÷ 19 of the user defined characteristic

### RS485 Modbus Programming

Register	Write	Range	Register description
96h <sup>5</sup>	Yes	-999 ÷ 1999	The value of „X” coordinate of point no. 20 of the user defined characteristic, expressed in 0.1%
97h <sup>5</sup>	Yes	-999 ÷ 9999	The value of „Y” coordinate of point no. 20 of the user defined characteristic, no decimal point included
A0h <sup>1</sup>	Yes	0 ÷ 3	“Omod” parameter in “OUTP” menu (active current output mode) 0 - current output disabled; 1 - current output enabled with 4÷20mA mode; 2 - current output enabled with 0÷20mA mode; 3 - current output controlled via RS-485 interface
	Yes	0 ÷ 2	“Omod” parameter in “OUTP” menu (passive current output mode) 0 - current output disabled; 1 - current output enabled with 4÷20mA mode; 2 - current output controlled via RS-485 interface
	Yes	0 ÷ 5	“Omod” parameter in “OUTP” menu (active voltage output mode) 0 - voltage output disabled; 1 - voltage output enabled with 0÷5V mode; 2 - voltage output enabled with 1÷5V mode; 3 - voltage output enabled with 0÷10V mode; 4 - voltage output enabled with 2÷10V mode; 5 - voltage output controlled via RS-485 interface
A1h <sup>1</sup>	Yes	-999 ÷ 9999	“OUTL” parameter in “OUTP” menu, no decimal point included
A2h <sup>1</sup>	Yes	-999 ÷ 9999	“OUTH” parameter in “OUTP” menu, no decimal point included
A3h <sup>1</sup>	Yes	0 ÷ 999	“Lo r” parameter in “OUTP” menu, for active current output and active voltage output, expressed in 0.1%
	Yes	0 ÷ 299	“Lo r” parameter in “OUTP” menu for passive current output, expressed in 0.1%
A4h <sup>1</sup>	Yes	0 ÷ 199	“Hi r” parameter in “OUTP” menu for active and passive current output, expressed in 0.1%
	Yes	0 ÷ 99	“Hi r” parameter in “OUTP” menu for active voltage output, expressed in 0.1%
A5h <sup>1</sup>	Yes	0 ÷ 3	“AL” parameter in “OUTP” menu (active current output value on critical exception): 0 - no change; 1 - 22.1 mA; 2 - 3.4 mA; 3 - 0 mA
	Yes	0 ÷ 2	“AL” parameter in “OUTP” menu (passive current output value on critical exception): 0 - no change; 1 - 22.1 mA; 2 - 3.4 mA
	Yes	0 ÷ 5	“AL” parameter in “OUTP” menu (active voltage output value on critical exception): 0 - no change; 1 - 11 V; 2 - 5.5; 3 - 1.2 V; 4 - 0.6 V; 5 - 0 V

- 1 - these registers are active only if device is equipped with current or voltage output
- 2 - after writing to register no 20h the device responds with an “old” address in the message.
- 3 - after writing to register no 22h the device responds with the new baud rate.
- 4 - the value of the “mbAc” parameter is also connected to write to this register, so it is possible to block a writes, but impossible to unblock writes via RS-485 interface, The unblocking of the writes is possible from menu level only.
- 5 - the pairs of „X-Y” coordinates may be defined for any free point. The pair is “free” (it means that particular point is not defined) if „X” coordinate of this point is equal 8000h. After writing both X and Y coordinate the point is defined and used in calculation of result. The coordinates of any point can be changed at any time.

### RS485 Modbus Programming

#### 11.2. TRANSMISSION ERRORS DESCRIPTION

If an error occurs while write or read of single register, then the device sends an error code according to Modbus RTU specifications (example message no 1).

Error codes:

**01h** - illegal function (only functions 03h, 06h and 10h are available),

**02h** - illegal register address

**03h** - illegal data value

**08h** - no write permission ( see: “**mbAc**” parameter)

**A0h** - exceed of upper border of input range

**60h** - exceed of lower border of input range

A0h and 60h codes can appear only during reg. 01h is reading by 03h function (read of a single register).

#### 11.3. EXAMPLES OF QUERY/ANSWER FRAMES

Examples apply for device with address 1. All values are represent hexadecimal.

**Field description:**

**ADDR** Device address on modbus network

**FUNC** Function code

**REG H,L** Starting address (address of first register to read/write, Hi and Lo byte)

**COUNT H,L** No. of registers to read/write (Hi and Lo byte)

**BYTE C** Data byte count in answer frame

**DATA H,L** Data byte (Hi and Lo byte)

**CRC L,H** CRC error check (Hi and Lo byte)

##### 1. Read of the displayed value (measurement), SRP-N118 device address = 01h:

ADDR	FUNC	REG H,L		COUNT H,L		CRC L,H	
01	03	00	01	00	01	D5	CA

a) The answer (we assume that the measure result is not out of range):

ADDR	FUNC	BYTE C	DATA H,L		CRC L,H	
01	03	02	00	FF	F8	04

DATA H, L - displayed value = 255, no decimal point.

Decimal point position can be read from reg. 03h.

### RS485 Modbus Programming

b) The answer (if an error occur):

ADDR	FUNC	ERROR	CRC L,H	
01	83	60	41	18

ERROR - error code = 60h, bottom border of the measurement range is exceeded

#### 2. Read of device ID code

ADDR	FUNC	REG H,L		COUNT H,L		CRC L,H	
01	03	00	21	00	01	D4	00

The answer:

ADDR	FUNC	BYTE C	DATA H,L		CRC L,H	
01	03	02	21	F0	A0	50

DATA - identification code (21F0h)

#### 3. Change of the device address from 1 to 2 (write to reg. 20h)

ADDR	FUNC	REG H,L		DATA H,L		CRC L,H	
01	06	00	20	00	02	09	C1

DATA H - 0

DATA L - new device address (2)

The answer (the same as the message):

ADDR	FUNC	REG H,L		DATA H,L		CRC L,H	
01	06	00	20	00	02	09	C1

#### 4. Change of baud rate of all devices connected to the net (BROADCAST message).

ADDR	FUNC	REG H,L		COUNT H,L		CRC L,H	
00	06	00	22	00	04	29	D2

DATA H - 0

DATA L - 4, new baud rate 19200 baud



Device do not reply to BROADCAST-type messages.

### RS485 Modbus Programming

#### 5. Read of the registers 1, 2 and 3 in one message (example of reading a number of registries in one frame):

ADDR	FUNC	REG H,L		COUNT H,L		CRC L,H	
01	03	00	01	00	03	54	0B

COUNT L - the count of being read registers (max.16)

The answer:

ADDR	FUNC	BYTE C	DATA H1,L1		DATA H2,L2		DATA H3,L3		CRC L,H	
01	03	06	00	0A	00	00	00	01	78	B4

DATA H1, L1 - reg. 01h (10 - displayed value "1.0"),

DATA H2, L2 - reg. 02h (0 - no errors),,

DATA H3, L3 - reg. 03h (1 - decimal point position " 0.0").



**There is no full implementation of the Modbus Protocol in the device. The functions presented above are available only.**

### RS485 Modbus Programming

## 12. DEFAULT AND USER'S SETTINGS LIST

Parameter	Description	Default value	User's value	Desc. page
<b>Parameters of relay R1 operation ("rEL1" menu)</b>				
SEtP	Relay R1 threshold	20.0		29
SEt2	Relay R1 second threshold	40.0		29
HYSt	Hysteresis of relay R1	0.0		29
modE	Operation mode of relay R1	on		29
t on	Turn on delay of relay R1	0.0		30
toFF	Turn off delay of relay R1	0.0		30
unit	Unit of "t on", "toFF" parameters of relay R1	SEC		30
AL	Reaction for critical situation of relay R1	oFF		30
<b>Parameters of relay R2 operation ("rEL2" menu)</b>				
SEtP	Relay R2 threshold	40.0		29
SEt2	Relay R2 second threshold	60.0		29
HYSt	Hysteresis of relay R2	0.0		29
modE	Operation mode of relay R2	on		29
t on	Turn on delay of relay R2	0.0		30
toFF	Turn off delay of relay R2	0.0		30
unit	Unit of "t on", "toFF" parameters of relay R2	SEC		30
AL	Reaction for critical situation of relay R2	oFF		30
<b>Configuration of measurement input ("inPt" menu)</b>				
tYPE	Input mode	„4-20"		31
CHAr	Conversion characteristic mode	Lin		31
FiLt	Filtering ratio	0		31
Pnt	Decimal point position	0.0		31
Lo C	Minimum displayed value (for nominal range)	000.0		32
Hi C	Maximum displayed value (for nominal range)	100.0		32
t h1	Height (length) first part of the tank	00.00		32
t h2	Height (length) second part of the tank	00.00		32
t h3	Height (length) third part of the tank	00.00		32
t d	Tank diameter	00.01		32
t Sn	Distance between sensor and bottom of the tank	00.00		32
t Sh	Height of the sensor	20.00		32
Lo r	Extension of the bottom of the nominal input range	5.0 (%)		35

### RS485 Modbus Programming

<i>Parameter</i>	<i>Description</i>	<i>Default value</i>	<i>User's value</i>	<i>Desc. page</i>
Hi r	Extension of the top of the nominal input range	5.0 (%)		35
<b>Current output configuration ("OUTP" menu)</b>				
Omod	Current output mode	„4-20" (mA)		37
OUTL	Display value for 4 mA current output	0.0		37
OUTH	Display value for 20 mA current output	100.0		37
Lo r	Extension of the bottom of the nominal output range	5.0 (%)		38
Hi r	Extension of the top of the nominal output range	5.0 (%)		38
AL	Current output value on critical exception	22.1 (mA)		38
<b>Display parameters</b>				
bri	Display brightness	bri6		38
<b>Configuration of peaks detection function ("HOLd" menu)</b>				
modE	Kind of detected changes	norm		39
PEA	Minimum detected change	0.0		39
timE	Maximum time of peak displaying	0.0		39
HdiS	The type of displayed value	HOLd		39
H r1	Source of relay R1, and LED R1 control	rEAL		39
H r2	Source of relay R2, and LED R2 control	rEAL		39
HOut	Source of current output control	rEAL		39
<b>Settings of access to the configuration parameters ("SECu" menu)</b>				
A r1	Permission to changes of relay R1 threshold without of the user password knowledge	on		39
A r2	Permission to changes of relay R2 threshold without of the user password knowledge	on		39
<b>RS 485 interface configuration (menu "rS")</b>				
Addr	Device address	0		40
bAud	Baud rate	9.6		40
mbAc	Permission to changes of configuration registers	on		40
mbtO	Maximum delay between received messages	0		40
rESP	Additional delay of answer transmission	Std		40
<b>Configuration of numerical parameters edition</b>				
Edit	Numerical parameters edit mode	dig		41