

Difference Between FLIR Tools & FLIR Tools+

Feature	Flir Tools	Flir Tools+
Import and group images using USB	X	X
Create IR/photo image groups manually	X	X
Measure temperatures using spots, areas, lines, and isotherms	X	X
Measure a temperature difference (DeltaT)	X	X
Adjust object parameters	X	X
View a live image	X	X
Save IR JPEGs from a live image	X	X
Record a video sequence (SEQ)		X
Replay and edit recorded sequence	X	X
Export a recorded sequence to AVI	X	X
Create a temporal plot	X	X
Export plot data to Excel	X	X
Export an image to CSV format	X	X
Create a Panorama image		X
Create a PDF report	X	X
Create a Microsoft Word report		X
Create text annotation templates for the camera	X	X
Add/edit text annotations and image descriptions	X	X
Listen to IR voice comments	X	X

Note 1: USB import is only possible with cameras that connect to the PC as a Mass Storage Device.

Note 2: Live imaging and recording requires a compatible USB Video, Ethernet, or Firewire camera.