

Chino LE5000 SERIES - Change between Deg.C and Deg.F

1. Power ON and wait until the recorder fully boots up
2. Press [**MENU**] key (the screen will change to MENU Mode)
3. Press and hold the [**FUNC1**] key for ~10+ seconds.
4. Deg.C / Deg.F selection screen will appear on the screen. Make the necessary change using the keyboard.
5. Press the [**Esc**] key to return to the main display

