



	Vac)	(230 Vac)			(115 Vac)	(230Vac)			(115 Vac)	(230Vac)	
Nova-Strobe AA *	AC Powered										
Nova-Strobe AB *	X	X							X	X	
Nova-Strobe BA	AC Powered										
Nova-Strobe BB	X	X									
Nova-Strobe DB *	X	X							X	X	
Nova-Strobe DB Plus			X	X							
Nova-Strobe DA Plus	AC Powered										
Palm Strobe							X	X			X
Phaser-Strobe PB	X	X			X	X					
Self-Contained DA Plus SC	AC Powered										
Machine Strobe LSSC	AC Powered										
Vibration Strobe	X	X							X	X	
<b>Self-Powered Sensors</b>											
SPS-5	X	X									
SPLS-5*	X	X									
SLS-115/230											X
* Obsolete											

Electrical Specifications	Re-chargers/Power Supplies					
	R-5 R-6	FR-3A FR-4	PSC-3 PSC-4	R-115 R-230	PR115 PR230	PR UNIVERSAL
<b>DC Charging Volts</b>	7.8V	6.9 V	7.0 V	12V	9V	9V
<b>DC Charging Current</b>	300 mA	1 Amp	100 mA	650mA	300mA	1.1A
<b>DC Volts (No Load)</b>	11 V	14.4V	7.6V	17.4V	15V	9.1V

**Notes**

R-5 & R-6: 14 Hr. Slow Recharger. Only use with AB, BB,DB, VB & PB Strobes.  
FR-3A and FR-4: 3-4Hr. Fast Recharger. Only use with DB and AB Strobes  
R-115 & R-230: 3 Hr. Fast Recharger. Only use with DB Plus Strobes  
PSC-3 & PSC-4: Continuous Operation AC Power Supply and 12 Hr. Recharger. Only use with PB Strobes  
PR115 and PR230: Palm Strobe 6-8 Hour Recharger  
PR Universal: Palm Strobe 115Vac to 230Vac with Universal Wall Plugs



--