

Interface Cable/Software Compatibility Information

Certain interface cables will only operate with specific loggers. They are as follows:

IFC200 (USB interface cable w/ 3.5mm headphone plug)

Will work with all MadgeTech loggers **EXCEPT**:

- Transi-Temp-EC (Single and Multi-Use versions) Yellow case loggers
- MicroTemp and MicroRHTemp data loggers

IFC110 (9-pin serial interface cable w/ 3.5mm headphone plug)

Will work with all MadgeTech loggers **EXCEPT**:

- Transi-Temp-EC (Single and Multi-Use versions) Yellow case loggers
- MicroTemp and MicroRHTemp data loggers

IFC102 (9-pin serial interface cable w/ 3.5mm headphone plug and 3.5 to 2.5mm adapter)

Necessary for the following loggers, **ONLY**:

- MicroTemp and MicroRHTemp loggers require this cable and adapter plug

IFC103 (9-pin serial interface cable with special interface, base station)

Works with these loggers, **ONLY**:

- Transi-Temp-EC (Single and Multi-Use versions) Yellow case loggers

(The interface on this interface/base station is a hard-wired, 9-pin serial plug. This part number requires the use of a USB to Serial adapter to become USB capable. We offer the USB-1, USB to Serial Adapter that will work with this cable to convert it to USB)

RFC101A - (RF, wireless receiver for use with RF loggers.) The interface on this receiver is a hard-wired, 9-pin serial plug. This part number requires the use of a USB to Serial adapter to become USB capable. We offer the USB-1, USB to Serial Adapter that will work with this device to convert it to USB. Necessary for the following loggers, **ONLY**:

- RF Logger Series

IFC202 (USB interface cable w/ 3.5mm headphone plug and 3.5mm to 2.5mm adapter)

Necessary for the following loggers, **ONLY**:

- MicroTemp and MicroRHTemp loggers require this cable and adapter plug

MadgeTech, Inc.
(603) 456-2011 Phone
(603) 456-2012 Fax
www.madgetech.com
support@madgetech.com

201 Route 103 West
PO Box 50
Warner NH 03278