Fox Thermal Instruments FT2A Display Configuration Codes

FLOW DIRECTION - NO ELBOW KIT

(F1) Flow - Left to Right



OR

(F1) Flow Down



FLOW DIRECTION - NO ELBOW KIT

(F2) Flow - Right to Left



OR

(F2) Flow Up



VERTICAL FLOW DIRECTION AND FLOWMETER POSITION

** Elbow Kit required (P/N 102299) - EXTRA CHARGE OPTION **

(F3) Flow Down - Meter Right



(F4) Flow Down - Meter Left



(F5) Flow Down - Meter Front



(F6) Flow Up - Meter Right



(F7) Flow Up - Meter Left



(F8) Flow Up - Meter Front