


# Operating Instructions

## Oxymax COS22D

Sensor for the measurement of dissolved oxygen with Memosens technology








## Table of contents








<b>1</b>	<b>About this document</b> .....	<b>4</b>	<b>10</b>	<b>Maintenance</b> .....	<b>29</b>
1.1	Warnings .....	4	10.1	Maintenance schedule .....	29
1.2	Symbols .....	4	10.2	Maintenance tasks .....	29
<b>2</b>	<b>Basic safety instructions</b> .....	<b>5</b>	10.3	Cleaning of sensor .....	29
2.1	Requirements for the personnel .....	5	10.4	Wear parts and consumables .....	30
2.2	Designated use .....	5	10.5	Checking the measurement function .....	33
2.3	Workplace safety .....	5	<b>11</b>	<b>Accessories</b> .....	<b>34</b>
2.4	Operational safety .....	6	11.1	Assemblies (selection) .....	34
2.5	Product safety .....	6	11.2	Measuring cable .....	34
<b>3</b>	<b>Device description, function</b> .....	<b>9</b>	11.3	Zero-point gel .....	35
3.1	Amperometric measuring principle .....	9	11.4	Maintenance kit .....	35
3.2	Sensor design .....	9	<b>12</b>	<b>Repair</b> .....	<b>36</b>
3.3	Membrane body .....	9	12.1	Spare parts and consumables .....	36
3.4	Memosens technology .....	10	12.2	Return .....	36
3.5	Polarization .....	10	12.3	Disposal .....	36
<b>4</b>	<b>Incoming acceptance and product identification</b> .....	<b>11</b>	<b>13</b>	<b>Technical data</b> .....	<b>37</b>
4.1	Incoming acceptance .....	11	13.1	Input .....	37
4.2	Product identification .....	11	13.2	Performance characteristics .....	37
4.3	Scope of delivery .....	12	13.3	Environment .....	39
4.4	Certificates and approvals .....	12	13.4	Process .....	39
<b>5</b>	<b>Installation</b> .....	<b>14</b>	13.5	Mechanical construction .....	40
5.1	Installation conditions .....	14	<b>14</b>	<b>EU Declaration of Conformity</b> .....	<b>42</b>
5.2	Mounting the sensor .....	14	<b>Index</b> .....	<b>43</b>	
5.3	Installation examples .....	16			
5.4	Post-installation check .....	20			
<b>6</b>	<b>Electrical connection</b> .....	<b>21</b>			
6.1	Quick wiring guide (COS22D-BA/NA only) ...	21			
6.2	Connecting the sensor .....	22			
6.3	Ensuring the degree of protection .....	22			
6.4	Post-connection check .....	22			
<b>7</b>	<b>Calibration and adjustment</b> .....	<b>23</b>			
7.1	Types of calibration .....	23			
7.2	Calibration in air .....	23			
7.3	Calculation example for the calibration value .....	23			
7.4	Zero point calibration .....	25			
<b>8</b>	<b>Commissioning</b> .....	<b>26</b>			
8.1	Function check .....	26			
8.2	Sensor polarization .....	26			
8.3	Sensor calibration .....	27			
<b>9</b>	<b>Troubleshooting</b> .....	<b>28</b>			

# 1 About this document

## 1.1 Warnings

Structure of information	Meaning
 <b>DANGER</b> <b>Causes (/consequences)</b> If necessary, Consequences of non-compliance (if applicable) ▶ Corrective action	This symbol alerts you to a dangerous situation. Failure to avoid the dangerous situation <b>will</b> result in a fatal or serious injury.
 <b>WARNING</b> <b>Causes (/consequences)</b> If necessary, Consequences of non-compliance (if applicable) ▶ Corrective action	This symbol alerts you to a dangerous situation. Failure to avoid the dangerous situation <b>can</b> result in a fatal or serious injury.
 <b>CAUTION</b> <b>Causes (/consequences)</b> If necessary, Consequences of non-compliance (if applicable) ▶ Corrective action	This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or more serious injuries.
<b>NOTICE</b> <b>Cause/situation</b> If necessary, Consequences of non-compliance (if applicable) ▶ Action/note	This symbol alerts you to situations which may result in damage to property.


## 1.2 Symbols

Symbol	Meaning
	Additional information, tips
	Permitted or recommended
	Not permitted or not recommended
	Reference to device documentation
	Reference to page
	Reference to graphic
	Result of a step

## 2 Basic safety instructions

### 2.1 Requirements for the personnel

- Installation, commissioning, operation and maintenance of the measuring system may be carried out only by specially trained technical personnel.
- The technical personnel must be authorized by the plant operator to carry out the specified activities.
- The electrical connection may be performed only by an electrical technician.
- The technical personnel must have read and understood these Operating Instructions and must follow the instructions contained therein.
- Faults at the measuring point may only be rectified by authorized and specially trained personnel.

 Repairs not described in the Operating Instructions provided must be carried out only directly at the manufacturer's site or by the service organization.

### 2.2 Designated use

The sensor is designed for the continuous measurement of dissolved oxygen in water.

The specific suitability depends on the sensor version:

- COS22D-**\*\*1\*\*\*\*\*** (standard, measuring range 0.01 to 60 mg/l)
  - Measuring, monitoring and regulating the oxygen content in fermenters
  - Monitoring the oxygen content in biotechnology facilities
- COS22D-**\*\*3/4\*\*\*\*\*** (trace measurement, measuring range 0.001 to 10 mg/l, preferred operational range 0.001 to 2 mg/l), also suitable for high CO<sub>2</sub> partial pressure
  - Monitoring inertization equipment in the food industry
  - Monitoring the residual oxygen content in carbonated fluids of the beverage industry
  - Trace measurement in industrial applications such as inertizations
  - Monitoring the residual oxygen content in boiler feedwater
  - Monitoring, measuring and regulating the oxygen content in chemical processes

#### NOTICE

#### Molecular hydrogen

Hydrogen causes sensitivity in other substances and leads to false low readings or, at the worst, total failure of the sensor.

- ▶ Only use the COS22D-**\*\*1/3\*\*\*\*\*** sensor in media free of hydrogen.
- ▶ Use the COS22D-**\*\*4\*\*\*\*\*** sensor in media containing hydrogen.

For non-contact digital data transmission, the COS22D sensor must be connected to the digital input of the Liquiline transmitter using the CYK10 measuring cable.

Use of the device for any purpose other than that described, poses a threat to the safety of people and of the entire measuring system and is therefore not permitted.

The manufacturer is not liable for damage caused by improper or non-designated use.

### 2.3 Workplace safety

As the user, you are responsible for complying with the following safety conditions:

- Installation guidelines
- Local standards and regulations
- Regulations for explosion protection

**Electromagnetic compatibility**

- The product has been tested for electromagnetic compatibility in accordance with the applicable European standards for industrial applications.
- The electromagnetic compatibility indicated applies only to a product that has been connected in accordance with these Operating Instructions.

## 2.4 Operational safety

**Before commissioning the entire measuring point:**

1. Verify that all connections are correct.
2. Ensure that electrical cables and hose connections are undamaged.
3. Do not operate damaged products, and protect them against unintentional operation.
4. Label damaged products as defective.

**During operation:**

- ▶ If faults cannot be rectified:  
products must be taken out of service and protected against unintentional operation.

## 2.5 Product safety

### 2.5.1 State of the art

The product is designed to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate. The relevant regulations and European standards have been observed.

### 2.5.2 Electrical equipment in hazardous areas

**For all approvals**

- To avoid incendive sparking, you must install the titanium hazardous area versions COS22D-BA\*\*\*D\*3, COS22D-GC\*\*\*D\*3, COS22D-8A\*\*\*D\*3, COS22D-TA\*\*\*D\*3 and COS22D-NA\*\*\*D\*3 in such a way that they are protected against impact and friction.
- When transporting, installing and performing maintenance in the hazardous area, you must also avoid sparks resulting from impact and friction on the sensor shaft or membrane body.
- The use of these versions in liquid media with solid particles must be avoided.

**ATEX II 1G / IECEx Ex ia IIC T3/T4/T6 Ga**

The Memosens inductive sensor cable connection system, consisting of:

- oxygen sensor Oxymax COS22D-BA\*\*\*\*\*3 and
- measuring cable CYK10-G\*\*\*

is suitable for use in hazardous areas according to type examination certificate BVS 04 ATEX E 121 X. The corresponding EU Declaration of Conformity is part of this document.

- The certified Oxymax COS22D-BA<sup>\*\*\*\*3</sup> oxygen sensor, in conjunction with the CYK10-G<sup>\*\*\*</sup> measuring cable, may be connected only to certified, intrinsically safe, digital sensor circuits of the Liquiline M CM42-OE/F/I<sup>\*\*\*\*\*</sup> transmitter. The electrical connection must be made according to the wiring diagram.
- Oxygen sensors for use in the Ex area have a special conductive O-ring. The electrical connection of the metallic sensor shaft to the conductive mounting location (such as a metallic assembly) takes place via the O-ring.
- You must connect the assembly or the installation location to ground according to the Ex guidelines.
- The sensors must not be operated under electrostatically critical process conditions. Avoid strong steam or dust currents that act directly on the connection system.
- Hazardous area versions of digital sensors with Memosens technology are indicated by a red-orange ring in the plug-in head.
- The maximum permitted cable length between the sensor and transmitter is 100 m (330 ft).

**NEPSI Ex ia IIC T3/T4/T6 Ga**

The Memosens inductive sensor cable connection system, consisting of:

- oxygen sensor Oxymax COS22D-NA<sup>\*\*\*\*3</sup> and
- measuring cable CYK10-G<sup>\*\*\*</sup>

is approved for use in explosive atmospheres in accordance with the National supervision and inspection center for Explosion protection and Safety of Instrumentation (NEPSI) in China.

The certified oxygen sensor Oxymax COS22D-NA<sup>\*\*\*\*3</sup> may only be connected to the following certified, intrinsically safe, digital sensor circuits in conjunction with the measuring cable CYK10-G<sup>\*\*\*</sup>, or a Memosens cable with an identical structure both in terms of hardware and function:

- Liquiline CM42-OJ<sup>\*\*\*\*\*</sup>
- Alternatively to an approved, intrinsically safe Memosens sensor output that supplies the following values at the very maximum:

Parameter set 1	Parameter set 2
$U_0 = 5.1 \text{ V}$ $I_0 = 130 \text{ mA}$ $P_0 = 166 \text{ mW}$ (linear output characteristic) $C_i = 15 \text{ }\mu\text{F}$ $L_i = 95 \text{ }\mu\text{H}$	$U_0 = 5.04 \text{ V}$ $I_0 = 80 \text{ mA}$ $P_0 = 112 \text{ mW}$ (trapezoidal output characteristic) $C_i = 14.1 \text{ }\mu\text{F}$ $L_i = 237.2 \text{ }\mu\text{H}$

- The electrical connection must be made according to the wiring diagram.
- Oxygen sensors for use in the Ex area have a special conductive O-ring. The electrical connection of the metallic sensor shaft to the conductive mounting location (such as a metallic assembly) takes place via the O-ring.
- You must connect the assembly or the installation location to ground according to the Ex guidelines.
- If the CYK10-G<sup>\*\*\*</sup> cable is installed with its terminal head in Ex zone 0, the cable must be protected against electrostatic charge.
- The user may not change the configuration. Only in this way will the explosion protection of the unit remain intact. Every change puts safety at risk.
- The sensors must not be operated under electrostatically critical process conditions. Avoid strong steam or dust currents that act directly on the connection system. The metal sensor shaft must be installed at the mounting location in such a way that it is electrostatically conductive (< 1 MΩ).

- To mount, use and maintain the product, you must follow the information in the Operating Instructions and the following standards:
  - GB50257 -1996 "Code for construction and acceptance of electric device for explosion atmospheres and fire hazard electrical equipment installation engineering"
  - GB3836.13-1997 "Electrical apparatus for explosive gas atmospheres Part 13: Repair and overhaul for apparatus used in explosive gas atmospheres"
  - GB3836.15-2000 "Electrical apparatus for explosive gas atmospheres- Part 15: Electrical installations in hazardous area (other than mines)"
  - GB3836.16-2006 "Electrical apparatus for explosive gas atmospheres- Part 16: Inspection and maintenance of electrical installation (other than mines)"
- Hazardous area versions of digital sensors with Memosens technology are indicated by a red-orange ring in the plug-in head.
- The maximum permitted cable length between the sensor and transmitter is 100 m (330 ft).

#### FM/CSA IS/NI Cl.1 Div.1 GP: A-D

Observe the documentation and the control drawings of the transmitter.

#### Temperature classes ATEX, IECEx, FM/CSA and NEPSI

	Temperature class		
	T3	T4	T6
Ambient temperature $T_a$	-5 to +135 °C	-5 to +120 °C	-5 to +70 °C
Reference temperature $T_{ref}$	+25 °C		

#### TIIS Ex ib IIC T4

The certified oxygen sensor Oxymax COS22D-TA\*\*\*\*\*3 may only be connected to the certified, intrinsically safe, digital sensor circuit of the transmitter Liquiline M CM42-OT\*\*\*\*\* in conjunction with the measuring cable CYK10-U\*\*1.

#### Temperature classes TIIS

	T4
Ambient temperature $T_a$	-5 to +60 °C
Reference temperature $T_{ref}$	+25 °C




## 3 Device description, function

### 3.1 Amperometric measuring principle

The oxygen molecules that diffuse through the membrane are reduced at the cathode to hydroxide ions (OH<sup>-</sup>). At the anode, silver is oxidized to silver ions (Ag<sup>+</sup>) (this forms a silver halide layer). A current flows due to the electron donation at the cathode and the electron acceptance at the anode. Under constant conditions, this flow is proportional to the oxygen content of the medium. This current is converted in the transmitter and indicated on the display as an oxygen concentration in mg/l, µg/l, ppm, ppb or Vol%, as a saturation index in % SAT or as an oxygen partial pressure in hPa.

### 3.2 Sensor design



1 COS22D

1	Plug-in head	4	O-ring 8.5 x 1.5 mm	7	Glass part with anode and cathode
2	Thrust collar	5	Membrane body	8	Process seal 10.77 x 2.62 mm
3	Sensor shaft	6	Shaft sleeve	9	Process connection Pg 13.5

### 3.3 Membrane body

The oxygen dissolved in the medium is transported to the membrane by the necessary flow. The membrane is permeable for dissolved gases only. Other substances dissolved in the liquid phase, e.g. ionic substances, will not penetrate through the membrane. Therefore, medium conductivity has no impact on the measuring signal.

The sensor is shipped with a standard membrane body, which can be used for all common applications. The membrane is pretensioned at the factory and can be installed immediately.



Electrolytes are version-specific and **cannot** be mixed in a single application!

### 3.4 Memosens technology

Sensors with Memosens protocol have an integrated electronics unit that stores calibration data and other information. Once the sensor has been connected, the sensor data are transferred automatically to the transmitter and used to calculate the measured value.

- ▶ Call up the sensor data via the corresponding DIAG menu.

Digital sensors can store measuring system data in the sensor. These include the following:

- Manufacturer data
  - Serial number
  - Order code
  - Date of manufacture
- Calibration data
  - Calibration date
  - Calibration values
  - Number of calibrations
  - Serial number of the transmitter used to perform the last calibration
- Operating data
  - Temperature application range
  - Date of initial commissioning
  - Hours of operation under extreme conditions
  - Number of sterilizations

### 3.5 Polarization

When the sensor is connected to the transmitter, a fixed voltage is applied between the cathode and anode. The polarization current this creates can be identified on the transmitter with a reading that is initially high, but decreases with time. The sensor cannot be calibrated until the reading is stable.

Reference value for nearly complete polarization of a sensor that was previously stored for a long time:

- COS22D-\*1: 2 hours
- COS22D-\*3/4: 12 hours

After this time, even measurements close to the determination limit are useful. The necessary polarization time is reduced for sensors that were in use shortly beforehand.

## 4 Incoming acceptance and product identification

### 4.1 Incoming acceptance

1. Verify that the packaging is undamaged.
  - ↳ Notify the supplier of any damage to the packaging.  
Keep the damaged packaging until the issue has been resolved.
2. Verify that the contents are undamaged.
  - ↳ Notify the supplier of any damage to the delivery contents.  
Keep the damaged goods until the issue has been resolved.
3. Check that the delivery is complete and nothing is missing.
  - ↳ Compare the shipping documents with your order.
4. Pack the product for storage and transportation in such a way that it is protected against impact and moisture.
  - ↳ The original packaging offers the best protection.  
Make sure to comply with the permitted ambient conditions.

If you have any questions, please contact your supplier or your local Sales Center.

### 4.2 Product identification

#### 4.2.1 Nameplate

The nameplate provides you with the following information on your device:

- Manufacturer identification
  - Order code
  - Extended order code
  - Serial number
  - Safety information and warnings
- ▶ Compare the information on the nameplate with the order.

#### 4.2.2 Product identification

##### Product page

[www.endress.com/cos22d](http://www.endress.com/cos22d)

##### Interpreting the order code

The order code and serial number of your product can be found in the following locations:

- On the nameplate
- In the delivery papers

##### Obtaining information on the product

1. Go to [www.endress.com](http://www.endress.com).
2. Call up the site search (magnifying glass).
3. Enter a valid serial number.
4. Search.
  - ↳ The product structure is displayed in a popup window.

5. Click on the product image in the popup window.
  - ↳ A new window (**Device Viewer**) opens. All of the information relating to your device is displayed in this window as well as the product documentation.

### Manufacturer address

Endress+Hauser Conducta GmbH+Co. KG  
 Dieselstraße 24  
 D-70839 Gerlingen

## 4.3 Scope of delivery

The scope of delivery comprises:

- Oxygen sensor with watering cap (filled with tap water) for protecting the membrane
- Electrolyte, 1 bottle, 10 ml (0.34 fl.oz.)
- Tool to push out the membrane body
- Brief Operating Instructions

## 4.4 Certificates and approvals

### 4.4.1 Declaration of Conformity

The product meets the requirements of the harmonized European standards. As such, it complies with the legal specifications of the EU directives. The manufacturer confirms successful testing of the product by affixing to it the **CE** mark.

### 4.4.2 Ex approvals

Version **COS22D-BA**  
 ATEX II 1G / IECEx Ex ia IIC T3/T4/T6 Ga

### 4.4.3 Certification body

DEKRA EXAM GmbH  
 Bochum

### 4.4.4 Material certificates

#### Manufacturer declaration of FDA compatibility

The manufacturer declares the use of FDA-listed materials.

Product	FDA certificate for
COS22D-****22	Membrane, O-rings, process seal
COS22Z-*2*2	Membrane, O-rings, process seal
COS22D-****23	Membrane, O-rings
COS22Z-*2*3	Membrane, O-rings

### Hazardous area versions

For operation in FDA processes, another FDA-approved seal must be installed before the process seal (for example CPA442). Doing so will sufficiently separate the process from the Ex connection.

**Material test certificate**

A test certificate 3.1 in accordance with EN 10204 is supplied depending on the version (→ Product Configurator on the product page).

**4.4.5 EHEDG**


Compliance with EHEDG's criteria for hygienic design

- TÜV Rheinland, Apeldorn, Netherlands
- Certificate type: Type EL Class I

## 5 Installation

### 5.1 Installation conditions

#### 5.1.1 Orientation




2 Permitted orientations

A0030545

The sensor must be installed at an angle of inclination of 10 to 170 ° in an assembly, holder or appropriate process connection. Recommended angle: 45° to prevent the attachment of air bubbles.

Inclination angles other than those mentioned are not permitted. In order to avoid buildup and condensation on the spot, do **not** install the sensor upside down.

 Follow the instructions for installing sensors in the Operating Instructions for the assembly used.

#### 5.1.2 Mounting location


1. Choose a mounting location that is easy to access.
2. Ensure that upright posts and assemblies are fully secured and vibration-free.
3. Choose a mounting location with an oxygen concentration that is typical for the application.

## 5.2 Mounting the sensor

### 5.2.1 Measuring system

A complete measuring system comprises:

- an Oxymax COS22D oxygen sensor
- Measuring cable CYK10
- A transmitter, e.g. Liquiline CM42
- Optional: an assembly, e.g. permanent installation assembly CPA442, flow assembly CPA240 or retractable assembly CPA875



A0022853

3 Example of a measuring system with COS22D-\*1

- 1 Liquiline CM42
- 2 Measuring cable CYK10
- 3 Oxymax COS22D-\*1 digital oxygen sensor
- 4 Permanent installation assembly CPA442

## 5.2.2 Installing at a measuring point

Must be installed in a suitable assembly (depending on the application).

### **WARNING**

#### **Electrical voltage**

In the event of a fault, non-grounded metallic assemblies may be live and as such are not safe to touch!

- ▶ When using metallic assemblies and installation equipment, national grounding provisions must be observed.

For complete installation of a measuring point, proceed as follows:

1. Install a retractable or a flow assembly (if used) into the process.
2. Connect the water supply to the rinse connections (if you are using an assembly with a cleaning function).
3. Install and connect the oxygen sensor.

### **NOTICE**

#### **Installation error**

Cable breakage, loss of sensor due to cable separation, unscrewing of membrane cap!

- ▶ Do not install the sensor freely suspended from the cable.
- ▶ Screw the sensor into the assembly, ensuring that the cable is not twisted.
- ▶ Hold on to the sensor body during installation or removal. Turn **only at the hexagonal nut** of the armored coupling. Otherwise you might unscrew the membrane cap. This will then remain in the assembly or process.
- ▶ Avoid exerting excessive tensile force on the cable (e.g. through jerky pulling movements).
- ▶ Choose a mounting location that is easy to access for later calibrations.
- ▶ Follow the instructions for installing sensors in the Operating Instructions for the assembly used.


## 5.3 Installation examples

### 5.3.1 Permanent installation (CPA442)

The permanent installation assembly CPA442 enables easy adaptation of a sensor to nearly any process connections from Ingold nozzles to Varivent or Tri-Clamp connections. This kind of installation is very well suited for tanks and larger pipes. You will achieve a defined immersion depth of the sensor into the medium in the simplest way.


### 5.3.2 Immersion operation

#### Universal holder and chain assembly



4 Chain holder on railing

- 1 Chain
- 2 Holder Flexdip CYH112
- 3 Rail
- 4 Sensor Oxymax
- 5 Wastewater assembly Flexdip CYA112




5 Chain holder on upright post

- 1 Weather protection cover CYY101
- 2 Controller / transmitter
- 3 Chain
- 4 Wastewater assembly Flexdip CYA112
- 5 Sensor Oxymax
- 6 Holder Flexdip CYH112



### Universal holder and fixed immersion tube




A0030567

6 Assembly holder with immersion tube

- 1 Protective cover
- 2 Controller / transmitter
- 3 Flexdip CYA112 immersion assembly
- 4 Sensor Oxymax
- 5 Assembly holder Flexdip CYH112

### Basin rim mounting with immersion tube




A0030568

7 Basin rim mounting

- 1 Pendulum holder CYH112
- 2 Assembly Flexdip CYA112
- 3 Assembly float
- 4 Sensor Oxymax

**Float**

The CYA112 float is for use in the case of large fluctuations in water level, for example in rivers or lakes.




- 1 Cable run with strain relief and rain shield
- 2 Fixing ring for rope and chains with terminal screw
- 3 Eyelets Ø15, 3 x 120 ° for anchoring
- 4 Plastic float, resistant to salt water
- 5 Pipe 40 x 1, stainless steel 1.4571
- 6 Bumper and ballast
- 7 Oxygen sensor

8 Dimensions in mm (inch)


**5.3.3 Flow assembly**

**CPA240**

The flow assembly CPA240 offers up to three installation spaces for sensors with a shaft diameter of 12 mm (0.47"), a shaft length of 120 mm (4.7"), and a Pg 13.5 process connection. It very well suited for use in pipelines or hose connections. To prevent measured error with trace measurements, pay particular attention to complete ventilation of the assembly.



9 Flow assembly CPA240 with protective cover




10 Bypass installation

- 1 Main pipe
- 2 Medium removal
- 3, 6 Manually actuated or solenoid valves
- 4 Sampling
- 5 Flow assembly with installed sensor
- 7 Medium return

### Flow assembly for water treatment and processes

The compact stainless steel assembly offers space for a 12-mm sensor with a length of 120 mm. The assembly has a low sampling volume and, with the 6-mm connections, it is best suited for residual oxygen measurement in water treatments and boiler feedwater. The flow comes from below.




11 Flow assembly

- 1 Built-in sensor
- 2 Drain
- 3 Wall mount (clamp D29)
- 4 Inflow

### 5.3.4 Retractable assembly (CPA875 or CPA450)

The assembly is designed for installation on tanks and pipes. Suitable nozzles must be available for this.

Install the assembly at places with constant flow. The minimum pipe diameter is DN 80.



12 Permissible and impermissible sensor installation positions with retractable assembly

- 1 Ascending pipe, best position
- 2 Horizontal pipe, sensor top down, impermissible due to air cushion or foam bubble forming
- 3 Horizontal pipe, lateral installation with permissible installation angle (acc. to sensor version)
- 4 Upside-down installation, unsuitable
- 5 Down pipe, impermissible

**NOTICE****Sensor not in the medium all the way, buildup, upside-down installation**

These can all cause incorrect measurements!

- ▶ Do not install assembly at points where air pockets or bubbles may form.
- ▶ Avoid or regularly remove deposits on the sensor membrane.
- ▶ Do not install sensor upside down.

## 5.4 Post-installation check

1. Are the sensor and cable undamaged?
2. Is the orientation correct?
3. Is the sensor installed in an assembly and is not suspended from the cable?
4. Avoid the penetration of moisture by fitting the protection cap on the immersion assembly.

## 6 Electrical connection


### **⚠ WARNING**

#### Device is live!

Incorrect connection may result in injury or death!

- ▶ The electrical connection may be performed only by an electrical technician.
- ▶ The electrical technician must have read and understood these Operating Instructions and must follow the instructions contained therein.
- ▶ **Prior** to commencing connection work, ensure that no voltage is present on any cable.


### 6.1 Quick wiring guide (COS22D-BA/NA only)



A0024123

## 6.2 Connecting the sensor

The electrical connection simulator to the transmitter is established using measuring cable CYK10.



14 Measuring cable CYK10

## 6.3 Ensuring the degree of protection

Only the mechanical and electrical connections which are described in these instructions and which are necessary for the required, designated use, may be carried out on the device delivered.

- ▶ Exercise care when carrying out the work.

Otherwise, the individual types of protection (Ingress Protection (IP), electrical safety, EMC interference immunity) agreed for this product can no longer be guaranteed due, for example to covers being left off or cable (ends) that are loose or insufficiently secured.

## 6.4 Post-connection check

Device condition and specifications	Notes
Are the sensor, assembly, or cables free from damage on the outside?	Visual inspection
Electrical connection	Notes
Are the mounted cables strain-relieved and not twisted?	
Is a sufficient length of the cable cores stripped, and are the cores positioned in the terminal correctly?	Check the fit (by pulling gently)
Are all the screw terminals properly tightened?	Tighten
Are all cable entries mounted, tightened and leak-tight?	For lateral cable entries, make sure the cables loop downwards to allow water to drip off
Are all cable entries installed downwards or mounted laterally?	

## 7 Calibration and adjustment

Calibration is a means of adapting the transmitter to the characteristic values of the sensor.

Calibration of the sensor is essential according to:

- Initial commissioning
- Changing the membrane or electrolyte
- Long pauses in operation without power supply

Within the framework of system monitoring, for example, calibration can also be cyclically monitored (at typical time intervals, depending on operating experience) or renewed.

### 7.1 Types of calibration

You can carry out a slope or zero point calibration for the sensor.

In most applications, single-point calibration in the presence of oxygen is sufficient (=calibration of the sensor slope). When switching from process to calibration conditions, you have to allow a longer settling time for the sensor.

The additional calibration of the zero point improves the accuracy of the measurement results at trace concentrations. You can calibrate the zero point using nitrogen (min. 99.995%) or oxygen-free water. Make sure that the sensor is polarized and the measured value is settled at the zero point (at least 20-30 minutes) to prevent later incorrect measurements at trace concentrations.

The following describes calibration of the slope in air (saturated with water vapor) as the easiest and recommended calibration method. However, this type of calibration is possible only if the air temperature is  $\geq 0\text{ }^{\circ}\text{C}$  ( $32\text{ }^{\circ}\text{F}$ ).

### 7.2 Calibration in air

1. Remove the sensor from the medium.
  2. Clean the outside of the sensor with a damp cloth.
  3. Allow a temperature compensation time of approx. 20 minutes for the sensor in the ambient air. Make sure that the sensor is not exposed to any direct ambient effects (direct sunlight, drafts) during this time.
  4. Is the measured value display on the transmitter stable:  
Perform the calibration in accordance with the Operating Instructions for the transmitter. Pay particular attention to the software settings for the stability criteria for calibration and for the ambient pressure.
  5. Where necessary:  
Adjust sensor.
  6. Then place the sensor back into the medium.
- Follow the calibration instructions in the Operating Instructions for the transmitter used.

### 7.3 Calculation example for the calibration value

As a check, you can calculate the expected calibration value (transmitter display) as shown in the following example (salinity is 0).

1. Determine the following:

- The ambient temperature for the sensor (air temperature for **Air 100% rh** or calibration methods **Air variable**, water temperature for **H2O air-saturated** calibration method)
- The altitude above sea level
- The current air pressure (= relative air pressure based on sea level) at the time of calibration. (If undeterminable, use 1013 hPa.)

2. Determine the following:

- The saturation value S acc. to Table 1
- The altitude factor K acc. to Table 2

Table 1

T [°C (°F)]	S [mg/l=ppm]	T [°C (°F)]	S [mg/l=ppm]	T [°C (°F)]	S [mg/l=ppm]	T [°C (°F)]	S [mg/l=ppm]
0 (32)	14.64	11 (52)	10.99	21 (70)	8.90	31 (88)	7.42
1 (34)	14.23	12 (54)	10.75	22 (72)	8.73	32 (90)	7.30
2 (36)	13.83	13 (55)	10.51	23 (73)	8.57	33 (91)	7.18
3 (37)	13.45	14 (57)	10.28	24 (75)	8.41	34 (93)	7.06
4 (39)	13.09	15 (59)	10.06	25 (77)	8.25	35 (95)	6.94
5 (41)	12.75	16 (61)	9.85	26 (79)	8.11	36 (97)	6.83
6 (43)	12.42	17 (63)	9.64	27 (81)	7.96	37 (99)	6.72
7 (45)	12.11	18 (64)	9.45	28 (82)	7.82	38 (100)	6.61
8 (46)	11.81	19 (66)	9.26	29 (84)	7.69	39 (102)	6.51
9 (48)	11.53	20 (68)	9.08	30 (86)	7.55	40 (104)	6.41
10 (50)	11.25						

Table 2

Altitude [m (ft)]	K	Altitude [m (ft)]	K	Altitude [m (ft)]	K	Altitude [m (ft)]	K
0 (0)	1.000	550 (1800)	0.938	1050 (3450)	0.885	1550 (5090)	0.834
50 (160)	0.994	600 (1980)	0.932	1100 (3610)	0.879	1600 (5250)	0.830
100 (330)	0.988	650 (2130)	0.927	1150 (3770)	0.874	1650 (5410)	0.825
150 (490)	0.982	700 (2300)	0.922	1200 (3940)	0.869	1700 (5580)	0.820
200 (660)	0.977	750 (2460)	0.916	1250 (4100)	0.864	1750 (5740)	0.815
250 (820)	0.971	800 (2620)	0.911	1300 (4270)	0.859	1800 (5910)	0.810
300 (980)	0.966	850 (2790)	0.905	1350 (4430)	0.854	1850 (6070)	0.805
350 (1150)	0.960	900 (2950)	0.900	1400 (4600)	0.849	1900 (6230)	0.801
400 (1320)	0.954	950 (3120)	0.895	1450 (4760)	0.844	1950 (6400)	0.796
450 (1480)	0.949	1000 (3300)	0.890	1500 (4920)	0.839	2000 (6560)	0.792
500 (1650)	0.943						

3. Calculate factor L:

$$L = \frac{\text{Relative air pressure at calibration}}{1013 \text{ hPa}}$$


4. Calculate calibration value C:



$$C = S \cdot K \cdot L$$

**Example**

- Air calibration at 18 °C (64 °F), altitude 500 m (1650 ft) above sea level, current air pressure 1009 hPa
- $S = 9.45 \text{ mg/l}$ ,  $K = 0.943$ ,  $L = 0.996$
- Calibration value  $C = 8.88 \text{ mg/l}$ .

 You do not need factor K in the table if your measuring device returns the absolute air pressure  $L_{\text{abs}}$  (air pressure depending on altitude) as the measured value. The formula for calculation is then:  $C = S \cdot L_{\text{abs}}$ .


## 7.4 Zero point calibration

The zero point is not so important when working with relatively high concentrations of oxygen.

However, once oxygen sensors are used at low concentrations and in the trace range, they must also be calibrated at the zero point.

Zero point calibrations are demanding as the ambient medium - usually air - already has a high oxygen content. This oxygen must be blocked off for zero point calibration of the sensor.

A calibration with zero-point gel can be used here:

The oxygen-depleting gel COY8 (→  35) creates an oxygen-free medium for zero point calibration.

Prior to sensor zero point calibration, check the following:

- Is the sensor signal stable?
- Is the value displayed plausible?


1. If the sensor signal is stable:  
Calibrate the zero point.
2. If necessary:  
Adjust the sensor to the zero point.

The reference method (sample calibration in zero point) can also be used here if appropriate collecting vessels or reference measurement are available.

 If the oxygen sensor is calibrated too early, this can result in an incorrect zero point.

Rule of thumb: Operate the sensor in zero-point gel for at least 0.5 h.

If the sensor was already operated in the trace range before the zero point calibration, the time specified above generally suffices. If the sensor was operated in air, significantly more time must be factored in to also remove residual oxygen from any dead volume inherent to the design. Here a value of 2 hours applies as a general rule.

 Follow the instructions in the kit documentation enclosed with the zero-point gel.

## 8 Commissioning

### 8.1 Function check

Prior to initial commissioning, ensure that:

- The sensor is correctly installed
- The electrical connection is correct
- There is sufficient electrolyte in the membrane cap  
The transmitter is not displaying a warning about electrolyte depletion



Please note the information on the safety data sheet to ensure safe use of the electrolyte.

If using an assembly with automatic cleaning function:

- ▶ Check that the cleaning medium (water or air, for example) is connected correctly.

#### **WARNING**

##### **Escaping process medium**

Risk of injury from high pressure, high temperatures or chemical hazards!

- ▶ Before applying pressure to an assembly with cleaning system, ensure that the system has been connected correctly.
- ▶ If you cannot reliably establish the correct connection, do not install the assembly in the process.



Following commissioning, the sensor must be serviced at regular intervals, as only then can reliable measurement be guaranteed.



Operating Instructions for the transmitter used, such as BA01245C if using the Liquiline CM44x or CM44xR.

### 8.2 Sensor polarization

#### **NOTICE**

##### **Incorrect measurements due to ambient influences!**

- ▶ Always avoid strong direct sunlight on the sensor.
- ▶ Comply with the instructions for commissioning in the Operating Instructions of the transmitter used.

The sensor has been tested at the factory for proper functioning and is shipped in a condition in which it is ready to operate.

To prepare for calibration:

1. Remove the sensor protection cap.
2. Expose the sensor, which is dry on the outside, to the air atmosphere.
  - ↳ The air should be saturated with water vapor. Therefore, install the sensor as close as possible to a water surface. However, the sensor membrane must remain dry during calibration. Therefore, avoid direct contact with the water surface.
3. Connect the sensor to the transmitter.
4. Switch on the transmitter.
  - ↳ When the sensor is connected to the transmitter, the polarization takes place automatically after the transmitter powers up.
5. Wait for polarization time to elapse.


### 8.3 Sensor calibration

Calibrate the sensor (e.g. air calibration) immediately after the polarization time elapses.

The calibration intervals depend greatly on:

- The application
- The installation position of the sensor

The following method helps you determine the necessary calibration intervals:

1. Inspect the sensor one month after commissioning. To do so, remove the sensor from the medium and dry it off.
  2. After 10 minutes, measure the oxygen saturation index in air.
    - ↳ Decide using the results:
      - a) Measured value not  $100 \pm 2$  %SAT? → Calibrate the sensor.
      - b) Measured value =  $100 \pm 2$  %SAT? → Double the length of time to the next inspection.
  3. Proceed as indicated in Step 1 after two, four and eight months.
    - ↳ This allows you to determine the optimum calibration interval for your sensor.
-  In any case, calibrate the sensor at least once a year.

## 9 Troubleshooting

- ▶ If one of the following problems is present:  
Check the measuring system in the order shown.

Problem	Testing	Remedial action
Nothing displayed, no reaction from the sensor	Power supply to the transmitter?	▶ Connect power supply.
	Sensor cable connected correctly?	▶ Establish correct connection.
	Medium flow present?	▶ Create medium flow.
	Deposit buildup on the membrane?	▶ Clean sensor.
	No electrolyte in the measuring chamber?	▶ Refill or replace electrolyte.
Displayed value too high	Polarization ended?	▶ Wait for polarization time to elapse.
	Is sensor calibrated/adjusted?	▶ Recalibrate/readjust.
	Displayed temperature clearly too low?	▶ Check sensor, if necessary send sensor in for repair.
	Membrane visibly stretched?	▶ Replace membrane cap.
	Electrolyte contaminated?	▶ Replace electrolyte.
	Open the sensor and dry the electrodes. Is the transmitter reading now at 0?	<ol style="list-style-type: none"> <li>1. Check the cable connection.</li> <li>2. If the problem persists: Send sensor in for repair.</li> </ol>
Displayed value too low	Is sensor calibrated/adjusted?	▶ Recalibrate/readjust.
	Medium flow present?	▶ Create medium flow.
	Displayed temperature clearly too high?	▶ Check sensor, if necessary send sensor in for repair.
	Deposit buildup on the membrane?	▶ Clean sensor.
	Electrolyte contaminated?	▶ Replace electrolyte.
Display value fluctuating greatly	Membrane visibly stretched?	▶ Replace membrane cap.
	Open the sensor and dry the electrodes. Is the transmitter reading now at 0?	<ol style="list-style-type: none"> <li>1. Check the cable connection.</li> <li>2. If the problem persists: Send sensor in for repair.</li> </ol>

1. Pay attention to the troubleshooting information in the Operating Instructions for the transmitter.
2. Check the transmitter if necessary.

## 10 Maintenance

Take all the necessary precautions in time to ensure the operational safety and reliability of the entire measuring system.

### NOTICE

#### Effects on process and process control!

- ▶ When carrying out any work on the system, bear in mind any potential impact this could have on the process control system and the process itself.
- ▶ For your own safety, only use genuine accessories. With genuine parts, the function, accuracy and reliability are also ensured after maintenance work.

### 10.1 Maintenance schedule



Maintenance cycles depend to a great extent on the operating conditions.

The following rule of thumb applies:

- Constant conditions, e.g. Power plant = long cycles (1/2 year)
- Widely varying conditions, e.g. daily CIP or SIP cleaning = short cycles (1 month or shorter)




The following method helps you determine the necessary intervals:

1. Inspect the sensor one month after commissioning. To do so, remove the sensor from the medium and dry it.
2. After 10 minutes, measure the oxygen saturation index in air.
  - ↳ Decide using the results:
    - a) Measured value not  $100 \pm 2$  %SAT? → Service the sensor.
    - b) Measured value =  $100 \pm 2$  %SAT? → Double the length of time to the next inspection.
3. Proceed as indicated in Step 1 after two, four and eight months.
  - ↳ This allows you to determine the optimum maintenance interval for your sensor.

 Particularly in the case of widely fluctuating process conditions, damage may occur to the membrane even within a maintenance cycle. You can recognize this by implausible sensor behavior. (→  28)

### 10.2 Maintenance tasks

The following tasks are mandatory:

1. Clean the sensor glass body with anode and cathode (particularly if the membrane is dirty). →  29
2. Replace wear parts or consumables. →  30
3. Check measurement function. →  33
4. Recalibrate (if desired or necessary).
  - ↳ Follow the Operating Instructions for the transmitter.

### 10.3 Cleaning of sensor

The measurement can be corrupted by sensor fouling or malfunction due to the following, for example:

Deposit buildup on the sensor membrane

↳ This results in a longer response time and, under certain circumstances, a reduced slope.

For reliable measurement, the sensor must be cleaned at regular intervals. The frequency and intensity of the cleaning operation depend on the medium.

Clean the sensor:

- Before every calibration
- At regular intervals during operation as necessary
- Before returning it for repairs


Type of contamination	Cleaning
Salt deposits	<ol style="list-style-type: none"> <li>1. Immerse the sensor in drinking water or in 1-5 % hydrochloric acid (for a few minutes).</li> <li>2. Then rinse it with copious amounts of water.</li> </ol>
Dirt particles on the sensor shaft and shaft sleeve ( <b>not membrane!</b> )	<ul style="list-style-type: none"> <li>▶ Clean sensor shaft and sleeve with water and a suitable sponge.</li> </ul>
Dirt particles on membrane or membrane body	<ul style="list-style-type: none"> <li>▶ Clean the membrane with water and a soft cloth.</li> </ul>

- ▶ After cleaning:  
Rinse with copious amounts of clean water.

### 10.4 Wear parts and consumables

Parts of the sensor are subject to wear during operation. By taking suitable measures, you can restore the normal operating function.

Corrective action	Reason
Replace sealing rings	Visible damage to a sealing ring
Replace electrolyte	Unstable or implausible measuring signal or fouling of the electrolyte
Replace membrane body	Membrane is damaged or can no longer be cleaned (hole or overstretching)




15 COS22D

- |                 |                       |                                     |
|-----------------|-----------------------|-------------------------------------|
| 1 Plug-in head  | 4 O-ring 8.5 x 1.5 mm | 7 Glass part with anode and cathode |
| 2 Thrust collar | 5 Membrane body       | 8 Process seal 10.77 x 2.62 mm      |
| 3 Sensor shaft  | 6 Shaft sleeve        | 9 Process connection Pg 13.5        |

### 10.4.1 Replacing sealing rings

It is compulsory to replace the sealing ring if it is visibly damaged. For replacement, use only original sealing rings.

The following O-rings can be replaced:

- Sealing ring for shaft sleeve: item 4 →  30
- Sealing ring to process (conductive for Ex): item 8

If the sealing ring on the membrane body (item 5) is damaged, you must replace the entire membrane body.

### 10.4.2 Replacing electrolyte

The electrolyte is used up gradually during operation. This is caused by electrochemical substance reactions. In de-energized state, no substance reactions take place, and the electrolyte is not used up. The operating time of the electrolyte is shortened by diffusion of dissolved gases such as H<sub>2</sub>S, NH<sub>3</sub> or high concentrations of CO<sub>2</sub>.

Theoretical operating time at p<sub>O2</sub> = 210 mbar and T=25 °C (77 °F)

COS22D-\*1 (standard sensor): > 1.5 years

COS22D-\*3/4 (trace sensor): > 3 months

#### CAUTION

#### The standard electrolyte is a strong irritant

Danger of severe skin and eye irritation!

- ▶ Be absolutely certain to observe the corresponding workplace safety regulations.
- ▶ Wear protective gloves and goggles when handling the electrolyte.
- ▶ In case of eye contact: Remove contact lenses, rinse eyes with water for a few minutes and contact a doctor.
- ▶ In case of skin contact: Take off wet clothing immediately, wash the skin or take a shower.

#### Generally, the following applies:

- The electrolyte must be changed if the membrane body is detached.
- Sensors operated close to the zero point consume hardly any chemical electrolyte. The electrolyte does not have to be replaced for a long period.
- Sensors operated at high oxygen partial pressures (> 100 hPa) consume a significant amount of electrolyte. The electrolyte has to be replaced frequently.
- 25 ml of electrolyte is enough to fill the membrane body approx. 15 times.

#### Draining the electrolyte

1. Disconnect the sensor from the transmitter and remove it from the medium.
2. Clean the exterior of the sensor.
3. Hold the sensor vertically and unscrew the shaft sleeve.
  - ↳ The membrane body is either in the shaft sleeve or is still on the glass part with the anode and cathode.
4. Remove the membrane body. For this purpose, use the tool provided to push out the membrane body.
5. Drain the membrane body and rinse it with potable water.

#### Topping up the electrolyte and installing the membrane body

1. Pour fresh electrolyte from the supply bottle into the membrane body.
2. Remove all air bubbles from the electrolyte by tapping the side of the membrane body (using a pen or pencil, for example).
3. Hold the sensor vertically and carefully fit the membrane body, filled with electrolyte, onto the glass part.

4. Carefully screw on the shaft sleeve and tighten until the stop.

#### Putting the sensor back into operation

1. Connect the sensor to the transmitter.
2. Polarize the sensor and recalibrate it.
3. After this:  
Re-immerses the sensor into the medium.
4. Check that the transmitter does not signal an alarm.

### 10.4.3 Replacing the membrane body

#### Removing the membrane body

1. Disconnect the sensor from the transmitter and remove it from the medium.
2. Clean the exterior of the sensor.
3. Hold the sensor vertically and unscrew the shaft sleeve.  
↳ The membrane body is either in the shaft sleeve or is still on the glass part with the anode and cathode.
4. Remove the membrane body. For this purpose, use the tool provided to push out the membrane body.
5. Dispose of the old membrane body and the old electrolyte.
6. Take a **new** membrane body out of its packaging.

#### Topping up the electrolyte and installing the membrane body

1. Pour fresh electrolyte from the supply bottle into the membrane body.
2. Remove all air bubbles from the electrolyte by tapping the side of the membrane body (using a pen or pencil, for example).
3. Hold the sensor vertically and carefully fit the membrane body, filled with electrolyte, onto the glass part.
4. Carefully screw on the shaft sleeve and tighten until the stop.

#### Putting the sensor back into operation

1. Connect the sensor to the transmitter.
2. Polarize the sensor and recalibrate it.
3. After this:  
Re-immerses the sensor into the medium.
4. Check that the transmitter does not signal an alarm.


### 10.4.4 Replacing glass body with cathode

#### NOTICE

**Polishing the cathode can cause the impaired functioning or total failure of the sensor!**

- ▶ Do not clean the cathode mechanically.

If the cathode is coated with buildup replace the glass body:

1. Hold the sensor vertically and unscrew the shaft sleeve: item 6 →  30.
2. If the membrane body (item 5) remains on the glass body (item 7) and not in the shaft sleeve:  
Remove it from the glass body.
3. Rinse the glass body, along with the anode and cathode, using distilled water.



4. Pull the used glass body out of the holder.
5. Dry the inside of the electrode holder.
6. Plug a new glass body (from the membrane kit) into the holder so that it fits. When doing so, ensure that you do not damage the electrical contact pins.
7. Fill the membrane body with electrolyte and screw the shaft sleeve back on.

## 10.5 Checking the measurement function

1. Remove the sensor from the medium.
2. Clean and dry the membrane.
3. After about 10 minutes, measure the oxygen saturation index in air (without recalibration).
  - ↳ The measured value should be at  $100 \pm 2$  % SAT.

## 11 Accessories

The following are the most important accessories available at the time this documentation was issued.

- ▶ For accessories not listed here, please contact your Service or Sales Center.

### 11.1 Assemblies (selection)

#### Cleanfit CPA875

- Retractable process assembly for sterile and hygienic applications
- For in-line measurement with standard sensors with 12 mm diameter, e.g. for pH, ORP, oxygen
- Product Configurator on the product page: [www.endress.com/cpa875](http://www.endress.com/cpa875)



Technical Information TI01168C

#### Flowfit CPA240

- pH/redox flow assembly for processes with stringent requirements
- Product Configurator on the product page: [www.endress.com/cpa240](http://www.endress.com/cpa240)



Technical Information TI00179C

#### Unifit CPA442

- Installation assembly for food, biotechnology and pharmaceuticals
- With EHEDG and 3A certificate
- Product Configurator on the product page: [www.endress.com/cpa442](http://www.endress.com/cpa442)



Technical Information TI00306C

#### Cleanfit CPA450

- Manual retractable assembly for installing sensors with a diameter of 120 mm in tanks and pipes
- Product Configurator on the product page: [www.endress.com/cpa450](http://www.endress.com/cpa450)



Technical Information TI00183C

#### Flow assembly

- For sensors with  $\varnothing$  12 mm and length 120 mm
- Compact stainless steel assembly with low sampling volume
- Order No.: 71042404

### 11.2 Measuring cable

#### 11.2.1 Cable for COS22D

##### Memosens data cable CYK10

- For digital sensors with Memosens technology
- Product Configurator on the product page: [www.endress.com/cyk10](http://www.endress.com/cyk10)



Technical Information TI00118C

##### Memosens data cable CYK11

- Extension cable for digital sensors with Memosens protocol
- Product Configurator on the product page: [www.endress.com/cyk11](http://www.endress.com/cyk11)



Technical Information TI00118C

## 11.3 Zero-point gel

### COY8

Zero-point gel for oxygen and disinfection sensors

- Oxygen-free and chlorine-free gel for the verification, zero point calibration and adjustment of oxygen and disinfection measuring points
- Product Configurator on the product page: [www.endress.com/coy8](http://www.endress.com/coy8)



Technical Information TI01244C

## 11.4 Maintenance kit

### COS22Z

- Service Kit, COS22 and COS22D
- Ordering information: [www.endress.com/cos22d](http://www.endress.com/cos22d) under "Accessories/spare parts"

## 12 Repair

### 12.1 Spare parts and consumables

#### COS22Z

- Service Kit, COS22 and COS22D
- Ordering information: [www.endress.com/cos22d](http://www.endress.com/cos22d) under "Accessories/spare parts"

### 12.2 Return

The product must be returned if repairs or a factory calibration are required, or if the wrong product was ordered or delivered. As an ISO-certified company and also due to legal regulations, Endress+Hauser is obliged to follow certain procedures when handling any returned products that have been in contact with medium.

To ensure the swift, safe and professional return of the device:

- ▶ Refer to the website [www.endress.com/support/return-material](http://www.endress.com/support/return-material) for information on the procedure and conditions for returning devices.

### 12.3 Disposal

The device contains electronic components. The product must be disposed of as electronic waste.

- ▶ Observe the local regulations.

## 13 Technical data

### 13.1 Input

Measured variables      Dissolved oxygen [mg/l, µg/l, ppm, ppb or %SAT or hPa]  
 Temperature [°C, °F]

Measuring ranges      Measuring ranges apply for 25 °C (77 °F) and 1013 hPa (15 psi)

	Measuring range	Optimum operational range <sup>1)</sup>
COS22D-*1	0.01 to 60 mg/l 0 to 600 % SAT 0 to 1200 hPa 0 to 100 Vol%	0.01 to 20 mg/l 0 to 200 % SAT 0 to 400 hPa 0 to 40 Vol%
COS22D-*3/4	0.001 to 10 mg/l 0 to 120 % SAT 0 to 250 hPa 0 to 25 Vol%	0.001 to 2 mg/l 0 to 20 % SAT 0 to 40 hPa 0 to 4 Vol%

1) Applications in this range guarantee a long service life and minimum maintenance

### 13.2 Performance characteristics

Response time      From air to nitrogen at reference operating conditions:  
 ■  $t_{90}$  : < 30 s  
 ■  $t_{98}$  : < 60 s

Reference operating conditions      Reference temperature:      25 °C (77 °F)  
 Reference pressure:      1013 hPa (15 psi)  
 Reference application:      Air-saturated water


Signal current in air      COS22D-\*1 (standard sensor):      40 to 100 nA  
 COS22D-\*3/4 (trace sensor):      210 to 451 nA

Zero current      COS22D-\*1 (standard sensor):      < 0.1 % of the signal current in air  
 COS22D-\*3/4 (trace sensor):      < 0.03 % of the signal current in air

Measured value resolution      COS22D-\*1 (standard sensor):      10 ppb in aqueous, 0.2 hPa or 0.02 Vol% in gaseous media  
 COS22D-\*3/4 (trace sensor):      1 ppb in aqueous, 0.02 hPa or 0.002 Vol% in gaseous media  
 Corresponds to the recommended measured value resolution at the transmitter

Maximum measured error <sup>1)</sup>	COS22D-*1 (standard sensor): COS22D-*3/4 (trace sensor): * at reference operating conditions	$\leq \pm 1\%$ of measuring range + 10 ppb * $\leq \pm 1\%$ of measuring range + 1 ppb *
Long-term drift	$< 4\%$ per month in reference operating conditions $\leq 1\%$ per month in operation with reduced oxygen concentration ( $< 4\text{ Vol\% O}_2$ )	
Influence of the medium pressure	Pressure compensation not required	
Polarization time	COS22D-*1 (standard sensor): COS22D-*3/4 (trace sensor):	$< 30$ min for 98% signal value, 2 h for 100% $< 3$ h for 98% signal value, 12 h for 100%
Intrinsic oxygen consumption	COS22D-*1 (standard sensor): COS22D-*3/4 (trace sensor):	Approx. 20 ng/h in air at 25 °C (77 °F) Approx. 100 ng/h in air at 25 °C (77 °F)
Operating time of the electrolyte	<p>The electrolyte is used up gradually during operation. This is caused by electrochemical substance reactions. In de-energized state, no substance reactions take place, and the electrolyte is not used up. The operating time of the electrolyte is shortened by diffusion of dissolved gases such as H<sub>2</sub>S, NH<sub>3</sub> or high concentrations of CO<sub>2</sub>.</p> <p>Theoretical operating time at p<sub>O2</sub> = 210 mbar and T=25 °C (77 °F)</p> <p>COS22D-*1 (standard sensor): <math>&gt; 1.5</math> years COS22D-*3/4 (trace sensor): <math>&gt; 3</math> months</p>	
	<p><b>⚠ CAUTION</b></p> <p><b>The standard electrolyte is a strong irritant</b> Danger of severe skin and eye irritation!</p> <ul style="list-style-type: none"> <li>▶ Be absolutely certain to observe the corresponding workplace safety regulations.</li> <li>▶ Wear protective gloves and goggles when handling the electrolyte.</li> <li>▶ In case of eye contact: Remove contact lenses, rinse eyes with water for a few minutes and contact a doctor.</li> <li>▶ In case of skin contact: Take off wet clothing immediately, wash the skin or take a shower.</li> </ul> <p><b>Generally, the following applies:</b></p> <ul style="list-style-type: none"> <li>■ The electrolyte must be changed if the membrane body is detached.</li> <li>■ Sensors operated close to the zero point consume hardly any chemical electrolyte. The electrolyte does not have to be replaced for a long period.</li> <li>■ Sensors operated at high oxygen partial pressures (<math>&gt; 100</math> hPa) consume a significant amount of electrolyte. The electrolyte has to be replaced frequently.</li> <li>■ 25 ml of electrolyte is enough to fill the membrane body approx. 15 times.</li> </ul>	
Temperature compensation	<p>Compensation of the membrane properties takes place in the transmitter between -5 and 90 °C (23 to 194 °F); above 90 °C (194 °F), extrapolation takes place</p> <ul style="list-style-type: none"> <li>■ Measured variable as partial pressure [hPa] or in Vol%: -5 to 90 °C (23 to 194 °F)</li> <li>■ Measured variable as concentration [mg/l]: 0 to 80 °C (32 to 176 °F)</li> <li>■ Measured variable as saturation [%SAT]: -5 to 90 °C (23 to 194 °F)</li> </ul>	

1) In accordance with IEC 60746-1 at rated operating conditions



A0011887

### 13.3 Environment

Ambient temperature range	COS22D-*1 /3:	-5 to +135 °C (23 to 275 °F), non-freezing
	COS22D-*4:	-5 to +50 °C (23 to 120 °F), non-freezing

Storage temperature -5 to +50 °C (20 to 120 °F) at 95% relative humidity, non-condensing

**NOTICE**

**Danger of sensor drying out!**

- Store the sensor with the watering cap only (filled with tap water).

Degree of protection IP 68 (10 m (33 ft) head of water at 25 °C (77 °F) over 45 days, 1 mol/l KCl)


Humidity 0 to 100%, condensating

### 13.4 Process

Process temperature	COS22D-*1 /3 (standard/trace sensor):	-5 to +135 °C (23 to 275 °F), non-freezing
	COS22D-*4 (trace sensor, gold):	-5 to +80 °C (23 to 180 °F), non-freezing

Process pressure Ambient pressure ... 12 bar (... 174 psi) absolute

Temperature-pressure ratings




A0028771-EN

Minimum flow	COS22D-*1 (standard sensor): COS22D-*3/4 (trace sensor):	0.02 m/s (0.07 ft/s) 0.1 m/s (0.33 ft/s)
Chemical resistance	Parts in contact with the medium are chemically resistant to: <ul style="list-style-type: none"> <li>▪ Diluted acids and alkalis</li> <li>▪ Hot water and superheated steam up to max. 135 °C (275 °F)</li> <li>▪ CO<sub>2</sub> up to 100 %, only with trace sensor COS22D-*3</li> </ul>	
	<p><b>NOTICE</b></p> <p><b>Hydrogen sulfide and ammonia shorten the operating life of the sensor!</b></p> <p>▶ Do not use the sensor in applications where it is exposed to hydrogen sulfide or ammonia vapors.</p>	
Cross-sensitivity	COS22D-*1/3 Molecular hydrogen causes false low readings and can, in a worst-case scenario, result in total failure of the sensor. No cross interference from hydrogen with the COS22D-*4 version.	
CIP compatibility	Yes ( COS22D-*1/3 )	
SIP compatibility	Yes, max. 140 °C (284 °F) ( COS22D-*1/3 )	
Autoclavability	Yes, max. 140 °C (284 °F), max. 30 min. (COS22D-*1/3)	

### 13.5 Mechanical construction

Dimensions




16 Dimensions in mm (inch)

A0011881



Flow assembly for sensors with  $\varnothing$  12 mm (accessories)



17 Dimensions in mm (inch)

**Weight** Depending on the design (length)  
0.2 kg (0.44 lbs) to 0.7 kg (1.54 lbs)

<b>Materials</b>	<b>Parts in contact with medium</b>	
	Sensor shaft (depending on the version)	Stainless steel 1.4435 (AISI 316L) Titanium Alloy C22
	Electrode combination	COS22D-*1/3: silver / platinum COS22D-*4: silver / gold
	Process seal	VITON (FDA-compliant)
	Process seal for Ex versions	VITON (not FDA-compliant)
	Seals/O-rings	VITON (FDA-compliant)
	Membrane body, sealing ring for shaft sleeve	Perfluoroelastomer with USP<88> Class VI
Membrane	Silicone (FDA-compliant, in compliance with USP87/88 class VI), PTFE, steel mesh	





**Process connection** Pg 13.5  
Torque max. 3 Nm

**Surface roughness**  $R_a < 0.38 \mu\text{m}$

**Temperature sensor** NTC 22 k $\Omega$

<b>Electrolyte</b>	COS22D-*1 (standard sensor):	Slightly alkaline electrolyte
	COS22D-*3 (trace sensor):	Neutral electrolyte
	COS22D-*4 (trace sensor, gold):	Slightly alkaline electrolyte

# 14 EU Declaration of Conformity

<b>EG/EU-Konformitätserklärung</b> <b>EC/EU-Declaration of Conformity</b> <b>Déclaration CE/UE de Conformité</b>		<b>Endress+Hauser</b>  People for Process Automation															
																	
<b>Company</b>	Endress+Hauser Conducta GmbH+Co. KG Dieselstraße 24, 70839 Gerlingen, Germany erklärt als Hersteller in alleiniger Verantwortung, dass das Produkt declares as manufacturer under sole responsibility, that the product déclare sous sa seule responsabilité en qualité de fabricant que le produit																
<b>Product</b>	Memosens Sensoren / Memosens sensors / Memosens capteurs COS21D-*12*1 COS22D-BA***3 COS51D-G*8*0  zusammen mit Messkabel / together with measuring cable / ensemble avec cable de mesure CYK10-a**b      a = G, E;      b = 1, 2 CYK20-BAab      a = B1, B2;      b = C1, C2																
<b>Regulations</b>	den folgenden Europäischen Richtlinien entspricht: conforms to following European Directives: est conforme aux prescription des Directives Européennes suivantes :  EMC    2014/30/EU ATEX    2014/34/EU																
<b>Standards</b>	angewandte harmonisierte Normen oder normative Dokumente: applied harmonized standards or normative documents: normes harmonisées ou documents normatifs appliqués :  <table border="0" style="width: 100%;"> <tr> <td>EN 61326-1</td> <td>(2013)</td> <td>EN 60079-0</td> <td>(2012)</td> <td>+ A11 (2013)</td> </tr> <tr> <td>EN 61326-2-3</td> <td>(2013)</td> <td>EN 60079-11</td> <td>(2012)</td> <td></td> </tr> <tr> <td></td> <td></td> <td>EN 60079-26</td> <td>(2007)</td> <td>+ Corrigendum 1</td> </tr> </table>		EN 61326-1	(2013)	EN 60079-0	(2012)	+ A11 (2013)	EN 61326-2-3	(2013)	EN 60079-11	(2012)				EN 60079-26	(2007)	+ Corrigendum 1
EN 61326-1	(2013)	EN 60079-0	(2012)	+ A11 (2013)													
EN 61326-2-3	(2013)	EN 60079-11	(2012)														
		EN 60079-26	(2007)	+ Corrigendum 1													
<b>Certification</b>	EG-Baumusterprüfbescheinigungs-Nr.      BVS 04 ATEX E 121 X EC-Type Examination Certificate No. Numéro de l'attestation d'examen CE de type  Ausgestellt von/issued by/développé par      DEKRA EXAM GmbH (0158) Qualitätssicherung/Quality assurance/Système d'assurance      DEKRA EXAM GmbH (0158) qualité  Gerlingen, 20.04.2016 Endress+Hauser Conducta GmbH+Co. KG																
	 i. V. Jörg-Martin Müller Technology	 i. V. Sven-Matthias Scheibe Technology Certifications and Approvals															
<small>EC_00357_01.16</small>																	

## Index

### A

Accessories . . . . .	34
Adjustment . . . . .	23
Ambient temperature range . . . . .	39
Amperometric measuring principle . . . . .	9
Assemblies . . . . .	34
Autoclavability . . . . .	40

### C

Calibration	
Calculation example . . . . .	23
In air . . . . .	23
Types of calibration . . . . .	23
Zero point calibration . . . . .	25
Cathode . . . . .	32
Certification body . . . . .	12
Check	
Connection . . . . .	22
Function . . . . .	26
Installation . . . . .	20
Chemical resistance . . . . .	40
CIP compatibility . . . . .	40
Cleaning	
Sensor . . . . .	29
Connection	
Check . . . . .	22
Ensuring the degree of protection . . . . .	22
Cross-sensitivity . . . . .	40

### D

Declaration of Conformity . . . . .	12
Degree of protection	
Degree of protection . . . . .	39
Ensuring . . . . .	22
Designated use . . . . .	5
Device description . . . . .	9
Dimensions . . . . .	40
Disposal . . . . .	36

### E

EHEDG . . . . .	13
Electrical connection . . . . .	21
Electrolyte . . . . .	38
Operating time . . . . .	31
Properties . . . . .	41
Replacement . . . . .	31
Environment . . . . .	39
Ex approvals . . . . .	12

### F

FDA compatibility . . . . .	12
Function . . . . .	9
Function check . . . . .	26

### G

Glass body . . . . .	32
----------------------	----

### H

Hazardous areas . . . . .	6
Humidity . . . . .	39

### I

Incoming acceptance . . . . .	11
Influence of the medium pressure . . . . .	38
Installation	
Check . . . . .	20
Examples . . . . .	16
Orientation . . . . .	14
Sensor . . . . .	14
Installation instructions . . . . .	14
Intrinsic oxygen consumption . . . . .	38

### L

Long-term drift . . . . .	38
---------------------------	----

### M

Maintenance schedule . . . . .	29
Maintenance tasks . . . . .	29
Manufacturer address . . . . .	12
Material test certificate . . . . .	13
Materials . . . . .	41
Maximum measured error . . . . .	38
Measured value resolution . . . . .	37
Measured variables . . . . .	37
Measurement function . . . . .	33
Measuring cable . . . . .	34
Measuring point . . . . .	15
Measuring principle . . . . .	9
Measuring ranges . . . . .	37
Measuring system . . . . .	14
Medium pressure . . . . .	38
Membrane body	
Description . . . . .	9
Replacement . . . . .	32
Minimum flow . . . . .	40

### N

Nameplate . . . . .	11
---------------------	----

### O

Operational safety . . . . .	6
Orientation . . . . .	14

### P

Performance characteristics . . . . .	37
Polarization . . . . .	10
Polarization time . . . . .	38
Pressure-temperature ratings . . . . .	39
Process . . . . .	39
Process connection . . . . .	41
Process pressure . . . . .	39
Process temperature . . . . .	39
Product identification . . . . .	11
Product safety . . . . .	6

**R**

Reference operating conditions . . . . .	37
Repair . . . . .	36
Replacing sealing rings . . . . .	31
Response time . . . . .	37
Return . . . . .	36

**S**

Safety	
Electrical equipment in hazardous areas . . . . .	6
Operational . . . . .	6
Product . . . . .	6
Workplace safety . . . . .	5
Safety instructions . . . . .	5
Scope of delivery . . . . .	12
Sensor	
Calibration . . . . .	27
Cleaning . . . . .	29
Connecting . . . . .	22
Design . . . . .	9
Mounting . . . . .	14
Polarization . . . . .	10, 26
Sensor design . . . . .	9
Signal current in air . . . . .	37
SIP compatibility . . . . .	40
Spare parts . . . . .	36
State of the art . . . . .	6
Storage temperature . . . . .	39
Surface roughness . . . . .	41
Symbols . . . . .	4

**T**

Technical data	
Environment . . . . .	39
Input . . . . .	37
Mechanical construction . . . . .	40
Performance characteristics . . . . .	37
Process . . . . .	39
Temperature compensation . . . . .	38
Temperature sensor . . . . .	41
Temperature-pressure ratings . . . . .	39
Troubleshooting . . . . .	28

**U**

Use . . . . .	5
---------------	---

**W**

Warnings . . . . .	4
Wear parts and consumables . . . . .	30
Weight . . . . .	41
Workplace safety . . . . .	5

**Z**

Zero current . . . . .	37
Zero solution	
Application . . . . .	25
Zero-point gel . . . . .	35









71436871

[www.addresses.endress.com](http://www.addresses.endress.com)

---