

# HD700 Manometer

## **Software Introduction**

MANOMETER serial software is a program for collecting data from HD700 Manometer when it is connected to a PC or notebook computer. The data may be displayed graphically, as text or exported to Excel or similar programs. The major functions are all listed in the main window.

The maximum number of data points is 17278.

#### **System Required:**

Windows 2000 or Windows XP

#### Minimum Hardware Required:

PC or NoteBook with Pentium 90MHz or higher 32 MB RAM ;

At least 5 MB byte hard disk space available to install MANOMETER serial software.

Recommended display resolution 1024X768 with High Color(16 bit).

# Main Menu



**Stop** - Stop collecting real time data .



Power off-power off the manometer

8 Help document

# **Operation**



- 1 .Power on the manometer first and connect it to a PC USB port with the cable provided
- 2. Run the MANOMETER software program.
- If the connection is successful the panel will display the same value as the manometerr



4. If the connection fails the software will display "- - - -" on the panel window .



5. If you fail to connect, check you cable first, close all other application and then choose other serial ports from the menu until the connection is successful. Wait a few second after a new com port is selected to see if the communication is successful. When successful, the com port selections will turn gray (become inactive).

📴 Ianoneter			
<u>F</u> ile(f) <u>R</u> ealTime(R)	COM Port Help(H)		
	• <u>C</u> om1		
	<u>C</u> om2		
	<u>C</u> om3		
	<u>C</u> om4		
	<u>O</u> ther COM		

### **Plotting Data**

- 1. If the connection is successful click and the Sample Rate dialog box will pop up.
- 2. Enter a number (1 or greater) in the edit box to set the sample rate, then click "OK".

Dialog		X
Sample Rate	1	Sec
	ОК	

The data will start plotting on the Real Time Graph Window



### Zoom in:

- 1. Press the left mouse button and drag a rectangle around the area to be expanded.
- 2. Release the mouse button.
- 3. Use the scrollbar to scroll through all the data.

Δ		<u>م</u>			
		$\sim$	M		
	. MME		L		
			l V		

**Zoom out:** Zoom out to full view by clicking

#### Display of Max, Min, Time, and Average in a selected time range



- 1. Place the mouse cursor on the graph at the starting time of interest and right click. A yellow vertical cursor will appear.
- 2. Place the mouse cursor at the end time and right click. A blue vertical cursor will appear.
- 3. The Max, Min and Avg data from the selected range will appear at the below the graph.
- 4. Press the button to remove the cursors and data.

#### **Display of the Running Max, Min and Average:**

Real-Time Graph							
Open	Export Excel	Sample Rate	1	Sec			
Start Time	21/02/07 15:37:4	voltage stage	Normal	DataNo.	100 Avg	0.377	
Maximum	1.278 @ 15:3	8:15	Minimum	-1.223	@ 15:38:43		
2.0800			:		:	: :	2.0800

- 1. Click the REC button to record the running Max, Min and Average value of the plotted data. The data will appear above the graph.
- 2. Click the UNREC button stop the recording

### Saving the recorded real time data to a file

1. Click the icon to open the file save dialog box.



2. Name the file and save it with the default extension. The file will be saves with the ".AsmDat". extension to be reopened in the Manometer program and also as a ".TXT" file to be opened in other word processing or spreadsheet programs.

#### Opening a saved data file

1. Click the \_\_\_\_\_\_ icon to open a saved file.



2. The opened graph supports Printing, Opening files, Zooming and Cursor data point selection

### **Exporting to Excel**

If the Excel spreadsheet program is installed on the computer, the data from the plotted graph can be directly exported to a spreadsheet.

Click on Export Excel , Excel will open and the data will appear. Save the file as desired.

# **Frequently Asked Questions**

### 1. I connected the manometer to PC port and turned meter power on, I tried all serial ports, and the software always shows"— — — —".

**Answer:** It could be that all serial ports are occupied by other applications. Close all other application, restart your computer and run MANOMETER serial software again. The software will check COM1 first with running. If it shows "— — — —", please choose other COM ports in the software until the connection is successful.

🖣 Lano	nete	er		
<u>F</u> ile(f) <u>R</u> ealTime(R)		<u>C</u> OM Port	Help(H)	
	6		• <u>C</u> om1	
-			<u>C</u> om2	Ē
			<u>C</u> om3	
Pf	RES	SUR	<u>C</u> om4	
			<u>O</u> ther	COM

## 2. Why there is only (\*.AsmDat ) file type selection in the save dialog, and no (\*.TXT) type?

06-12-02 14.18.39. 1Sec	
DataLogger Files (*.AsmDat)	•
DataLogger Files (*.AsmDat)	

**Answer:** Because the text file is creating automatically, as long as you click SAVE in the save dialog, you will get the text file in the same path as the binary file.

#### 3. Why did the error message "Create Excel service failure!" appear when I

clicked Export Excel ?

**Answer:** EXCEL software is not installed on the computer.

#### 4. Why did the software stopped automatically?

**Answer:** If communication is disrupted for any reason the program will stop automatically.