Addendum for MS-748 Flow Computer in Field Mount Enclosure

DESCRIPTION:

The MS-748 Flow Computer satisfies the instrument requirements for a variety of flowmeter types in liquid, gas, steam and heat applications. Multiple flow equations are available in a single instrument with many advanced features. The MS-748 is mounted in an attractive and rugged field mount enclosure.


CAUTIONS AND SAFETY WARNINGS:

Refer to the SUPERtrol II user manual 99589 for all cautions and safety warnings.

MOUNTING GUIDELINES:

When mounting the unit, please consider the following:

- Refer to dimensions for mounting details
- 2. The unit is suitable for mounting in general areas subject to temperatures between 0° and 120° F.
- 3. Do not mount the unit so the display will be facing the sun. Direct sunlight may obscure the display.
- 4. A sun/rain shield (user supplied) is recommended to provide supplemental weather protection.
- The optional mounting brackets (MB option) come preassembled when the option is ordered.





- 1 = Peak Demand
- 2 = AGA NX-19 calculation for natural gas
- 3 = Three Relays
- 4 = Stacked DP option
- 5 = Datalogger option (consult factory)
- 6 = Stack Emissions Controller option
- 7 = Manifold Flowmeter Controller option
- 9 = 3 Relay Super Chip (options 1, 2, 4, 6,7)
- 10 = 2 Relay Super Chip (options 1, 2, 4, 6,7)
- TU = Translation Utility Disk
- MB= Aluminum Mounting Brackets (2)

Accessories:


KEPS-KEP1-32 = KEP RS232 OPC/DDE server for SUPERtrol.
KEPS-MBS32 = Modbus RTU OPC/DDE server
SUPERtrol 2 and LEVELtrol 2 • 32 Bit OPC/DDE Server
P1000 Printer (see Accessories)
IM-2400 = Internal Modem for SUPERtrol Family
MPP2400 = Port Powered Modem
MPP2400N = Port Powered Modem in NEMA4 enclosure
TWP = Industrial Two Way Pager Wireless Data Transceiver

DIMENSIONS:






Optional Mounting Bracket (MB)






User Wiring


Two Relay Wiring



Three Relay Wiring



RS-232 & RS-485 Wiring



RS-485 Wiring

1 Transmit (+) 2 TX-180 Ref

3 Transmit (-) 4 G 180 Ref **RS-232 Wiring**

1 Transmit 2 Receive

3 Ground

4 MP. 5 DCD

6 Do Not Use