

Operating Instructions

Condumax CLS15D/16D/21D

Sensors with Memosens protocol
For conductive measurement of conductivity in liquids







Table of contents








1	About this document	5
1.1	Warnings	5
1.2	Symbols	5
2	Basic safety instructions	6
2.1	Requirements for personnel	6
2.2	Designated use	6
2.3	Workplace safety	6
2.4	Operational safety	7
2.5	Product safety	7
3	Incoming acceptance and product identification	9
3.1	Incoming acceptance	9
3.2	Product identification	10
3.3	Scope of delivery	11
3.4	Certificates and approvals	11
4	Installation	13
4.1	Mounting the sensor	13
4.2	Post-installation check	17
5	Electrical connection	17
5.1	Quick wiring guide	18
5.2	Connecting the sensor	20
5.3	Ensuring the degree of protection	20
5.4	Post-connection check	20
6	Commissioning	21
7	Maintenance	21
8	Repair	22
8.1	Sealing ring replacement and recalibration (CLS16D only)	22
8.2	Return	23
8.3	Disposal	23
9	Technical data	24
9.1	Input	24
9.2	Performance characteristics	25
9.3	Environment	26
9.4	Process	26
9.5	Mechanical construction	28

1 About this document

1.1 Warnings

Structure of information	Meaning
<p> DANGER</p> <p>Causes (/consequences) If necessary, Consequences of non-compliance (if applicable) ► Corrective action</p>	<p>This symbol alerts you to a dangerous situation. Failure to avoid the dangerous situation will result in a fatal or serious injury.</p>
<p> WARNING</p> <p>Causes (/consequences) If necessary, Consequences of non-compliance (if applicable) ► Corrective action</p>	<p>This symbol alerts you to a dangerous situation. Failure to avoid the dangerous situation can result in a fatal or serious injury.</p>
<p> CAUTION</p> <p>Causes (/consequences) If necessary, Consequences of non-compliance (if applicable) ► Corrective action</p>	<p>This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or more serious injuries.</p>
<p>NOTICE</p> <p>Cause/situation If necessary, Consequences of non-compliance (if applicable) ► Action/note</p>	<p>This symbol alerts you to situations which may result in damage to property.</p>

1.2 Symbols

Symbol	Meaning
	Additional information, tips
	Permitted or recommended
	Not permitted or not recommended
	Reference to device documentation
	Reference to page
	Reference to graphic
	Result of a step

2 Basic safety instructions

2.1 Requirements for personnel

- Installation, commissioning, operation and maintenance of the measuring system may be carried out only by specially trained technical personnel.
- The technical personnel must be authorized by the plant operator to carry out the specified activities.
- The electrical connection may be performed only by an electrical technician.
- The technical personnel must have read and understood these Operating Instructions and must follow the instructions contained therein.
- Faults at the measuring point may only be rectified by authorized and specially trained personnel.



Repairs not described in the Operating Instructions provided must be carried out only directly at the manufacturer's site or by the service organization.

2.2 Designated use

The conductivity sensors are designed for the conductive measurement of the conductivity of liquids.

They are used in the following fields:

Sensor	Applications	Hazardous areas
Condumax CLS15D	Measurements in pure and ultrapure water	Approved for Ex zone 0
Condumax CLS16D	Measurements in pure and ultrapure water with hygienic requirements	Approved for Ex zone 0
Condumax CLS21D	Measurements in media with medium or high conductivity	Approved for Ex zone 0

Use of the device for any purpose other than that described, poses a threat to the safety of people and of the entire measuring system and is therefore not permitted.

The manufacturer is not liable for damage caused by improper or non-designated use.

2.3 Workplace safety

As the user, you are responsible for complying with the following safety conditions:

- Installation guidelines
- Local standards and regulations
- Regulations for explosion protection

Electromagnetic compatibility

- The product has been tested for electromagnetic compatibility in accordance with the applicable international standards for industrial applications.
- The electromagnetic compatibility indicated applies only to a product that has been connected in accordance with these Operating Instructions.

2.4 Operational safety

Before commissioning the entire measuring point:

1. Verify that all connections are correct.
2. Ensure that electrical cables and hose connections are undamaged.
3. Do not operate damaged products, and protect them against unintentional operation.
4. Label damaged products as defective.

During operation:

- ▶ If faults cannot be rectified:
products must be taken out of service and protected against unintentional operation.

2.5 Product safety

2.5.1 State-of-the-art technology

The product is designed to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate. The relevant regulations and international standards have been observed.

2.5.2 Electrical equipment in hazardous areas

ATEX/NEPSI II 1G Ex ia IIC T3/T4/T6 Ga

- The Memosens inductive sensor-cable connection system is suitable for use in hazardous areas in accordance with EC type examination certificate BVS 04 ATEX E 121 X. The corresponding EC declaration of conformity is part of this document.
- The certified conductivity sensors CLS15D/CLS16D/CLS21D may only be connected via the measuring cable CYK10-G/I*** to the certified intrinsically safe digital sensor output circuits of measuring device Liquiline M CM42-KE/F/G/I/J***** in accordance with EC type-examination certificate TÜV 13 ATEX 7459 X.
- The electrical connection must be made according to the wiring diagram of the transmitter.
- Metallic process connection parts must be mounted at the mounting location electrostatically conductive (< 1 MΩ).
- The CLS15D-type sensors with non-metal process connections and the CLS21D-type sensors may only be employed for measurement in liquids with a minimum conductivity of 10 nS/cm.
- The CLS15D-type sensors with non-metal process connections may not be operated under process conditions in which electrostatic charging of the sensor, and particularly of the electrically insulated outer electrode, is likely to occur.
- Measuring cable CYK10-G/I*** and its terminal head must be protected against electrostatic charging if it is run through Zone 0.
- The maximum permitted cable length is 100 m.
- Ex versions of digital sensors with Memosens technology are indicated by an orange-red ring.
- Full compliance with regulations for electrical systems in hazardous areas (e.g. EN/IEC 60079-14) is mandatory when using the devices and sensors.

Temperature classes

Name	Type					Medium temp. T _a for temperature class (Tn)	Cat.
Condumax	CLS15D	-	A	**	G	-20 °C ≤ Ta ≤ +135 °C (T3) -20 °C ≤ Ta ≤ +120 °C (T4) -20 °C ≤ Ta ≤ +70 °C (T6)	II 1G
Condumax	CLS15D	-	B/L	**	G	-20 °C ≤ Ta ≤ +135 °C (T3) -20 °C ≤ Ta ≤ +100 °C (T4) -20 °C ≤ Ta ≤ +50 °C (T6)	II 1G
Condumax	CLS16D	-	**	**	G	-5 °C ≤ Ta ≤ +135 °C (T3) -5 °C ≤ Ta ≤ +115 °C (T4) -5 °C ≤ Ta ≤ +65 °C (T6)	II 1G
Condumax	CLS21D	-	*	**	G	-20 °C ≤ Ta ≤ +135 °C (T3) -20 °C ≤ Ta ≤ +115 °C (T4) -20 °C ≤ Ta ≤ +65 °C (T6)	II 1G

If the specified medium temperatures are complied with, temperatures that are not permitted for the respective temperature class will not occur on the equipment.

ATEX/NEPSI II 3G Ex ic IIC T3/T4/T6 Gc

- The Memosens inductive sensor-cable connection system is suitable for use in hazardous areas, Zone 2. The corresponding EU declaration of conformity is part of this document.
- The certified conductivity sensors CLS15D / CLS16D / CLS21D may only be connected via the measuring cable CYK10-V*** to the certified intrinsically safe digital sensor output circuits of measuring device Liquiline M CM42-KV*****.
- The electrical connection must be made according to the wiring diagram of the transmitter.
- Metallic process connection parts must be mounted at the mounting location electrostatically conductive (< 1 MΩ).
- The CLS15D-type sensors with non-metal process connections and the CLS21D-type sensors may only be employed for measurement in liquids with a minimum conductivity of 10 nS/cm.
- The CLS15D-type sensors with non-metal process connections may not be operated under process conditions in which electrostatic charging of the sensor, particularly of the electrically insulated outer electrode, is likely to occur.
- The maximum permitted cable length is 100 m.
- Full compliance with regulations for electrical systems in hazardous areas (EN/IEC 60079-14) is mandatory when using the devices and sensors.

Temperature classes

Name	Type					Medium temp. T _a for temperature class (Tn)	Cat.
Condumax	CLS15D	-	A	**	V	-20 °C ≤ Ta ≤ +135 °C (T3) -20 °C ≤ Ta ≤ +120 °C (T4) -20 °C ≤ Ta ≤ +70 °C (T6)	II 3G
Condumax	CLS15D	-	B/L	**	V	-20 °C ≤ Ta ≤ +135 °C (T3) -20 °C ≤ Ta ≤ +100 °C (T4) -20 °C ≤ Ta ≤ +50 °C (T6)	II 3G

Name	Type					Medium temp. T _a for temperature class (Tn)	Cat.
Condumax	CLS16D	-	**	**	V	-5 °C ≤ T _a ≤ +135 °C (T3) -5 °C ≤ T _a ≤ +115 °C (T4) -5 °C ≤ T _a ≤ +65 °C (T6)	II 3G
Condumax	CLS21D	-	*	**	V	-20 °C ≤ T _a ≤ +135 °C (T3) -20 °C ≤ T _a ≤ +115 °C (T4) -20 °C ≤ T _a ≤ +65 °C (T6)	II 3G

If the specified medium temperatures are complied with, temperatures that are not permitted for the respective temperature class will not occur on the equipment.

FM/CSA IS/NI Cl.1 Div.1&2 Gr. A-D

Observe the documentation and the control drawings of the transmitter.

3 Incoming acceptance and product identification

3.1 Incoming acceptance

1. Verify that the packaging is undamaged.
 - ↳ Notify the supplier of any damage to the packaging.
Keep the damaged packaging until the issue has been resolved.
2. Verify that the contents are undamaged.
 - ↳ Notify the supplier of any damage to the delivery contents.
Keep the damaged goods until the issue has been resolved.
3. Check that the delivery is complete and nothing is missing.
 - ↳ Compare the shipping documents with your order.
4. Pack the product for storage and transportation in such a way that it is protected against impact and moisture.
 - ↳ The original packaging offers the best protection.
Make sure to comply with the permitted ambient conditions.

If you have any questions, please contact your supplier or your local Sales Center.

3.2 Product identification

3.2.1 Type code for versions with explosion protection

Name	Type	Version		
Condumax	CLS15D	- *	**	G
	CLS16D	- **	**	G
	CLS21D	- *	**	G
		Process connections, materials not Ex-relevant		For use in hazardous areas, ATEX/NEPSI II 1G Ex ia IIC T3/T4/T6 Ga, IECEx Ex ia IIC T3/T4/T6 Ga

Name	Type	Version		
Condumax	CLS15D	- *	**	O
	CLS16D	- **	**	O
	CLS21D	- *	**	O
		Process connections, materials not Ex-relevant		For use in hazardous areas, FM/CSA IS/NI CI I Div.1&2 Gr. A-D

Name	Type	Version		
Condumax	CLS15D	- *	**	V
	CLS16D	- **	**	V
	CLS21D	- *	**	V
		Process connections, materials not Ex-relevant		For use in hazardous areas, ATEX/NEPSI II 3G Ex ic IIC T3/T4/T6 Gc

3.2.2 Nameplate

The nameplate provides you with the following information on your device:

- Manufacturer identification
- Order code
- Serial number
- Ambient and process conditions
- Safety information and warnings
- Cell constant (nominal value)
- Degree of protection
- Ex labeling on hazardous area versions

► Compare the information on the nameplate with the order.

3.2.3 Product identification

Product page

www.endress.com/cls15d

www.endress.com/cls16d

www.endress.com/cls21d

Interpreting the order code

The order code and serial number of your product can be found in the following locations:

- On the nameplate
- In the delivery papers

Obtaining information on the product

1. Go to www.endress.com.
2. Call up the site search (magnifying glass).
3. Enter a valid serial number.
4. Search.
 - ↳ The product structure is displayed in a popup window.
5. Click on the product image in the popup window.
 - ↳ A new window (**Device Viewer**) opens. All of the information relating to your device is displayed in this window as well as the product documentation.

Manufacturer's address

Endress+Hauser Conducta GmbH+Co. KG
Dieselstraße 24
D-70839 Gerlingen

3.3 Scope of delivery

The scope of delivery includes:

- Sensor in the version ordered
- Operating Instructions

3.4 Certificates and approvals

3.4.1 CE mark

Declaration of Conformity

The product meets the requirements of the harmonized European standards. As such, it complies with the legal specifications of the EU directives. The manufacturer confirms successful testing of the product by affixing to it the **CE** mark.

3.4.2 Hazardous area approvals

ATEX / NEPSI II 1G Ex ia IIC T3/T4/T6 Ga, IECEx Ex ia IIC T3/T4/T6 Ga
FM/CSA IS/NI Cl. I Div.1&2 Gr. A-D in conjunction with Liquiline M CM42 transmitter

ATEX/NEPSI II 3G Ex ic IIC T3/T4/T6 Gc for use in Zone 2 with Liquiline M CM42-KV*** transmitter

- EAC Ex, OEx ia IIC T6/T4/T3 Ga X
- Zone 0
- Certificate number: TC RU C-DE.AA87.B.00088
- The product has been certified in accordance with Directive TR CU 012/2011 which applies in the European Economic Area (EEA). The EAC conformity mark is affixed to the product.



ATEX and FM/CSA versions of digital sensors with Memosens technology are indicated by an orange-red ring in the plug-in head (sensors for zone 0) or a white-gray axial ring (sensors for zone 2).

3.4.3 EHEDG (CLS16D only)

Certified according to EL Class I, only for process connections:

- Clamp 1"
- Clamp 1 1/2"
- Clamp 2"
- Varivent

3.4.4 FDA (CLS16D only)

All materials in contact with the product are listed by the FDA.

3.4.5 Manufacturer inspection certificate

Stating the individual cell constant

3.4.6 Biological reactivity test (USP class VI, CLS16D only)

Biological reactivity test certificate according to USP (United States Pharmacopeia) part <87> and part <88> class VI with batch traceability of materials in contact with the medium

3.4.7 Inspection certificate in accordance with EN 10204 3.1

A test certificate 3.1 in accordance with EN 10204 is supplied depending on the version (→ Product Configurator on the product page).

3.4.8 ASME (CLS16D only)

Manufactured in accordance with ASME criteria (American Society of Mechanical Engineers)

3.4.9 Ex-certification body

DEKRA EXAM GmbH

Bochum

3.4.10 Marine approvals


A selection of sensors have type approval for marine applications, issued by the following classification societies: ABS (American Bureau of Shipping), BV (Bureau Veritas), DNV-GL (Det Norske Veritas-Germanische Lloyd) and LR (Lloyd's Register). Details of the order codes of the approved sensors, and the installation and ambient conditions, are provided in the relevant certificates for marine applications on the product page on the Internet.

4 Installation

4.1 Mounting the sensor

4.1.1 CLS15D

The sensors are installed directly via the process connection thread NPT 1/2" or 3/4" or clamp 1 1/2". As an option, the sensor can also be installed using a commercially available T-piece or cross fitting or using a flow assembly.




NOTICE


Incorrect mounting or disassembly

The Memosens head could become loose and fall off, resulting in total sensor failure!

- ▶ Only mount the sensor via the process connection.
- ▶ To do so, use a suitable tool, such as an open-ended wrench.



A0019015



A0019014

1 With NPT 1/2" thread in T-piece or cross fitting

1 T-piece or cross fitting (DN 32, 40 or 50)
 2 Glue-in VC threaded coupling (NPT 1/2" for DN 20)
 3 Glue-in adapter coupling (for DN 32, 40, 50)

2 With NPT 1/2" thread in flow assembly 71042405, dimensions in mm (inch)


1 Sensor holder NPT 1/2"
 2 Inlet
 3 Outlet

1. Ensure that the electrodes are fully immersed in the medium during measurement. Immersion depth: at least 35 mm (1.38").
2. If using the sensor in the ultrapure water range, you must work under air-evacuated conditions.
 - ↳ Otherwise, the CO₂ in the air can dissolve in the water and its (weak) dissociation can increase the conductivity by up to 3 µS/cm.


4.1.2 CLS16D

The sensors are installed directly via the process connection.

- ▶ When installing in pipes, pay attention to the flow direction.



3 Permitted flow direction



4 Inadmissible flow direction

1. Ensure that the electrodes are fully immersed in the medium during measurement.
2. If using the sensor in the ultrapure water range, you must work under air-evacuated conditions.
 - ↳ Otherwise, the CO₂ in the air can dissolve in the water and its (weak) dissociation can increase the conductivity by up to 3 μS/cm.


4.1.3 CLS21D



Clamp connection

Both sheet-metal brackets and solid brackets can be used to secure the sensor. Sheet-metal brackets have a lower dimensional stability, uneven bearing surfaces causing point loads, and sometimes sharp edges that can damage the clamp. We recommend you only use solid brackets due to their higher dimensional stability. Solid brackets can be used over the entire pressure/temperature range (see pressure-temperature ratings).

The sensors are installed directly via the process connection. As an option, the sensor can also be installed via a flow assembly.




NOTICE


Incorrect mounting or disassembly

The Memosens head could become loose and fall off, resulting in total sensor failure!

- ▶ Only mount the sensor via the process connection.
- ▶ To do so, use a suitable tool, such as an open-ended wrench.




5 Installation in flow assembly CLA751



6 Installation in flow assembly CLA752

The Dipfit CLA111 immersion assembly is available for installing sensors with G1 thread in vessels.



A0024145

 7 *Installation in Dipfit CLA111 immersion assembly, fastening versions A, B and D*



Ensure that the electrodes are fully immersed in the medium during measurement.

4.2 Post-installation check

1. Are the sensor and cable undamaged?
2. Is the sensor installed in the process connection and is not suspended from the cable?

5 Electrical connection

WARNING


Device is live!

Incorrect connection may result in injury or death!

- ▶ The electrical connection may be performed only by an electrical technician.
- ▶ The electrical technician must have read and understood these Operating Instructions and must follow the instructions contained therein.
- ▶ **Prior** to commencing connection work, ensure that no voltage is present on any cable.

5.1 Quick wiring guide


5.1.1 Sensors for zone 0



A0031174

8 Electrical connection in hazardous environment

5.1.2 Sensors for zone 2




9 Electrical connection in hazardous environment

A0031184

5.2 Connecting the sensor

The electrical connection simulator to the transmitter is established using measuring cable CYK10.



10 Measuring cable CYK10

NOTICE

Mechanical twist protection for CLS15D and CLS21D

If too much force is applied to the Memosens head, this can shear the connections and therefore destroy the sensor!

- ▶ There is no need to exert excessive force when connecting the sensor to the cable coupling. Proceed with care!
- ▶ If the Memosens coupling clearly will not close, check the coupling for dirt or mechanical damage, and make sure that you are turning it in the right direction. Pay attention to the lock symbol on the coupling!
- ▶ If necessary, use a different Memosens cable.

5.3 Ensuring the degree of protection

Only the mechanical and electrical connections which are described in these instructions and which are necessary for the required, designated use, may be carried out on the device delivered.

- ▶ Exercise care when carrying out the work.

Otherwise, the individual types of protection (Ingress Protection (IP), electrical safety, EMC interference immunity) agreed for this product can no longer be guaranteed due, for example to covers being left off or cable (ends) that are loose or insufficiently secured.

5.4 Post-connection check

Device condition and specifications	Action
Are the sensor, assembly, or cables free from damage on the outside?	▶ Perform a visual inspection.
Electrical connection	Action
Are the mounted cables strain-relieved and not twisted?	▶ Untwist the cables.
Is a sufficient length of the cable cores stripped, and are the cores positioned in the terminal correctly?	▶ Pull gently to check they are seated correctly.
Are all the screw terminals properly tightened?	▶ Tighten the screw terminals.

Device condition and specifications	Action
Are all cable entries mounted, tightened and leak-tight?	In the case of lateral cable entries: ▶ Point cable loops downward so that water can drip off.
Are all cable entries installed downwards or mounted laterally?	

6 Commissioning

Prior to initial commissioning, ensure that:

- The sensor is correctly installed
- The electrical connection is correct

If using an assembly with automatic cleaning function:


- ▶ Check that the cleaning medium (water or air, for example) is connected correctly.

WARNING

Escaping process medium

Risk of injury from high pressure, high temperatures or chemical hazards!

- ▶ Before applying pressure to an assembly with cleaning system, ensure that the system has been connected correctly.
- ▶ If you cannot reliably establish the correct connection, do not install the assembly in the process.

 Following commissioning, the sensor must be serviced at regular intervals, as only then can reliable measurement be guaranteed.

 Operating Instructions for the transmitter used, such as BA01245C if using the Liquiline CM44x or CM44xR.

7 Maintenance

CAUTION

Corrosive chemicals

Risk of chemical burns to the eyes and skin and risk of damage to clothing and equipment!

- ▶ It is absolutely essential to protect the eyes and hands properly when working with acids, alkalis and organic solvents!
- ▶ Wear protective goggles and safety gloves.
- ▶ Clean away splashes on clothes and other objects to prevent any damage.
- ▶ Comply with instructions in the safety data sheets for the chemicals used.

⚠ WARNING**Thiocarbamide**

Harmful if swallowed! Limited evidence of carcinogenicity! Possible risk of harm to the unborn child! Dangerous for the environment with long-term effects!

- ▶ Wear protective goggles, protective gloves and appropriate protective clothing.
- ▶ Avoid all contact with the eyes, mouth and skin.
- ▶ Avoid discharge into the environment.

Clean away fouling on the sensor as follows depending on the type of fouling:

1. Oily and greasy films:

Clean with fat solvent, e.g. alcohol, or hot water and agents containing surfactants (alkaline) (e.g. dishwashing detergent).

2. Lime and metal hydroxide buildup and low solubility (lyophobic) organic buildup:

Dissolve buildup with diluted hydrochloric acid (3 %) and then rinse thoroughly with plenty of clear water.

3. Sulfidic buildup (from flue gas desulfurization or wastewater treatment plants):

Use a mixture of hydrochloric acid (3 %) and thiocarbamide (commercially available) and then rinse thoroughly with plenty of clear water.

4. Buildup containing proteins (e.g. food industry):

Use a mixture of hydrochloric acid (0.5 %) and pepsin (commercially available) and then rinse thoroughly with plenty of clear water.

5. Readily soluble biological buildup:

Rinse with pressurized water.

After cleaning, rinse the sensor thoroughly with water.

8 Repair

8.1 Sealing ring replacement and recalibration (CLS16D only)

Intact seals are a prerequisite for safe and reliable measurements. The seal should be replaced at regular intervals to guarantee maximum sensor operational safety and hygiene.

Practical repair intervals can only be determined by the user as they depend greatly on the operating conditions, such as:

- Type and temperature of the product
- Type and temperature of the cleaning agent
- Number of cleanings
- Number of sterilizations
- Operating environment

Recommended intervals for seal replacement (reference values)

Application	Window
Media with temperatures from 50 to 100 °C (122 to 212 °F)	Approx. 18 months
Media with temperatures < 50 °C (122 °F)	Approx. 36 months
Sterilization cycles, max. 150 °C (302 °F), 45 min.	Approx. 400 cycles

To ensure your sensor is operational again after being exposed to very high loads, you can have it regenerated in the factory. In the factory, the sensor is fitted with new seals and recalibrated.

Please contact your sales office for information on replacing the seal and recalibration in the factory.

8.2 Return

The product must be returned if repairs or a factory calibration are required, or if the wrong product was ordered or delivered. As an ISO-certified company and also due to legal regulations, Endress+Hauser is obliged to follow certain procedures when handling any returned products that have been in contact with medium.

To ensure the swift, safe and professional return of the device:

- ▶ Refer to the website www.endress.com/support/return-material for information on the procedure and conditions for returning devices.

8.3 Disposal

The device contains electronic components. The product must be disposed of as electronic waste.

- ▶ Observe the local regulations.

9 Technical data

9.1 Input

9.1.1 Measured variables

- Conductivity
- Temperature

9.1.2 Measuring ranges

Conductivity	(in relation to water at 25 °C (77 °F))
CLS15D -A	0.04 to 20 µS/cm
CLS15D -B/L	0.10 to 200 µS/cm
CLS16D	0.04 to 500 µS/cm
CLS21D	10 µS/cm to 20 mS/cm
Temperature	
CLS15D	-20 to 100 °C (-4 to 212 °F)
CLS16D	-5 to 100 °C (23 to 212 °F)
CLS21D	-20 to 100 °C (-4 to 212 °F)

9.1.3 Cell constant

CLS15D -A	$k = 0.01 \text{ cm}^{-1}$
CLS15D -B/L	$k = 0.1 \text{ cm}^{-1}$
CLS16D	$k = 0.1 \text{ cm}^{-1}$
CLS21D	$k = 1.0 \text{ cm}^{-1}$, nominal

9.1.4 Temperature compensation

NTC 30K

9.2 Performance characteristics

9.2.1 Uncertainty of measurement

CLS15D

Each individual sensor is factory-measured in a solution of approx. 5 $\mu\text{S}/\text{cm}$ for cell constant 0.01 cm^{-1} or approx. 50 $\mu\text{S}/\text{cm}$ for cell constant 0.1 cm^{-1} using a reference measuring system traceable to NIST or PTB. The exact cell constant is entered into the manufacturer inspection certificate supplied. The uncertainty of measurement in determining the cell constant is 1.0 %.

CLS16D

Each individual sensor is factory-measured in a solution of approx. 5 $\mu\text{S}/\text{cm}$ using a reference measuring system traceable to NIST or PTB. The exact cell constant is entered into the manufacturer inspection certificate supplied. The uncertainty of measurement in determining the cell constant is 1.0 %.

CLS21D

Each individual sensor is factory-measured in a solution of approx. 5 mS/cm using a reference measuring system traceable to NIST or PTB. The exact cell constant is entered into the manufacturer inspection certificate supplied. The uncertainty of measurement in determining the cell constant is 1.0 %.

9.2.2 Response time

Conductivity	$t_{95} \leq 3 \text{ s}$
Temperature	
CLS15D-A	$t_{90} \leq 39 \text{ s}$
CLS15D-B/L	$t_{90} \leq 17 \text{ s}$
CLS16D	$t_{90} \leq 13 \text{ s}$
CLS21D	$t_{90} \leq 296 \text{ s}$

9.2.3 Maximum measured error

CLS15D	2% of reading
CLS16D	2 % of reading up to 200 $\mu\text{S}/\text{cm}$ 3 % of reading from 200 to 500 $\mu\text{S}/\text{cm}$
CLS21D	5% of reading

9.2.4 Repeatability

0.2% of reading

9.3 Environment

9.3.1 Ambient temperature

-20 to 60 °C (-4 to 140 °F)

9.3.2 Storage temperature

-25 to +80 °C (-10 to +180 °F)

9.3.3 Degree of protection

IP 68 / NEMA type 6P (1 m water column, 25 °C, 24 h)

9.4 Process

9.4.1 Process temperature

CLS15D

Normal operation

-20 to 120 °C (-4 to 248 °F)

Sterilization (max. 1 h)¹⁾

Max. 140 °C (284 °F)

CLS16D

Normal operation

-5 to 120 °C (23 to 248 °F)

Sterilization (max. 45 min)

Max. 150 °C (302 °F) at 6 bar (87 psi) absolute

CLS21D

-20 to 135 °C (-4 to 275 °F) at 3.5 bar (50 psi) absolute

1) Threaded versions: max. 30 minutes



The maximum temperature for communication with the transmitter is 130 °C (266°F) for the Memosens versions.

9.4.2 Process pressure

CLS15D

13 bar (188 psi) absolute, at 20 °C (68 °F)

2 bar (29 psi) absolute, at 120 °C (248 °F)

CLS16D

13 bar (188 psi) absolute, at 20 °C (68 °F)

9 bar (130 psi) absolute, at 120 °C (248 °F)


0.1 bar (1.5 psi) absolute (negative pressure), at 20 °C (68 °F)

CLS21D

17 bar (246 psi) absolute, at 20 °C (68 °F)

9.4.3 Temperature/pressure ratings

CLS15D




A0031428-EN

11 Mechanical pressure-temperature resistance

A Can be sterilized for a short time (1 hour)

CLS16D




A0031431-EN

12 Mechanical pressure-temperature resistance

A Can be sterilized for a short time (45 min.)

CLS21D



A0031435-EN

13 Mechanical pressure-temperature resistance

9.5 Mechanical construction

9.5.1 Weight

CLS15D and CLS21D

Approx. 0.3 kg (0.66 lbs) depending on version

CLS16D

Approx. 0.13 to 0.75 kg (0.29 to 1.65 lbs) depending on version

9.5.2 Materials

CLS15D

Electrodes	Polished, stainless steel 1.4435 (AISI 316L)
Sensor shaft	Polyethersulfone (PES-GF20)
O-ring, in contact with medium (only Clamp version)	EPDM

CLS16D

Electrodes	Electropolished, stainless steel 1.4435 (AISI 316L)
Seal	Gasket seal ISOLAST (FFKM), FDA-compliant

CLS21D

Electrodes	Graphite
Sensor shaft	Polyethersulfone (PES-GF20)
Thermal conductivity socket for temperature probe	Titanium 3.7035
Clamp process connection	
▪ Process connection	▪ Stainless steel 1.4435
▪ Seal	▪ EPDM

9.5.3 Process connection**CLS15D**

Thread NPT ½" and ¾"
Clamp 1½" as per ISO 2852

CLS16D

Clamp 1", 1½", 2" as per ISO 2852 (also suitable for TRI-CLAMP, DIN 32676)
Tuchenhagen VARIVENT N DN 50 to 125
NEUMO BioControl D50

CLS21D

Thread G1
NPT 1" thread
Clamp 2" as per ISO 2852
Sanitary connection DN 25 and DN 40 as per DIN 11851

9.5.4 Surface roughness (only CLS15D, CLS16D)**CLS15D**

$R_a \leq 0.8 \mu\text{m}$

CLS16D

$R_a \leq 0.8 \mu\text{m}$, electropolished
 $R_a \leq 0.38 \mu\text{m}$, electropolished, optional



71464661

www.addresses.endress.com
