


Electrical Connector Terminal Wiring and Pinout


6-Pin Bayonet
Environmental Rating IP67, Ordering Code -3

Pin No.	4-20 mA Output	Voltage Output
A	V+	V+
B	V-	Common
C		Output
D		
E		
F		




M12x1 (4-Pin)
Environmental Rating IP67, Ordering Code -25

Pin No.	4-20 mA Output	Voltage Output
1	V+	V+
2		
3	V-	Common
4		Output



Integral Cable
Environmental Rating IP67: Ordering Code -16, -36
Environmental Rating IP65: Ordering Code -18

Cable Color	4-20 mA Output	Voltage Output
Brown	V+	V+
Blue	V-	Common
Black		Output
Drain (bare)	Shield	Shield



DIN EN 175301-803 Form A
Environmental Rating IP65, Ordering Code -8, -14

Pin No.	4-20 mA Output	Voltage Output
1	V+	V+
2	V-	Common
3		Output
4		





Figure 1


Pressure Range	Proof Pressure	Burst Pressure
psi	psi	psi
23000	33300	58000
36000	50500	87000
58000	72500	116000
72000	87000	145000
87000	101500	159500
100000	116000	159500
115000	145000	174000
145000	159000	174000

Power Supply Requirements And Ratings

4 mA to 20 mA Output



3-Wire Voltage Output



V+ = Supply voltage
 V- = 4 mA to 20 mA signal
 Output = Voltage Output signal
 Common = Supply voltage return/ground

Load Limitations

4 mA to 20 mA output only
Vmin = 10V + (.020 x RL)
RL = RS + RW
RL = Loop resistance (ohms)
RS = Sense resistance (ohms)
RW = Wire resistance (ohms)

Output Signal	Min Supply	Max Supply	Max Current Consumption
4 mA to 20 mA	10 Vdc	30 Vdc	25 mA
0 Vdc to 5 Vdc	10 Vdc	30 Vdc	8 mA
0 Vdc to 10 Vdc	14 Vdc	30 Vdc	8 mA

Technical Specifications Related To Safety

See product label for specific product input (voltage), output (voltage or current), and pressure ranges.

Temperature Ranges
 Compensated 32 °F to 176 °F (0 °C to 80 °C)
 Media 32 °F to 176 °F (0 °C to 80 °C)
 Ambient -4 °F to 176 °F (-20 °C to 80 °C)
 Storage -40 °F to 185 °F (-40 °C to 85 °C)

Compensated Temperature Error
 0.20% of span / 10 K

Proof Pressure
 Refer to table (Figure 1)

Burst Pressure
 Refer to table (Figure 1)

Ingress Protection Ratings
 IP65 to IP67 Depending on Electrical Connection (Refer to Electrical Connector Terminal Wiring and Pinout)

Shock
 100 g's according to IEC 60068-2-27

Vibration
 15 g's according to IEC 60068-2-6

Uncertainty
 $\pm 0.52\%$ of span, optional $\pm 0.29\%$ of span, including non-linearity best fit straight line, hysteresis, and non-repeatability per IEC 61298-2 at reference conditions:
 • Non-Linearity 0.50%, 0.25%
 • Hysteresis 0.10%
 • Non-repeatability 0.10%

$$\text{Uncertainty} = \sqrt{(\text{Non-linearity})^2 + (\text{Hysteresis})^2 + (\text{Non-repeatability})^2}$$



1010 West Bagley Road • Berea, Ohio 44017
 440-243-0888 • Fax 440-243-3472
 noshok@noshok.com • www.noshok.com



NWD PT41-22



User Manual

PT41 Series High Pressure Fixed Range Transmitter



WARNING

Please read the entire user manual for safe use of product.

NOTE: If NOSHOK PT41 Series High Pressure pressure transmitters are used in a manner not specified in this manual, the protection provided by the equipment may be impaired.

NOTE: The safety of the system is the responsibility of the assembler of the system. See www.noshok.com for further product detail and documentation.

General Description

NOSHOK PT41 pressure transmitters are high performance instruments intended for use in industrial applications where the process media is compatible with the 316 Stainless Steel wetted parts and system temperatures and pressure are within the limits specified herein.

Installation

NOSHOK PT41 pressure transmitters require no special mounting hardware and can be mounted in any orientation with negligible position error.

Although the units can withstand considerable vibration without damage or significant output effects, it is always good practice to mount the transmitter where there is minimum vibration. Refer to product specification for allowable shock and vibration conditions.

When installing or removing the unit apply a wrench to the hex wrench flats, located above the pressure fitting. A 27 mm wrench can be used on the wrench flats of the hex.

Mating connection cable assemblies are available as an accessory part from NOSHOK. Refer to Electrical Connector Terminal Wiring and Pinout for additional detail.

A pressure snubber may be installed to eliminate damaging hammer effects. Water and conventional cleaning detergents are acceptable cleaning agents. Cleaning with unsuitable cleaning agents may damage the instrument or the product label. Do not use any aggressive chemical agents or abrasive cloths or sponges.

Transmitter should be electrically common with earth via the process connection.

- Refer to Power Supply Requirements and Ratings.
- Refer to Electrical Connector Terminal Wiring and Pinout.
- Refer to product technical specification for allowable minimum and maximum temperature and pressure conditions.

General Operation

Pressure spikes in excess of the rated overpressure capability of the transmitter may cause irreversible electrical and/or mechanical damage to the pressure measuring and containing elements. Fluid hammer and surges can destroy any pressure transmitter and must always be avoided.

Maintenance and Service

NOSHOK PT41 pressure transmitters are precisely calibrated, and temperature compensated at the factory to ensure long and stable performance.

The NOSHOK PT41 is capable of being field adjusted for zero offset and span by removing the top cap and adjusting the potentiometers. This product is maintenance-free. Repairs should only be carried out by the manufacturer.

Additional Notes

Any electrical device may be susceptible to damage when exposed to static electrical charges. To avoid damage to the transmitter, observe the following:

- The circuitry of the NOSHOK PT41 pressure transmitters is designed to minimize the effect of electromagnetic and radio frequency interference. To minimize susceptibility to noise, avoid running the termination wiring in a conduit which contains high current AC power cables.
- Where possible avoid running the termination wiring near inductive equipment.

NOTE: The shield and drain wire in the cable (if supplied) is not connected to the transmitter body and is not a suitable ground.